

Левая боковина (продолжение на листе 1)

Цепи переменного напряжения		X	
	49	X 49	SG9 2
	50	X 50	SG9 4
	51	X 51	SG9 6
	52		
Цепи переменного напряжения		X	
	53	X 53	SG10 2
	54	X 54	SG10 4
	55	X 55	SG10 6
	56		
Цепи оперативного тока терминала A1		X	
+EC1	57	X 57	SQ133
	58	X 58	UZ11
	59		
X 310	X 60	60	
	61	X 61	A1-M5.XB 1
	62		
X 314	X 63	63	
	64	X 64	A1-M5.XB 3
	65		
	66	X 66	A1-M5.XB 5
	67	X 67	A1-M5.XB 7
	68	X 68	A1-M5.XB 9
	69	X 69	A1-M5.XB 11
	70	X 70	A1-M5.XB 13
	71	X 71	A1-M5.XB 15
	72	X 72	A1-M5.XB 17
	73		
	74		
	75		
	76		
	77		
	78		
	79		
	80		
-EC1	81	X 81	K1A2
	82	X 82	UZ14
Цепи оперативного тока ГЗ Т		X	
+EC2	83	X 83	KS1-X11
	84	X 84	A1-M5.XB 29
	85		
	86	X 86	A1-M5.XB 19
	87	X 87	KS1-X112
	88	X 88	KS2-X112
	89		
	90		
-EC2	91	X 91	A1-M5.XB 20
	92	X 92	R2 2
Цепи оперативного тока ТЗ Т		X	
+EC3	93	X 93	KS3-X11
	94	X 94	A1-M6.XB 29
	95		
	96		
	97		
	98	X 98	A1-M6.XB 1
	99	X 99	KS3-X112
	100	X 100	A1-M6.XB 5
	101	X 101	KS4-X112
	102	X 102	A1-M6.XB 7
	103	X 103	A1-M6.XB 9
	104	X 104	A1-M6.XB 11
	105	X 105	A1-M6.XB 13
	106	X 106	A1-M6.XB 15
	107	X 107	A1-M6.XB 17
	108	X 108	A1-M6.XB 19
	109	X 109	A1-M6.XB 21
	110	X 110	A1-M6.XB 23

Левая боковина (продолжение на листе 3)

Правая боковина (продолжение на листе 1)

SA2 4	X 215	215		
SA2 6	X 216	216		
SA3 4	X 217	217		
SA3 6	X 218	218		
SA3 8	X 219	219		
SA4 4	X 220	220		
SA4 6	X 221	221		
SA5 4	X 222	222		
SA5 6	X 223	223		
SA5 8	X 224	224		
SA6 4	X 225	225		
SA6 6	X 226	226		
SA7 4	X 227	227		
SA7 6	X 228	228		
SA7 8	X 229	229		
SA8 4	X 230	230		
SA8 6	X 231	231		
SA9 4	X 232	232		
SA9 6	X 233	233		
SA9 8	X 234	234		
SA10 4	X 235	235		
SA10 6	X 236	236		
SA10 8	X 237	237		
SA11 4	X 238	238		
SA12 4	X 239	239		
SA13 4	X 240	240		
SA14 4	X 241	241		
SA15 4	X 242	242		
SA15 6	X 243	243		
SA16 4	X 244	244		
A1-M4.XB 3	X 245	245		
A1-M4.XB 5	X 246	246		
A1-M4.XB 7	X 247	247		
A1-M4.XB 9	X 248	248		
A1-M4.XB 11	X 249	249		
A1-M4.XB 13	X 250	250		
A1-M4.XB 15	X 251	251		
		252		
		253		
		254		
		255		
		256		
		257		
		258		
		259		
		260		
		261		
		262		
X		Цепи сигнализации A1		
A1-M1XP 2	X 263	263		+EH1
		264		
		265		(+)EH1
		266		
		267		
		268		
A1-M1XP 3	X 269	269	X 269	X 326
		270		
		271		
		272		
		273		
		274		
HL1 2	X 275	275		-EH1
		276	X 276	X 333

Правая боковина (продолжение на листе 3)