

Левая боковина (продолжение на листе 1)

Цепи переменного напряжения (НН, СН)		X	
	49	X 49	SG9-2
	50	X 50	SG9-4
	51	X 51	SG9-6
	52		
Цепи переменного напряжения (НН, СН)		X	
	53	X 53	SG10-2
	54	X 54	SG10-4
	55	X 55	SG10-6
	56		
Цепи оперативного тока терминала A1		X	
+EC1	57	X 57	SQ133
	58	X 58	UZ11
	59		
X-310	X-60	60	
	61	X 61	A1-M5.XB-1
	62		
X-314	X-63	63	
	64	X 64	A1-M5.XB-3
	65		
	66	X 66	A1-M5.XB-5
	67	X 67	A1-M5.XB-7
	68	X 68	A1-M5.XB-9
	69	X 69	A1-M5.XB-11
	70	X 70	A1-M5.XB-13
	71	X 71	A1-M5.XB-15
	72	X 72	A1-M5.XB-17
	73		
	74		
	75		
	76		
	77		
	78		
	79		
	80		
-EC1	81	X 81	K1A2
	82	X 82	UZ14
Цепи оперативного тока ГЗ Т		X	
+EC2	83	X 83	KS1-X11
	84	X 84	A1-M5.XB-29
	85		
	86	X 86	A1-M5.XB-19
	87	X 87	KS1-X112
	88	X 88	KS2-X112
	89		
	90		
-EC2	91	X 91	A1-M5.XB-20
	92	X 92	R2-2
Цепи оперативного тока ТЗ Т		X	
+EC3	93	X 93	KS3-X11
	94	X 94	A1-M6.XB-29
	95		
	96		
	97		
	98	X 98	A1-M6.XB-1
	99	X 99	KS3-X112
	100	X 100	A1-M6.XB-5
	101	X 101	KS4-X112
	102	X 102	A1-M6.XB-7
	103	X 103	A1-M6.XB-9
	104	X 104	A1-M6.XB-11
	105	X 105	A1-M6.XB-13
	106	X 106	A1-M6.XB-15
	107	X 107	A1-M6.XB-17
	108	X 108	A1-M6.XB-19
	109	X 109	A1-M6.XB-21
	110	X 110	A1-M6.XB-23

Левая боковина (продолжение на листе 3)

Правая боковина (продолжение на листе 1)

SA2-4	X 215	215		
SA2-6	X 216	216		
SA3-4	X 217	217		
SA3-6	X 218	218		
SA3-8	X 219	219		
SA4-4	X 220	220		
SA4-6	X 221	221		
SA5-4	X 222	222		
SA5-6	X 223	223		
SA5-8	X 224	224		
SA6-4	X 225	225		
SA6-6	X 226	226		
SA7-4	X 227	227		
SA7-6	X 228	228		
SA7-8	X 229	229		
SA8-4	X 230	230		
SA8-6	X 231	231		
SA9-4	X 232	232		
SA9-6	X 233	233		
SA9-8	X 234	234		
SA10-4	X 235	235		
SA10-6	X 236	236		
SA10-8	X 237	237		
SA11-4	X 238	238		
SA12-4	X 239	239		
SA13-4	X 240	240		
SA14-4	X 241	241		
SA15-4	X 242	242		
SA15-6	X 243	243		
SA16-4	X 244	244		
A1-M4.XB-3	X 245	245		
A1-M4.XB-5	X 246	246		
A1-M4.XB-7	X 247	247		
A1-M4.XB-9	X 248	248		
A1-M4.XB-11	X 249	249		
A1-M4.XB-13	X 250	250		
A1-M4.XB-15	X 251	251		
		252		
		253		
		254		
		255		
		256		
		257		
		258		
		259		
		260		
		261		
		262		
X	Цепи сигнализации A1			
A1-M1XP-2	X-263	263		+EH1
		264		
		265		(+)EH1
		266		
		267		
		268		
A1-M1XP-3	X-269	269	X-269	X-326
		270		
		271		
		272		
		273		
		274		
HL1-2	X-275	275		-EH1
		276	X-276	X-333

Правая боковина (продолжение на листе 3)