

Левая доковина (продолжение на листе 2)

		111		
		112		
		113		
		114		
		115		
		116		
-EC3		117	X:117	A1-M6.XB-30
		118	X:118	R4-2
	Цепи ЗДЗ (НН, СН)			X
+EC4		119	X:119	A1-M7.XB-1
		120		
		121	X:121	A1-M6.XB-31
-EC4		122	X:122	A1-M7.XB-2
		123		
	Цепи Ввода (НН, СН)			X
+EC5		124	X:124	A1-M7.XB-7
		125		
		126	X:126	A1-M7.XB-3
		127	X:127	A1-M7.XB-5
-EC5		128	X:128	A1-M7.XB-4
		129		
	Цепи ЗДЗ (НН, СН)			X
+EC6		130	X:130	A1-M7.XB-11
		131		
		132	X:132	A1-M7.XB-9
-EC6		133	X:133	A1-M7.XB-10
		134		
	Цепи Ввода (НН, СН)			X
+EC7		135	X:135	A1-M7.XB-17
		136		
		137	X:137	A1-M7.XB-13
		138	X:138	A1-M7.XB-15
-EC7		139	X:139	A1-M7.XB-14
		140		
	Цепи ЗДЗ (НН, СН)			X
+EC8		141	X:141	A1-M7.XB-21
		142		
		143	X:143	A1-M7.XB-19
-EC8		144	X:144	A1-M7.XB-20
		145		
	Цепи Ввода (НН, СН)			X
+EC9		146	X:146	A1-M7.XB-27
		147		
		148	X:148	A1-M7.XB-23
		149	X:149	A1-M7.XB-25
-EC9		150	X:150	A1-M7.XB-24
		151		
	Цепи ЗДЗ (НН, СН)			X
+EC10		152	X:152	A1-M7.XB-31
		153		
		154	X:154	A1-M7.XB-29
-EC10		155	X:155	A1-M7.XB-30
		156		
	Цепи Ввода (НН, СН)			X
+EC11		157	X:157	A1-M8.XB-5
		158		
		159	X:159	A1-M8.XB-1
		160	X:160	A1-M8.XB-3
-EC11		161	X:161	A1-M8.XB-2
		162		

Правая доковина (продолжение на листе 2)

X	Цепи РАС А1			
A1-M1.XP-5	X:277	277		
A1-M1.XP-15	X:278	278		
		279		
A1-M1.XP-4	X:280	280		
A1-M1.XP-14	X:281	281		
X	Цепи переменного тока А2			
SG11-2	X:282	282		
SG11-4	X:283	283		
SG11-6	X:284	284		
SG11-8	X:285	285		
SG11-10	X:286	286		
SG11-12	X:287	287		
		288		
		289		
SG12-2	X:290	290		
SG12-4	X:291	291		
SG12-6	X:292	292		
SG12-8	X:293	293		
SG12-10	X:294	294		
SG12-12	X:295	295		
		296		
		297		
SG13-2	X:298	298		
SG13-4	X:299	299		
SG13-6	X:300	300		
SG13-8	X:301	301		
SG13-10	X:302	302		
SG13-12	X:303	303		
		304		
		305		
X	Цепи оперативного постоянного тока А2			
SG13-14	X:306	306		+EC12
UZ2-1	X:307	307		
A2-1-X4-2	X:308	308		-EC12
A2-M6.XB-2	X:309	309		
X	Выходные цепи А2			
A2-M2.XB-2	X:310	310	X:310	X-60
A2-M2.XB-4	X:311	311		
		312		
		313		
SA17-4	X:314	314	X:314	X-63
SA18-4	X:315	315		
		316		
		317		
		318		
		319		
X	Цепи сигнализации А2			
A2-M1.XP-2	X:320	320		+EH1
		321		
		322		(+EH1)
		323		
		324		
		325		
A2-M1.XP-3	X:326	326	X:326	X-269
		327		
		328		
		329		
		330		
		331		
		332		-EH1
		333	X:333	X-276

Правая доковина (продолжение на листе 4)