



Dishwasher



BOSCH

aus Operating instructions



aus Table of contents

Safety instructions	4	Washing the dishes	14																																																																												
Delivery	4	Aqua sensor	14																																																																												
Installation	4	Switching on the appliance	14																																																																												
In daily use	4	Timer programming	14																																																																												
Children in the household	4	End of programme	14																																																																												
Door lock	4	Switching off the appliance	14																																																																												
Damage	4	Interrupting the programme	14																																																																												
Disposal	5	Terminating the programme	14																																																																												
Getting to know your appliance	5	Changing the programme	14																																																																												
Control panel	5	Intensive drying	15																																																																												
Appliance interior	5	Maintenance and care	15																																																																												
Rinse aid	6	Overall condition of the machine	15																																																																												
Setting amount of rinse aid	6	Rinse aid	15																																																																												
Switching off rinse-aid refill indicator	6	Filters	16																																																																												
Utensils	7	Spray arms	16																																																																												
Not suitable	7	Waste water pump	17																																																																												
Glass and utensil damage	7	Troubleshooting	17																																																																												
Loading the dishwasher	7	... when the appliance is switched on	17	Unloading the dishwasher	7	... on the appliance	17	Cups and glasses	7	... during the wash cycle	18	Pans	7	... on the utensils	18	Cutlery basket	8	Customer service	19	Folding spikes	8	Installation	20	Cup support clip	8	Safety instructions	20	Small accessories holder	8	Delivery	20	Knife shelf	9	Technical specifications	20	Adjusting the height of the basket	9	Installation	21	Detergent	10	Waste-water connection	21	Adding detergent	10	Fresh water connection	21	Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13
... when the appliance is switched on	17																																																																														
Unloading the dishwasher	7	... on the appliance	17	Cups and glasses	7	... during the wash cycle	18	Pans	7	... on the utensils	18	Cutlery basket	8	Customer service	19	Folding spikes	8	Installation	20	Cup support clip	8	Safety instructions	20	Small accessories holder	8	Delivery	20	Knife shelf	9	Technical specifications	20	Adjusting the height of the basket	9	Installation	21	Detergent	10	Waste-water connection	21	Adding detergent	10	Fresh water connection	21	Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13				
... on the appliance	17																																																																														
Cups and glasses	7	... during the wash cycle	18	Pans	7	... on the utensils	18	Cutlery basket	8	Customer service	19	Folding spikes	8	Installation	20	Cup support clip	8	Safety instructions	20	Small accessories holder	8	Delivery	20	Knife shelf	9	Technical specifications	20	Adjusting the height of the basket	9	Installation	21	Detergent	10	Waste-water connection	21	Adding detergent	10	Fresh water connection	21	Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13								
... during the wash cycle	18																																																																														
Pans	7	... on the utensils	18	Cutlery basket	8	Customer service	19	Folding spikes	8	Installation	20	Cup support clip	8	Safety instructions	20	Small accessories holder	8	Delivery	20	Knife shelf	9	Technical specifications	20	Adjusting the height of the basket	9	Installation	21	Detergent	10	Waste-water connection	21	Adding detergent	10	Fresh water connection	21	Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13												
... on the utensils	18																																																																														
Cutlery basket	8	Customer service	19																																																																												
Folding spikes	8	Installation	20																																																																												
Cup support clip	8	Safety instructions	20	Small accessories holder	8	Delivery	20	Knife shelf	9	Technical specifications	20	Adjusting the height of the basket	9	Installation	21	Detergent	10	Waste-water connection	21	Adding detergent	10	Fresh water connection	21	Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																								
Safety instructions	20																																																																														
Small accessories holder	8	Delivery	20	Knife shelf	9	Technical specifications	20	Adjusting the height of the basket	9	Installation	21	Detergent	10	Waste-water connection	21	Adding detergent	10	Fresh water connection	21	Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																												
Delivery	20																																																																														
Knife shelf	9	Technical specifications	20	Adjusting the height of the basket	9	Installation	21	Detergent	10	Waste-water connection	21	Adding detergent	10	Fresh water connection	21	Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																																
Technical specifications	20																																																																														
Adjusting the height of the basket	9	Installation	21	Detergent	10	Waste-water connection	21	Adding detergent	10	Fresh water connection	21	Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																																				
Installation	21																																																																														
Detergent	10	Waste-water connection	21	Adding detergent	10	Fresh water connection	21	Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																																								
Waste-water connection	21																																																																														
Adding detergent	10	Fresh water connection	21	Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																																												
Fresh water connection	21																																																																														
Overview of programmes	12	Electrical connection	21	Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																																																
Electrical connection	21																																																																														
Programme selection	13	Removing the appliance	22	Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																																																				
Removing the appliance	22																																																																														
Information about comparability tests	13	Transportation	22	Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																																																								
Transportation	22																																																																														
Additional options	13	Protection against frost (Emptying the appliance)	22	Express Wash	13	Waste disposal	22	Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																																																												
Protection against frost (Emptying the appliance)	22																																																																														
Express Wash	13	Waste disposal	22																																																																												
Intensive zone	13	Packaging	22	Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																																																																				
Packaging	22																																																																														
Hygiene	13	Old appliances	22	Half load	13	Extra drying	13																																																																								
Old appliances	22																																																																														
Half load	13																																																																														
Extra drying	13																																																																														

Safety instructions

Delivery

- Check the packaging and dishwasher immediately for damage caused in transit. Do not switch on a damaged appliance, but contact your supplier.
- Please dispose of the packaging material in an environmentally friendly manner.
- Do not let children play with packaging and its parts. There is a risk of suffocation from collapsible boxes and film.

Installation

Read the "Installation" chapter to learn how to install and connect the appliance correctly.

In daily use

- Use the dishwasher only in the household and only for its designed purpose: for washing domestic dishes.
- The appliance is not designed to be used by small children or frail people unless they have been instructed accordingly by a responsible person, thereby ensuring that they can operate the appliance safely. Small children must be instructed not to play with the appliance.
- Do not lean or sit on the open door. The appliance could tip.
- Please note that free-standing appliances may tip over if the baskets are overloaded.
- Do not add any solvents to the washing chamber. Danger of explosion!
- Open the door carefully when the programme is still running. There is a risk of hot water spraying out of the appliance.
- To prevent injuries, e.g. caused by stumbling, open the dishwasher only briefly in order to load and unload the dishwasher.
- Read and observe the safety information and instructions for use on the packaging for cleaning and rinsing agents.

Warning

Knives and other utensils with sharp points must be placed in the cutlery basket with the points downwards or horizontally on the knife shelf *.

* depending on model

Children in the household

- If fitted, use the childproof lock. An exact description can be found in the back of the envelope.
- Do not allow children to play with or operate the appliance.
- Keep children away from detergents and rinse aid. These may cause chemical burns in the mouth, throat and eyes or asphyxiation.
- Keep children away from open dishwasher. The water in the rinsing compartment is not drinking water and could contain detergent residue. Ensure that children do not place fingers in the tablet collecting tray [22]. Small fingers could become caught in the slots.
- If the appliance is installed at eye-level, ensure when opening and closing the door that children are not caught or crushed between the appliance door and the cupboard door situated below.

Childproof lock (door lock) *

The description of the childproof lock is at the back in the envelope.

* depending on model

Damage

- The appliance may be repaired and opened up by a technician only. To do this, disconnect the appliance from the power supply. Pull out the mains plug or switch off the fuse. Turn off the tap.

Disposal

- Make redundant appliances unusable to prevent subsequent accidents.
- Dispose of the appliance in an environmentally friendly manner.

Warning

Children could become locked in the appliance (risk of suffocation) or find themselves in other dangerous situations.

Therefore: Pull out the mains plug, sever and dispose of the power cord. Destroy the door lock so that the door can no longer be closed.

Getting to know your appliance

Diagrams of the control panel and the interior of the appliance can be found in the envelope at the front.

Individual positions are referred to in the text.

Control panel

- 1 ON/OFF switch
- 2 Door opener
- 3 Programme selector
- 4 START button
- 5 Timer programming *
- 6 Additional options **
- 7 Rinse aid refill indicator
- 8 Display "Check water supply"
- 9 End display
- 10 Cleaning display

* depending on model

** Number depending on model

Appliance interior

- 20 Top basket
- 21 Knife shelf *
- 22 Tablet collecting tray
- 23 Top spray arm
- 24 Bottom spray arm
- 25 Filters
- 26 Cutlery basket
- 27 Bottom basket
- 28 Dispenser for rinse aid
- 29 Detergent dispenser
- 30 Lock for detergent dispenser
- 31 Rating plate

* depending on model


Rinse aid

As soon as the rinse-aid refill indicator **[7]** is lit on the fascia, there is still a rinse-aid reserve of 1 – 2 rinsing processes. Refill with rinse aid.


The rinse aid is required for stain-free utensils and clear glasses. Use only rinse aid for domestic dishwashers.

Combined detergents with rinse-aid component may be used up to a water hardness of 21° dH (37° fH, 26° Clarke, 3.7 mmol/l) only. If the water hardness is over 21° dH, rinse aid must be used.

- Open the dispenser **[28]** by pressing and lifting the plate on the cover.



- Carefully pour rinse aid up to the max. mark in the filler opening.



- Close cover until it clicks shut.
- To prevent excessive foam formation during the next rinse cycle, remove any rinse aid which has run over with a cloth.

Setting amount of rinse aid

The amount of rinse aid dispensed can be set in 4 stages. Accordingly 0, 1, 2 or 3 displays are lit (see water hardness table).

Factory setting: 2.

Do not change the amount of rinse aid unless streaks (select lower setting) or water stains (select higher setting) are left on the utensils.

- Close the door.
- Switch on ON/OFF switch **[1]**.
- Press and hold down the START button **[4]**.
- Rotate programme selector **[3]** until the rinse aid refill indicator **[7]** flashes.

- Release button.

The rinse aid refill indicator **[7]** flashes and the displays **[9]** and **[8]** are lit (= Setting 2).

To change the setting:

- Rotate programme selector **[3]** until the required setting has been selected.
- Press START button **[4]**.

The rinse-aid refill indicator **[7]** goes out. The selected setting is saved.

Switching off rinse-aid refill indicator

If the rinse-aid refill indicator **[7]** is impaired (e.g. when using combined detergents containing rinse-aid component), it can be switched off.

- Proceed as described under "Setting amount of rinse aid" and select setting 0.

The rinse aid refill indicator **[7]** is now switched off.

Utensils

Not suitable

- Cutlery and utensils made of wood.
- Delicate decorative glasses, craft and antique utensils. These decors are not dishwasher-proof.
- Plastic parts not resistant to heat.
- Copper and tin utensils.
- Utensils which are soiled with ash, wax, lubricating grease or ink.

Aluminium and silver parts have a tendency to discolour and fade during the wash cycle. Even some types of glass (e.g. crystal glass objects) may turn cloudy after many wash cycles.

Glass and utensil damage

Causes:

- Glass type and glass production process.
- Chemical composition of the detergent.
- Water temperature of the wash programme.

Recommendation:

- Use only glasses and porcelain which the manufacturer designates as dishwasher-proof.
- Use a detergent which protects utensils.
- Take glass and cutlery out of the dishwasher as soon as possible after the programme ends.

Loading the dishwasher

- Remove large food remnants. It is not necessary to prerinse utensils under running water.
- Place the utensils so that
 - they are secure and cannot tip over.
 - all utensils with their openings face down.
 - parts with curves or indentations are at an angle, thereby allowing water to drain.
 - does not obstruct rotation of the two spray arms [23] and [24].

Very small utensils should not be washed in the machine, as they may fall out of the baskets.

Unloading the dishwasher

To prevent water from dripping off the upper basket onto the utensils in the lower basket, it is recommended to empty the appliance from the bottom up.

Hot utensils are sensitive to shock! Therefore, when the programme ends, leave the utensils to cool down in the dishwasher until they can be handled.


Cups and glasses

Top basket [20]



Pans

Bottom basket [27]



Tip

Heavily soiled utensils (pans) should be placed in the bottom basket. The more powerful spray jet provides a better dishwashing result.


Tip

Other examples, such as the best way of loading your dishwasher, can be found on our homepage as a free download. The corresponding Internet address can be found on the back page of these instructions for use.

Cutlery basket


You should always place cutlery unsorted with the points downwards.

To prevent injuries, place long, pointed implements and knives on the knife shelf.

**Folding spikes ***

* depending on model


The spikes can be folded down to improve arrangement of pans, bowls and glasses.

**Cup support clip ***

* depending on model


When washing cups, the cup support clip can be folded up. The additional inclined position reduces the accumulation of water on the underside of the cup.

In the case of tall glasses it is recommended to fold down the cup support clip.

**Small accessories holder ***

* depending on model

Light-weight plastic accessories, e.g. cups, lids, etc. can be held securely in the small accessories holder.




Knife shelf *

* depending on model

Long knives and other utensils can be arranged horizontally.

You can remove the knife shelf to wash taller utensils. Re-insert the knife shelf in the correct position.



Adjusting the height of the basket *

* depending on model

If required, the height of the upper utensils basket [20] can be adjusted to provide more space for tall utensils either in the upper or lower basket.

Appliance height 81.5 cm

	Top basket	Bottom basket
Setting 1 max. ø	22 cm	30 cm
Setting 2 max. ø	24.5 cm	27.5 cm
Setting 3 max. ø	27 cm	25 cm


Appliance height 86.5 cm

	Top basket	Bottom basket
Setting 1 max. ø	24 cm	33 cm
Setting 2 max. ø	26.5 cm	30.5 cm
Setting 3 max. ø	29 cm	28 cm

Select one of the two following procedures according to the design of the top basket for your appliance model:

Top basket with side levers


- Pull out the top basket [20] out.
- To **lower** the basket, press in the left and then the right lever on the outside of the basket. In doing so, hold the sides of the basket along the upper edge to prevent it from suddenly dropping.



- To **raise** the basket, hold the basket on the sides of the upper edge and lift it up.
- Before re-inserting the basket again, ensure that it is at the **same height** on both sides. Otherwise, the appliance door cannot be closed and the upper spray arm will not be connected to the water circuit.

Top basket with upper and lower roller pairs

- Pull out the top basket [20] out.
- Remove the upper basket and re-attach it to the upper (stage 3) or lower (stage 1) rollers.



Detergent

You can use tablets as well as powder or liquid detergents for dishwashers, but never use washing up liquid. The dosage can be individually adjusted with powder or a liquid detergent according to the degree of soiling. Tablets contain an adequately large amount of active ingredients for all cleaning tasks. Modern, powerful detergents predominantly use a low-alkaline formulation with phosphate and enzymes. Phosphates bond the lime in the water. Enzymes break down starch and remove protein. Phosphate-free detergents are less frequent. These have a slightly weaker lime bonding capacity and require a higher dosage. To remove coloured stains (e.g. tea, tomato sauce), oxygen-based bleaching agents are usually used.

Note

To ensure a good washing result, always follow the instructions on the detergent packaging!

If you have further questions, we recommend that you contact the detergent manufacturers' helpline.

⚠ Warning

Read and observe the safety information and instructions for use on the packaging for cleaning and rinsing agents.

Adding detergent


- If the detergent dispenser [29] is still closed, press the lock [30] to open the detergent dispenser.

Pour detergent into the dry detergent dispenser [29] only (insert tablet flat, not on its edge).


Dosage: see manufacturer's instructions on the packaging.

The graduated detergent dispenser [29] helps you add the correct amount of powder or liquid detergent.

Usually 20 ml–25 ml are adequate for normal soiling. If using tablets, one tablet is adequate.



- Close the cover on the detergent dispenser by sliding it up until the lock engages without difficulty.



The detergent dispenser opens automatically at the optimum time depending on the programme. The powder or liquid detergent is distributed in the appliance and is dissolved, the tablet falls into the tablet collecting tray where it dissolves in doses.

Tip

If the utensils are only lightly soiled, slightly less than the indicated amount of detergent is usually adequate.

Suitable detergents and care products can be purchased online via our website or via customer service (see back page).

⚠️ Warnings





- Do **not** place small parts for washing in the tablet collecting tray [22]; this prevents the tablet from dissolving evenly.
- If you want to add more utensils after the programme has started, do **not** use the tablet collecting tray [22] as a handle for the upper basket. The tablet could already be there and you will touch the partially dissolved tablet.

Notes

- If programmes are short, tablets may not have full cleaning effect due to different dissolving properties and there may even be undissolved detergent residue. It is recommended to use washing powder for these programmes.
- The Intensive programme (on some models) requires one tab only. When using washing powder, you can apply some of this cleaning agent to the inside of the appliance's door.
- If using detergents in a water-soluble protective cover: Take hold of the cover with dry hands only and put the detergent into an absolutely dry detergent dispenser only, otherwise the detergent may stick.
- If you switch from combined detergents to solo detergents, ensure that the water softening system and amount of rinse aid have been set to the correct value.

Overview of programmes

The max. possible number of programmes is illustrated in this overview. The corresponding programmes for your appliance can be found on the fascia. The programme data has been measured in the laboratory according to AS/NSZ 2007.

Programme	Type of utensils and soiling	Programme sequence	Possible additional options	Programme data 1.) Duration: hs/mins 2.) Energy consumption in kWh 3.) Water consumption in litres 4.) With Aquasensor
 Pots and Pans 70°	Pots, utensils and cutlery Highly soiled	Prerinse Clean 70° Intermediate rinse Final rinse 70° Dry	All	1.) 2:15 2.) 1,50 3.) 15 4.) 12
 Intensive 65°	Pots, utensils and cutlery Highly soiled	Prerinse Clean 65° Intermediate rinse Final rinse 70° Dry	All	1.) 2:00 2.) 1,45 3.) 14 4.) -
 Auto 45° – 65°	Utensils and cutlery Normally soiled	Is optimised according to the soiling with the aid of sensors.	All	1.) 1:40-2:15 2.) 1,30-1,60 3.) - 4.) 10-11
 Normal 45°	Utensils and cutlery Normally soiled	Prerinse Clean 45° Intermediate rinse Final rinse 45° Dry	All	1.) 2:20 2.) 0,71 3.) 12,3 4.) -
 Quick 45°	Utensils and cutlery Lightly soiled	Clean 45° Intermediate rinse Final rinse 55°	Extra drying	1.) 0:29 2.) 0,80 3.) 10 4.) -
 Prerinse	Lightly soiled	Prerinse	None	1.) 0:15 2.) 0,05 3.) 4 4.) -

Programme selection

You can select a suitable programme according to the type of utensils and degree of soiling.

Information about comparability tests

The conditions for the comparison test are available on request by e-mail from dishwasher@test-appliances.com.

Quote the appliance number (E-Nr.) and the production date (FD) which you can find on the rating plate [31] on the appliance door.

Additional options

* depending on model

Additional options can be set with the buttons [6].

Express Wash *

The >>Express Wash<< function can reduce the running time by approx. 20% to 50% depending on the selected rinse programme. To obtain optimum cleaning and drying results at a reduced running time, water and energy consumption are increased.

Intensive zone *

Perfect for a mixed load. You can wash very soiled pots and pans in the lower basket together with normally soiled utensils in the upper basket. The spray pressure in the lower basket is intensified, the rinsing temperature is increased slightly.

Hygiene *

The temperature is increased during the cleaning process. This increases the hygiene status. This additional option is ideal for cleaning e.g. chopping boards and baby bottles.

Half load *

If you have only a few items to wash (e.g. glasses, cups, plates), you can switch to "half load". This will save water, energy and time. It is recommended to put a little less detergent in the detergent dispenser than for a full load.

Extra drying *

An increased temperature during the final rinse and an extended drying phase ensure that even plastic parts dry better. There is a slight increase in the energy consumption.

Washing the dishes

Aqua sensor *

* depending on model

The Aqua sensor is an optical measuring device (light barrier) which measures the turbidity of the rinsing water.

The Aqua sensor is used according to the programme. If the Aqua sensor is active, "clean" rinsing water can be transferred to the next rinse bath and water consumption can be reduced by 3–6 litres. If the turbidity is greater, the water is drained and is replaced with fresh water. In the automatic programmes the temperature and running time can also be adjusted to the degree of soiling.

Switching on the appliance

- Turn on the tap fully.
- Switch on ON/OFF switch **[1]**.
- Rotate programme selector **[3]** to the required programme.
- Press START button **[4]**.
The Cleaning display **[10]** is lit. the programme starts running.

Timer programming *

* depending on model

You can delay the start of the programme by 3, 6 or 9 hours.

- Switch on ON/OFF switch **[1]**.
- Keep pressing the Preselected starting time button **[5]** until the appropriate display 3h, 6h or 9h is lit.
- Press START button **[4]**, timer programming is activated.
- To delete the preselected starting time, keep pressing the Preselected starting time button **[5]** until none of the displays 3h, 6h or 9h is lit.

You can change your programme selection at any time until the programme starts.

End of programme

The programme has ended when the End display **[9]** is lit.

Switching off the appliance

Short time after the end of the programme:

- Switch off ON/OFF switch **[1]**.
- Turn off the tap (not applicable if Aqua-Stop fitted).
- Remove the utensils when they have cooled down.

Warning

At the end of the programme please open the door fully and not partially when emptying the dishwasher. Any escaping water vapour could damage sensitive worktops.

Interrupting the programme

- Switch off ON/OFF switch **[1]**.
The LEDs go out. The programme is saved.
If the door was opened on an appliance which has a warm water connection or is heated, first leave the door ajar for several minutes and then close. Otherwise, expansion (pressure) may cause the appliance door to spring open or water to run out of the appliance.
- To continue the programme, switch on the ON/OFF switch **[1]** again.

Terminating the programme

(Reset)

- Press START button **[4]** for approx. 3 sec.
The End display **[9]** is lit.
- The remaining programme sequence lasts approx. 1 minute.
Switch off ON/OFF switch **[1]**.

Changing the programme

When the START button **[4]** has been pressed, the programme cannot be changed.

The only way a programme can be changed is by Cancel programme (Reset).

Intensive drying

The final rinse uses a higher temperature which improves the drying result. The running time may increase slightly.
(Caution if utensils are delicate!)

- Close the door.
- Switch on ON/OFF switch **[1]**.
- Press and hold down the START button **[4]**.
- Rotate programme selector **[3]** until the "Check water supply" display **[8]** flashes.
- Release button.

To change the setting,

- By rotating the programme selector **[3]**, you can switch on intensive drying (End display **[9]** is lit) or switch off intensive drying (End display **[9]** is not lit).
- Press START button **[4]**.

The setting is saved.

Maintenance and care

A regular inspection and maintenance of your machine will help to prevent faults. This saves time and prevents problems.

Overall condition of the machine

- Check spray arm for grease and limescale deposits.

If you find such deposits:

- Fill detergent dispenser with detergent. Start the appliance without utensils in the programme with the highest rinsing temperature.

Clean the appliance with detergents/appliance cleaners which are particularly suitable for use with dishwashers.

- Regularly clean door seal with a damp cloth.

Never use a steam cleaner to clean your dishwasher. The manufacturer is not liable for any consequential damage.

Regularly wipe the front of the appliance and fascia with a damp cloth; water and a little washing up liquid are adequate. Do not use sponges with a rough surface or abrasive detergents, as these could scratch the surfaces.

Stainless steel appliances: To prevent corrosion, avoid using sponge cloths or wash them out thoroughly several times before using for the first time.



Warning

Never use other chlorinated household detergents! Health hazard!

Rinse aid



- Check the refill indicator **[7]**. If required, refill rinse aid.

Filters

The filters [25] keep large foreign objects in the rinsing water away from the pump. These foreign objects may occasionally block the filters.

The filter system consists of a coarse filter, a flat fine filter and a microfilter.

- After each washing cycle check the filters for residue.
- Unscrew filter cylinder as illustrated and take out filter system.




- Remove any residue and clean filters under running water.
- Re-install filter system in reverse sequence and ensure that the arrow marks are opposite each other after closing the filter system.

Spray arms

Limescale and contaminants in the rinsing water may block nozzles and bearings on the spray arms [23] and [24].

- Check outlet nozzles on the spray arms for blockages.
- Unscrew the upper spray arm [23].
- Remove the lower spray arm [24] upwards.




- Clean spray arms under running water.
- Re-engage or screw on spray arms.

Waste water pump


Large food remnants in the rinsing water not retained by the filters may block the waste water pump. The rinsing water is then not pumped out and covers the filter.

In this case:

- First disconnect the appliance from the power supply.
- Remove the filters [25].
- Scoop out water, use a sponge if required.
- Using a spoon, prise off pump cover (as illustrated) until it clicks, then grip the cover by the lug and first pull it upwards until it resists and then pull it out forwards.



- Check inner compartment and remove any foreign objects.
- Place cover in the original position, press down and engage.



- Install filters.

Troubleshooting

The majority of faults which could occur in daily operation can be rectified by the user. This ensures that the appliance is quickly available for use again. The following overview will help you locating the causes and gives helpful advise to eliminate them.

Warning

Don't forget: Repairs may be carried out by technicians only. If a component has to be replaced, ensure that only original spare parts are used. Improper repairs or use of non-original spare parts may cause considerable damage and put the user at considerable risk.

... when the appliance is switched on

The appliance does not start.

- The mains fuse has tripped.
- The appliance plug has not been inserted.
- The appliance door has not been shut properly.

... on the appliance

Lower spray arm rotates sluggishly.

- Spray arm blocked.

The door is difficult to open. *

- Child-proof lock is activated. The deactivation instructions are at the back in the envelope.

* depending on model

Door cannot be closed.

- Door lock has been activated. To reset, close the door with greater force.

Cover on the detergent dispenser cannot be closed.

- Detergent dispenser overfilled or mechanism blocked by sticky detergent residue.


Detergent residue in the detergent dispenser.

- Dispenser was damp when filled.

aus

“Check water supply” display **[8]** lights up.

- Tap turned off.
- Water supply interrupted.
- Supply hose kinked.
- Filter in the water supply blocked.
 - Switch off the appliance and pull out the mains plug.
 - Turn off the tap.
 - Clean filter in the supply hose.



- Reconnect power supply.
- Turn on the tap.
- Switch on the appliance.
- Water is left in the appliance at the end of the programme.
 - Waste water hose is blocked or kinked.
 - Waste water pump blocked, cover on the waste water pump is not locked in position
(see Maintenance and care).
 - Filters blocked.
 - The programme has not yet ended. Wait until programme ends or implement “Reset” function.

The “Check water supply” display **[8]** flashes rapidly.

- Water in the safety system.
 - Switch off the appliance and pull out the mains plug.
 - Turn off the tap.
 - Call customer service.

Refill indicator for rinse aid **[7]** is not lit.

- Refill indicator switched off.
- Adequate rinse aid available.

... during the wash cycle

Unusual foam formation.

- Handwash liquid in the rinse aid dispenser.
- Spilled rinse aid causes excessive frothing, therefore please remove with a cloth.

Appliance stops during the wash cycle.

- Power supply interrupted.
- Water supply interrupted.

Filling valves making striking noises

- Caused by the installation of the water line and has no effect on the function of the machine. Remedial action is not possible.

Knocking/rattling noise during rinsing

- Spray arm is striking utensils.
- Utensils not arranged correctly.

... on the utensils

Food residue on the utensils.

- Utensils placed too closely together, utensils basket overfilled.
- Too little detergent.
- Rinse programme too weak.
- Spray arm rotation obstructed.
- Spray arm nozzles blocked.
- Filters blocked.
- Filters incorrectly inserted.
- Waste water pump blocked.
- Top basket on right and left not set to same height.

Tea or lipstick residue is not completely removed.

- The detergent has an inadequate bleaching effect.
- Too low rinsing temperature.
- Too little/unsuitable detergent.

Dull, discoloured glasses, film cannot be washed off.

- Unsuitable detergent.
- Glasses not dishwasher-proof.

Streaks on glasses and cutlery, glasses have metallic appearance.

- Too much rinse aid.

Plastic parts discoloured.

- Too little/unsuitable detergent.
- Too weak programme selected.


Utensils not dry.

- Appliance door opened too early and utensils taken out too early.
- Programme selected without drying.
- Too little/unsuitable rinse aid.
- Activate intensive drying.
- The combined detergent used has a poor drying performance.

Use rinse aid (see Rinse aid chapter for setting).

Customer service

If the advice given does not resolve your problem, please contact your customer service. Contact details can be found on the back cover of this instruction manual or in the enclosed customer service list. When calling , please quote the appliance number (1) and the production date (FD = 2) which can be found on the rating plate [31] on the appliance door.



Rely on the expertise of the manufacturer. Call us to ensure that the repair will be carried out by fully-trained service engineers, who are equipped with original spare parts for your appliance.

Installation

The dishwasher must be connected correctly, otherwise it will not function properly. The specifications for the inlet and outlet as well as the electrical connected loads must correspond with the required criteria as specified in the following paragraphs or in the installation instructions.

Install the appliance in the correct sequence:

- Checking appliance on delivery
- Installing the appliance
- Waste water connection
- Fresh water connection
- Electrical connection

Safety instructions

- Install and connect the appliance according to the installation and assembly instructions.
- Prior to installation, disconnect the dishwasher from the power supply.
- Ensure that the protective conductor system of the domestic supply has been correctly installed.
- The electrical connection conditions must correspond with the specifications on the dishwasher rating plate [31].
- If the power cord of this appliance is damaged, it must be replaced with a particular power cord.

To prevent injury, the power cord may be replaced by customer service only.

- If the dishwasher is installed in a high-sided unit, the unit must be secured properly.
- Install built-under or integratable appliances only under continuous worktops which have been screwed to adjacent cupboards to ensure stability.

- Do not install the appliance near heat sources (radiators, heat storage tanks, cookers or other appliances which generate heat) and do not install under a hob.
- After installing the appliance, ensure that the plug is easily accessible.
- Some models:
The plastic housing on the water connection contains an electric valve, the connecting cables are in the supply hose. Do not cut through this hose, do not immerse the plastic housing in water.

Warning

If the appliance is not in a cavity and a side panel is accessible, the door hinge area must be covered at the side for reasons of safety (risk of injury). The covers are available as optional accessories from customer service or specialist outlets.

Delivery

Your dishwasher has been checked thoroughly in the factory to ensure that it is in working order. This may cause small water stains. These will disappear after the first wash cycle.

Technical specifications

Weight:

max. 60 kg

Voltage:

220–240 V, 50 Hz or 60 Hz

Connected load:

1.9–2.3 kW

Fuse:

10/16 A

Water pressure:

at least 0.05 MPa (0.5 bar), maximum 1 MPa (10 bar). At a higher water pressure: connect pressure-reducing valve ahead.

Inlet rate:

minimum 10 litres/minute

Water temperature:

for cold water connection only.

Installation

The required installation dimensions can be found in the installation instructions. Level the appliance with the aid of the height-adjustable feet. Ensure that the appliance is situated securely on the floor.

- A built-under or integrated appliance which is installed subsequently as a free-standing appliance must be secured to prevent it from overturning, e.g. by screwing it to the wall or by installing it under a continuous worktop which is screwed to adjacent cupboards.
- The appliance can easily be installed in a fitted kitchen between wooden and plastic walls. If the plug is not freely accessible, an allpole disconnector with a contact opening of at least 3 mm must be fitted on the installation side to satisfy the relevant safety instructions.

Waste-water connection

- The required work sequence can be found in the installation instructions. If required, fit a siphon with an drainage connection.
- Connect the waste-water hose to the drainage connection of the siphon with the enclosed parts.
Ensure that the drainage hose is not kinked, crushed or twisted and that there is no cover plate in the drainage to prevent the waste water from flowing out!

Fresh water connection

- Connect the fresh-water connection to the tap according to the installation instructions with the enclosed parts. Ensure that the fresh-water connection is not kinked, crushed or twisted.
- When replacing the appliance, always use a new water supply hose.

Water pressure:

at least 0.05 MPa (0.5 bar), maximum 1 MPa (10 bar). At a higher water pressure: connect pressure-reducing valve ahead.

Inlet rate:

minimum 10 litres/minute

Water temperature:

for cold water connection only.

Electrical connection

- Connect the appliance to an alternating current only, ranging from 220 V to 240 V and 50 Hz or 60 Hz via a correctly installed socket with protective earth conductor. See rating plate for required fusing [31].
- The socket must be near the appliance and freely accessible following installation.
- The connection may be modified by technicians only.
- A power cord extension may be purchased from customer service only.
- Use only a residual current operated circuit-breaker which features the symbol . Only this extension guarantees compliance with the currently valid regulations.
- The appliance features a water damage protection system. Please note the system will not function **unless** the power supply is connected.

Removing the appliance

Also observe the sequence of worksteps here.

- Disconnect the appliance from the power supply.
- Turn off the water supply.
- Disconnect the waste water and fresh water connections.
- Loosen the fastening screws under the worktop.
- If fitted, remove the base panel.
- Pull out the appliance, carefully pulling the hose behind.

Transportation

Empty the dishwasher and secure loose parts.

Drain the appliance according to the following steps:

- Turn on the tap.
- Close the door.
- Switch on ON/OFF switch **[1]**.
- Select programme with the highest temperature.
- Press START button **[4]**.
Programme sequence starts.
- After approx. 4 minutes press the START button **[4]** until the Cleaning display **[10]** goes out.
After approx. 1 min. the End display **[9]** is lit.
- Switch the appliance off **[1]** and turn the tap off.

Transport appliance upright only.

(This prevents residual water from running into the machine control and damaging the programme sequence.)

Protection against frost

If the appliance is in a room where there is a risk of frost (e.g. holiday home), empty the appliance completely (see Transportation).

- Turn off the tap, disconnect supply hose and drain water.

Waste disposal

Both the packaging of new appliances and the old appliances themselves contain valuable raw materials and recyclable materials.

Please dispose of the individual parts separated according to type.

Please ask your dealer or inquire at your local authority about current means of disposal.

Packaging

All plastic parts of the appliance are identified with internationally standardised abbreviations (e.g. >PS< polystyrene). Therefore, plastic waste can be sorted out when the appliance is being disposed of. Please follow the safety instructions under "Delivery".

Old appliances


Please follow the safety instructions under "Disposal of your appliance".




This appliance is identified according to the European guideline 2002/96/EC on waste electrical and electronic equipment – WEEE. The guideline specifies the framework for an EU-wide valid return and re-use of old appliances.

Subject to changes.


Childproof lock (door lock) *



40



41




42

- 40 Activate the childproof lock.
- 41 Open the door with activated childproof lock.
- 42 Deactivate childproof lock.

Always close the appliance door completely when you leave the appliance.
This is the only way you can protect your children from potential dangers.

Baking sheet spray head *



Large sheets or grilles and plates which have a diameter greater than 30 cm (gourmet plates, pasta plates, dinner plates) can be cleaned with the aid of the spray head.
To do this, remove the top basket and insert the spray head as illustrated in the diagram.

To ensure that the spray jet can reach all parts, arrange the baking sheets as illustrated (max. 4 baking sheets and 2 grilles).

Never operate the dishwasher without the top basket or baking sheet spray head!

* some models

AQUA-STOP guarantee

en

(does not apply to appliances without Aqua-Stop)

In addition to warranty claims against the seller based on the purchase contract and in addition to our appliance warranty we will pay damages under the following conditions:

1. If our Aqua-Stop system is defective and causes water damage, we will make good the damage for private users.
To ensure water damage protection, the appliance **must** be connected to the power supply.
2. This liability guarantee is valid for the service life of the appliance.
3. A prerequisite for the warranty claim is that the appliance has been correctly installed and connected with Aqua-Stop according to our instructions. This also includes the correct installation of the Aqua-Stop extension (original accessory). Our warranty does not extend to defective feed lines or fittings up to the Aqua-Stop connection on the tap.
4. If your appliance is fitted with Aqua-Stop, you can leave your appliance unattended during operation and leave the tap turned on afterwards. The tap should only be turned off if you are absent from home for a prolonged period, e.g. several weeks holiday.

Robert Bosch Hausgeräte GmbH
Carl-Wery-Straße 34
81739 München

To book an engineer visit and product advice

GB 0844 / 8928979

Calls from a BT landline will be charged at up to 3 pence per minute.

A call set-up free of up to 6 pence may apply.

IE 01450 2655




Please find the contact data of all countries in the enclosed customer service list.





Internet: www.bosch-home.com




de Montageanleitung	cs Montážní návod
*) über Kundendienst erhältlich	*) K dispozici přes servisní službu
en Installation instructions	sk Návod na montáž
*) Available from customer service	*) Dostanete v službe zákazníkom
fr Notice de montage	pl Instrukcja montażu
*) Disponible par le biais du service après-vente	*) Do uzyskania w punkcie serwisowym
nl Montagevoorschrift	hu Szerelési utasítás
*) Tegen meerprijs bij de Servicedienst verkrijgbaar	*) A vevőszolgálaton keresztül kapható:
it Istruzioni per il montaggio	ro Instrucțiune de montaj
*) Disponibili presso il servizio assistenza clienti	*) obținabile la serviciul pentru clienți
es Instrucciones de montaje	hr Uputa za montažu
*) Se puede adquirir a través del Servicio de Asistencia Técnica Oficial de la marca	*) možno dobiti kod službe održavanja
pt Instruções de montagem	sr Uputstvo za montažu
*) Pode ser adquirido nos nossos Serviços Técnicos	*) Može se nabaviti preko servisne službe
el Οδηγίες τοποθέτησης	sl Navodilo za montažo
*) Διατίθενται από την υπηρεσία τεχνικής εξυπηρέτησης πελατών	*) Lahko nabavite v servisni službi
tr Montaj kılavuzu	mk Упатство за монтажа
*) Yetkili servis üzerinden alınabilir	*) се добива преку службата за купувачи
sv Monteringsanvisning	sq Udhëzues përmontim
*) kan fås via Service	*) Sigurohet nëpërmjet servisit
no Monteringsanvisning	et Monteeringisühend
*) fås hos kundeservice	*) küsige klienditeeninduselt
da Monteringsvejledning	lt Montavimo instrukcija
*) Kan købes hos serviceafdelingen	*) Ja galima gauti klientų aptarnavimo servise
fi Asennusohje	lv Montāžas pamācība
*) Saatavissa huoltopalvelusta	*) Var sajēmēt servisa dienestā

GV 640 Stand 9000 521 334 (0205)




ru Инструкция по монтажу	*) Можно получить в сервисном центре
uk Інструкція з монтажу	*) Можна отримати через сервісну службу
kk Ыске косу туралы нұсқаулар!	*) Сервис қызмет көрсету орталығында алына жатады
az Quraşdırma telimətləri	*) Müşteri xidmətlərindən əldə oluna bilər
uz Орнатиш yo'riqnomasi	*) mijozlarga xizmat ko'satish markazida mavjud
ka მონტაჟის ინსტრუქცია	*) ხელმისაწვდომი კონფიდენციალური სამსახურში
bg Ръководство за монтаж	*) предоставя се от службата за обслужване на клиенти
fa راهنمایی مونتاژ	*) از مرکز خدمات پس از فروش تهیه فرمائید.
ar تعليمات التركيب	*) يمكن طلبها من مراكز خدمة العملاء.
id Intruksi Pemasangan	*) bisa didapatkan melalui Customer Service
th สามารถซื้อสิ่งที่คุณต้องการได้ดังนี้	*) สำหรับศูนย์บริการลูกค้า
ko 설치 설명서	고객서비스 센터에서 구입 가능
zh 安装说明书	*) 可向售后服务站索取。
zh-tw 安裝說明書	*) 可向售後服務站索取







9000444005 (8903)



9000444005 (8903)