1. ISO 10487 CONNECTOR A (power) + ALWAYS-ON 5V FOR PICO AND GNSS

J1 pad n = ISO A pin n. A1 REVERSE A2 HANDBRAKE A3 AMP REMOTE A4 BATT+ A5 remote (R57) A6 ILLUM A7 ACC A8 GND

Always-on 5.2V: MCU VSYS + GNSS LDO. TPS560430X runs PFM at light load (~55uA Iq).

2. VEHICLE INPUTS (opto-isolated). ACC, ILLUM, REVERSE: +12V = on. PARK: switch to ground = on.

ACC (ISO A7)

ILLUM (ISO A6)

REVERSE lamp (ISO A1)

PARK (ISO A2, handbrake switch; may stay unwired)

LED ~2.7mA at 14.4V; EL817 C-grade CTR >= 200%. 4.7k pull-downs satisfy RP2350-E9.

3. AMPLIFIER REMOTE (+12V from ACC, MCU GP20)

Goes to ISO A3 and C1-6 (A5 via R57). ~1A capable; remote inputs draw <100mA.

Only works while ACC is on, even if the MCU hangs.

4. MCU HELPERS (MCU core is section 13)

GPIO map: see section 13 and DESIGN_rev03.md.

5. GNSS MODULE: u-blox NEO-M9N, active antenna on U.FL (pigtail to SMA), UART + USB to the main board. Switched 3.3V supply stays on the main board.

6. VIM3 POWER KEY, BACKLIGHT, LIGHT SENSOR (all from the MCU)

Display buttons (to GND): GP18 screen, GP17 vol+, GP22 vol−, GP16 mute. J12.

Backlight and reverse moved off the VIM3 header; the VHAL now sets/reads them through the MCU.

8. VIM3 40-PIN HEADER + ISO 10487 C1 (line out)

J8 pad n = ISO C1 pin n: 1 RL, 2 RR, 3 FL, 4 FR, 5 line GND, 6 remote +12V.

VIM3 pin v −> IDC pad 2v−1 (v<=20) or 2(v−20) (v>20). Pin 1 sits opposite pin 21 (confirmed by Glenn).

Pins 30 (TDM−B MCLK) and 35 (TDM−B lane 3) go straight to the audio module socket J23 as spares.

I2S series resistors at the ribbon entry.

Car radio peripheral board rev 0.4 − MG F (1996), VIM3 + RP2350B, 4ch line out on the audio module, NEO−M9N. Generated by gen4.py; see DESIGN_rev04.md.

9. DISPLAY: Waveshare 7in 70H−1024600 adapter built in (HDMI in from VIM3 −> 40−pin FPC to the panel)

Panel 5V (~0.45A) comes from the board's switched 5V rail (+5V_SYS, section 10), not from VIM3 USB. Touch USB goes to the on−board hub (section 11).

Backlight EN/PWM now go straight to the panel: 0V = brightest, 3.3V = darkest (invert PWM in firmware). J6 removed.

FPC orientation as on the Waveshare adapter: seen from the top, ribbon leaving the board edge, pin 1 is on the RIGHT, pin 40 on the left.

10. 5V/5A SYSTEM SUPPLY FOR VIM3 + SCREEN + HUB (TPS55288 buck−boost, rides through cranking and overvoltage)

Input 3V−36V (runs through cranking); output 5.0V up to 5A. MCU GP23 = EN, MCU I2C1 sets OE/voltage/current limit.

VIN is permanent +12V so the VIM3 can finish its Android shutdown after ACC drops.

11. USB HUB: VIM3 header USB (pins 3/4) −> MCU, screen touch, spare port

Hub 1 runs from the always−on +5V_AON so a blank MCU enumerates (first flash over USB). One link to the VIM3: no USB cables. Port 1 MCU, 2 touch, 3 GNSS module USB, 4 second hub (external ports + RTL−SDR). Route D+/D− as 90 ohm pairs.

VIM3 header pins 3/4 are a working USB host port (confirmed by Glenn, 2026−09−29).

13. MCU: RP2350B (QFN−80) + 16MB QSPI flash + 12MHz crystal + 3.3V LDO, per the Raspberry Pi Pico 2 reference design

rev 0.4: GPIO map re−assigned for routing; see the README pin table. ADC: GPIO40 battery, 41 5V rail, 42 board temperature.

GPIO44−47 are unused (ADC−capable spares).

RP2350−E9 check (every MCU pin): opto inputs GP2/3/6/7 4.7k down; SBC sense and service jumper 4.7k down; buttons, USB faults/PG, I2C, RUN pulled up;

GNSS PPS/RX 4.7k down (R94/R95); outputs have defined off−state resistors; ADC pins run with the digital input disabled; unused and expansion pins: see DESIGN_rev03.md.

Sheet: /
File: carradio_peripheral_rev04.kicad_sch

Title: Car radio peripheral board (RP2350B + VIM3)

Size: A0	Date: 2026−10−01
Rev: 0.4	Id: 1/1

KiCad E.D.A. 10.0.6