

## **Basic Navigation**

[?]	Gives the list of available commands		
command [?]	Gives help on the command and list of arguments		
[Tab]	Completes the command/word. If the input is ambiguous, a second [Tab] gives possible options		
/	Move up to base level		
	Move up one level		
/command	Use command at the base level		

## **Connecting to the console:**

RS232/Serial
Telnet
SSH
MAC-Telnet
Winbox
Webfig
RJ45 Rollover

### **Base Levels**

certificate	ppp	
driver	queue	
file	radius	
interface	routing	
ip	snmp	
ipv6	special-login	
1cd	store	
log	system	
metarouter	terminal	
mpls	tool	
partitions	user	
port	wireless	

# **Popular Sublevel Commands**

-				
/ip	/system	ssh	ppp-server	mac-scan
accounting	backup	sup-out	pppoe-client	mac-server
address	check-disk	telnet	pppoe-server	mac-telnet
arp	check-installation	upgrade	pptp-client	netwatch
dhcp-client	clock	watchdog	pptp-server	ping-speed
dhcp-relay	console	/interface	sstp-client	profile
dhcp-server	default	bonding	sstp-server	sms
dns	health	bridge	traffic-eng	sniffer
firewall	history	eoip	virtual-ethernet	torch
hotspot	identity	ethernet	vlan	traceroute
ipsec	leds	gre	/routing	traffic-generator
neighbor	license	ipip	bfd	traffic-monitor
packing	logging	l2tp-client	bgp	wol
pool	note	l2tp-server	mme	bandwidth-server
proxy	ntp	Ite	ospf	bandwidth-test
route	package	mesh	rip	/log
service	reboot	monitor-traffic	/tool	debug
settings	reset-configuration	ovpn-client	bandwidth-server	error
smb	resource	ovpn-server	bandwidth-test	info
socks	routerboard	ppp-client	dns-update	warning
ssh	scheduler	ppp-server	e-mail	
tftp	script	pppoe-client	fetch	Popular Keyboard Shortcuts
tuaffia flam	conial tangainal		ava obio a	- Spaidi Reybourd Siloi touts

#### **Examples**

/ip ?				
<pre>ip route print</pre>				
inter ether print				

# **General Syntax**

add	move
edit/set	remove
find	export
print	import
get	enable
comment	disable

Version 1.1 – 20130707 by: Werner van Heerden

graphing

ip-scan

by: Werner van Heerden werner@neonnetworks.co.za

Control-D Log out
Control-X Toggle safe mode
Control-L Clear screen
Control-V Command auto-complete
Control-\ Split line at cursor (new line)
F1 or ? Show help

Interrupt/Break

Control-C

Not all commands/connection methods may be possible, supported or enabled.

traffic-flow

upnp

serial-terminal

shutdown

http://wiki.mikrotik.com/wiki/Manual:Console

pppoe-server

pptp-client