

Zynq UltraScale+ MPSoC: Embedded Design Tutorial

***A Hands-On Guide to Effective
Embedded System Design***

UG1209 (v2017.2) August 24, 2017

Revision History

The following table shows the revision history for this document.

Date	Version	Revision
08/24/2017	2017.2	<ul style="list-style-type: none">• Validated with Vivado® Design Suite 2017.2 and PetaLinux 2017.2.• Tested steps and design files on ZCU102 Rev1 Board with Production Silicon.• Added reference to fbdev, in addition to the existing X windowing system.
07/14/2017	2017.1	<ul style="list-style-type: none">• USB Boot added to Boot and Configuration in Chapter 5.• Secure Boot Sequence in Chapter 5 revised with more details and steps.• Validated with Vivado® Design Suite 2017.1.• Tested steps and design-files on ZCU102 Rev1 Board with Production Silicon.

Table of Contents

Revision History	2
Chapter 1: Introduction	
About This Guide	5
How Zynq UltraScale+ Devices Offer a Single Chip Solution.....	6
How the Vivado Tools Expedite the Design Process	9
What You Need to Set Up Before Starting.....	10
Chapter 2: Zynq UltraScale+ MPSoC Processing System Configuration	
Zynq UltraScale+ System Configuration	13
Example Project: Creating a New Embedded Project with Zynq UltraScale+ MPSoC.....	14
Example Project: Running the “Hello World” Application from ARM Cortex-A53	24
Example Project: Running the “Hello World” Application from ARM Cortex-R5	28
Additional Information	31
Chapter 3: Build Software for PS Subsystems	
Processing Units in Zynq UltraScale+	32
Example Project: Create a Bare-Metal Application Project in SDK.....	33
Example Project: Create Linux Images using PetaLinux	43
Chapter 4: Debugging with SDK	
Xilinx System Debugger.....	49
Debugging Software Using SDK.....	51
Debugging Using XSCT	53
Chapter 5: Boot and Configuration	
System Software	61
Linux on APU and Bare-Metal on RPU	62
Boot Sequence for SD-Boot.....	63
Boot Sequence for QSPI Boot Mode.....	73
Boot Sequence for QSPI-Boot Mode Using JTAG.....	84
Boot Sequence for USB Boot Mode	87
Secure Boot Sequence	93

Chapter 6: System Design Examples

Design Example 1: Using GPIOs, Timers, and Interrupts.....	119
Design Example 2: Example Setup for Graphics and Display Port Based Sub-System	138

Appendix A: Debugging Problems with Secure Boot

Determine if PUF Registration is Running	145
Test the Bootheader Value Used in the Boot Image.....	145

Appendix B: Additional Resources and Legal Notices

Xilinx Resources	146
Solution Centers.....	146
Documentation Navigator and Design Hubs	146
Xilinx Documentation Navigator.....	147
Design Files for This Tutorial.....	147
Xilinx Resources	147
Training Resources.....	148
Please Read: Important Legal Notices	149

Introduction

About This Guide

This document provides an introduction to using the Xilinx® Vivado® Design Suite flow for using the Zynq® UltraScale+™ MPSoC device. The examples are targeted for the Xilinx ZCU102 Rev1 evaluation board. The tool versions used are Vivado and the Xilinx Software Development Kit (SDK) 2017.2.

Note: To install SDK as part of the Vivado Design Suite, you must choose to include SDK in the installer. See [Xilinx Software Development Kit, page 8](#).

The examples in this document were created using the Xilinx tools running on Windows 7, 64-bit operating system, and PetaLinux on Linux 64-bit operating system. Other versions of the tools running on other Window installs might provide varied results. These examples focus on introducing you to the following aspects of embedded design.

Note: The sequence mentioned in the tutorial steps for booting Linux on the hardware is specific to the PetaLinux tools released for 2017.2, which must be installed on the Linux host machine for exercising the Linux portions of this document.

- [Chapter 2, Zynq UltraScale+ MPSoC Processing System Configuration](#) describes creation of a system with the Zynq UltraScale+ MPSoC Processing System (PS) and running a simple “Hello World” application on ARM® Cortex®-A53 and Cortex-R5 processors. This chapter is an introduction to the hardware and software tools using a simple design as the example.
- [Chapter 3, Build Software for PS Subsystems](#) describes steps to configure and build software for processing blocks in processing system, including application processing unit (APU), real-time processing unit (RPU), and platform management unit (PMU).
- [Chapter 4, Debugging with SDK](#) provides an introduction to debugging software using the debug features of the Xilinx Software Development Kit (SDK). This chapter uses the previous design and runs the software bare metal (without an OS) to show how to debug. This chapter also lists Debug configurations for Zynq UltraScale+ MPSoC.
- [Chapter 5, Boot and Configuration](#) shows integration of components to configure and create Boot images for a Zynq UltraScale+ system. The purpose of this chapter is to understand how to integrate and load Boot loaders.

- [Chapter 6, System Design Examples](#) highlights how you can use the software blocks you configured in [Chapter 3](#) to create a Zynq UltraScale+ system.
- [Appendix B, Additional Resources and Legal Notices](#) provides links to additional resources related to this guide.

Example Project

The best way to learn a tool is to use it. This guide provides opportunities for you to work with the tools under discussion. Specifications for sample projects are given in the example sections, along with an explanation of what is happening behind the scenes. Each chapter and examples are meant to showcase different aspects of embedded design. The example takes you through the entire flow to complete the learning and then moves on to another topic.

Additional Documentation

Additional documentation is listed in [Appendix B, Additional Resources and Legal Notices](#).

How Zynq UltraScale+ Devices Offer a Single Chip Solution

Zynq UltraScale+ MPSoC, the next generation Zynq device, is designed with the idea of using the right engine for the right task. The Zynq UltraScale+ comes with a versatile Processing System (PS) integrated with a highly flexible and high-performance Programmable Logic (PL) section, all on a single System on Chip (SoC). The Zynq UltraScale+ MPSoC PS block includes engines such as the following:

- Quad-core ARM Cortex-A53 based Application Processing Unit (APU)
- Dual-core ARM Cortex-R5 based Real Time Processing Unit (RPU)
- ARM Mali-400 MP2 based Graphics Processing Unit (GPU)
- Dedicated Platform Management Unit (PMU) and Configuration Security Unit (CSU)
- List of High Speed peripherals, including Display port and SATA

The Programmable Logic Section, in addition to the programmable logic cells, also comes integrated with few high performance peripherals, including the following:

- Integrated Block for PCI Express
- Integrated Block for Interlaken
- Integrated Block for 100G Ethernet
- System Monitor
- Video Codec Unit

The PS and the PL in Zynq UltraScale+ can be tightly or loosely coupled with a variety of high performance and high bandwidth PS-PL interfaces.

To simplify the design process for such sophisticated and All Programmable devices, Xilinx offers the Vivado Design Suite, Xilinx Software Development Kit (SDK), and PetaLinux Tools for Linux. This set of tools provides you with everything you need to simplify embedded system design for a device that merges an SoC with an FPGA. This combination of tools enables hardware and software application design, code execution and debug, and transfer of the design onto actual boards for verification and validation.

The Vivado Design Suite

Xilinx offers a broad range of development system tools, collectively called the Vivado Design Suite. Various Vivado Design Suite Editions can be used for embedded system development. In this guide we will utilize the System Edition. The Vivado Design Suite Editions are shown in the following figure.

Vivado Design Suite - HLx Editions

Vivado Design Suite - HLx Edition Features	Vivado HL Design Edition	Vivado HL System Edition	Vivado Lab Edition	Vivado HL WebPACK Edition (Device Limited)	Free 30-day Evaluation
Accelerating Implementation					
Synthesis and Place and Route	●	●		●	●
Partial Reconfiguration*	●	●		●	●
Accelerating Verification					
Vivado Simulator	●	●		●	●
Vivado Device Programmer	●	●	●	●	●
Vivado Logic Analyzer	●	●	●	●	●
Vivado Serial I/O Analyzer	●	●	●	●	●
Debug IP (ILA/VIO/IBERT)	●	●		●	●
Accelerating High Level Design					
Vivado High-Level Synthesis	●	●		●	●
Vivado IP Integrator	●	●		●	●
System Generator for DSP		●			●

* Can be purchased as an option.

Figure 1-1: Vivado Design Suite Editions

Other Vivado Components

Other Vivado components include:

- Embedded/Soft IP for the Xilinx embedded processors
- Documentation
- Sample projects

Xilinx Software Development Kit

The Software Development Kit (SDK) is an integrated development environment, complementary to Vivado, that is used for C/C++ embedded software application creation and verification. SDK is built on the Eclipse open-source framework and might appear familiar to you or members of your design team.

When you install the Vivado Design Suite, SDK is available as an optional software tool that you must choose to include in your installation. For details, refer to [Installation Requirements, page 10](#).

For more information about the Eclipse development environment, refer to <http://www.eclipse.org>.

Other SDK components include:

- Drivers and libraries for embedded software development
- Linaro GCC compiler for C/C++ software development targeting the ARM Cortex-A53 and ARM Cortex-R5 MPCore processors in the Zynq UltraScale+ Processing System

PetaLinux Tools

The PetaLinux tools set is an Embedded Linux System Development Kit. It offers a multi-faceted Linux tool flow, which enables complete configuration, build, and deploy environment for Linux OS for the Xilinx Zynq devices, including Zynq UltraScale+.

For more information, refer to the Xilinx PetaLinux web page [\[Ref 15\]](#).

The PetaLinux Tools design hub provides information and links to documentation specific to PetaLinux Tools. For more information, refer to [Related Design Hubs, page 147](#).

How the Vivado Tools Expedite the Design Process

You can use the Vivado Design Suite tools to add design sources to your hardware. These include the IP integrator, which simplifies the process of adding IP to your existing project and creating connections for ports (such as clock and reset).

You can accomplish all your hardware system development using the Vivado tools along with IP integrator. This includes specification of the Zynq UltraScale+ Processing System, peripherals, and the interconnection of these components, along with their respective detailed configuration.

SDK is used for software development and is available either as part of the Vivado Design Suite, or it can be installed and used without any other Xilinx tools installed on the machine on which it is loaded. SDK can also be used to debug software applications.

The Zynq UltraScale+ Processing System (PS) can be booted and run without programming the FPGA (programmable logic or PL). However, in order to use any soft IP in the fabric, or to bond out PS peripherals using EMIO, programming of the PL is required. You can program the PL using SDK or using the Vivado Hardware Manager.

For more information on the embedded design process, refer to the *Vivado Design Suite Tutorial: Embedded Processor Hardware Design* (UG940) [Ref 2].

For more information about the Zynq UltraScale+ Processing System, refer to the *Zynq UltraScale+ Processing System v1.0 Product Guide* (PG201) [Ref 9].

What You Need to Set Up Before Starting

Before discussing the tools in depth, you should make sure they are installed properly and your environments match those required for the "Example Project" sections of this guide.

Hardware Requirements for this Guide

This tutorial targets the Zynq UltraScale+ ZCU102 evaluation board. The examples in this tutorial were tested using the ZCU102 Rev 1 board. To use this guide, you need the following hardware items, which are included with the evaluation board:

- ZCU102 Rev1 evaluation board
- AC power adapter (12 VDC)
- USB Type-A to USB Micro cable (for UART communications)
- USB Micro cable for programming and debugging via USB-Micro JTAG connection
- SD-MMC flash card for Linux booting
- Ethernet cable to connect target board with host machine
- Monitor with Display Port (DP) capability and at least 1080P resolution.
- DP cable to connect the Display output from ZCU102 Board to a DP monitor.

Installation Requirements

Vivado Design Suite and SDK

Make sure that you have installed the 2017.2 Vivado HL System Edition tools. Visit <http://www.xilinx.com/support/download.html> to confirm that you have the latest tools version.

Ensure that you have both the Vivado Design Suite and SDK Tools installed. When you install the Vivado Design Suite, SDK is available as an optional software tool that you must elect to include in your installation by selecting the **Software Development Kit** check box, as shown in the following figure. To install SDK by itself, you can deselect the other software products and run the installer with only **Software Development Kit** selected.




Figure 1-2: Vivado Installer - Select Software Development Kit

For more information on installing the Vivado Design Suite and SDK, refer to the *Vivado Design Suite User Guide: Release Notes, Installation, and Licensing* (UG973) [Ref 3].

IMPORTANT: *Installation does not create an SDK desktop shortcut by default. You can launch the SDK binary from C:\Xilinx\SDK\2017.2\bin\xsdk.bat.*

PetaLinux Tools

Install the PetaLinux Tools to run through the Linux portion of this tutorial. PetaLinux tools run under the Linux host system running one of the following:

- RHEL 7.2/7.3 (64-bit)
- CentOS 7.2/7.3 (64-bit)
- Ubuntu 16.04.1 (64-bit)
- RHEL 6.7/6.8 (64-bit)

Note: Limited support with workaround for RHEL and Cent OS 6.X. Refer *PetaLinux Tools Documentation: Reference Guide* (UG1144) [Ref 7] for more details.

This can use either a dedicated Linux host system or a virtual machine running one of these Linux operating systems on your Windows development platform.

When you install PetaLinux Tools on your system of choice, you must do the following:

- Download PetaLinux 2017.2 SDK software from the [Xilinx Website](#).

- Download the ZCU102 Petalinux BSP from the [2017.2 downloads](#) page.
Note: ZCU102-ZU9-ES2 Rev 1.0 BSP, for ES2 Silicon can be found [here](#).
- Add common system packages and libraries to the workstation or virtual machine. Refer Installation Requirements from the *Petalinux Tools Documentation: Reference Guide* (UG1144) [\[Ref 7\]](#).

Prerequisites

- 4GB RAM (recommended minimum for Xilinx tools)
- Pentium 4 2GHz CPU clock or equivalent (minimum of 4 cores)
- 100 GB free HDD space

Extract the Petalinux Package

By default, the installer installs the package as a subdirectory within the current directory. Alternatively, you can specify an installation path. Run the downloaded Petalinux installer.

Note: Ensure that the Petalinux installation path is kept short. The Petalinux build will fail if the path exceeds 255 characters.

```
bash> ./petalinux-v2017.2-final-installer.run
```

Petalinux is installed in the petalinux-v2017.2-final directory, directly underneath the working directory of this command. If the installer is placed in the home directory /home/user, Petalinux is installed in /home/user/petalinux-v2017.2-final.

Refer to [Chapter 3, Build Software for PS Subsystems](#) for additional information about the Petalinux environment setup, project creation, and project usage examples. A detailed guide on Petalinux Installation and usage can be found in the *Petalinux Tools Documentation: Reference Guide* (UG1144) [\[Ref 7\]](#).

Software Licensing

Xilinx software uses FLEXnet licensing. When the software is first run, it performs a license verification process. If the license verification does not find a valid license, the license wizard guides you through the process of obtaining a license and ensuring that the license can be used with the tools installed. If you do not need the full version of the software, you can use an evaluation license. For installation instructions and information, see the *Vivado Design Suite User Guide: Release Notes, Installation, and Licensing* (UG973) [\[Ref 3\]](#).

Tutorial Design Files

See [Design Files for This Tutorial, page 147](#) for information about downloading the design files for this tutorial.

Zynq UltraScale+ MPSoC Processing System Configuration

Now that you have been introduced to the Xilinx® Vivado® Design Suite, you will begin looking at how to use it to develop an embedded system using the Zynq® UltraScale+™ MPSoC Processing System (PS).

The Zynq UltraScale+ device consists of Quad-Core ARM® Cortex®-A53 based APU, Dual-Core ARM Cortex-R5 RPU, Mali 400 MP2 GPU, and many hard Intellectual Property components (IPs), and Programmable Logic (PL). This offering can be used in two ways:

- The Zynq UltraScale+ PS can be used in a standalone mode, without attaching any additional fabric IP.
- IP cores can be instantiated in fabric and attached to the Zynq UltraScale+ PS as a PS+PL combination.

Zynq UltraScale+ System Configuration

Creation of a Zynq UltraScale+ system design involves configuring the PS to select the appropriate boot devices and peripherals. To start with, as long as the PS peripherals and available MIO connections meet the design requirements, no bitstream is required. This chapter guides you through creating a simple PS-based design that does not require a bitstream.

Example Project: Creating a New Embedded Project with Zynq UltraScale+ MPSoC

For this example, you will launch the Vivado Design Suite and create a project with an embedded processor system as the top level.

Starting Your Design

1. Start the Vivado Design Suite.
2. In the Vivado Quick Start page, click **Create Project** to open the New Project wizard.
3. Use the information in the table below to make selections in each of the wizard screens.

Table 2-1: New Project Wizard Options

Wizard Screen	System Property	Setting or Command to Use
Project Name	Project name	<code>edt_zcu102</code>
	Project Location	C:/edt
	Create Project Subdirectory	Leave this checked
Project Type	Specify the type of sources for your design. You can start with RTL or a synthesized EDIF.	RTL Project
	Do not specify sources at this time check box	Leave this unchecked.
Add Sources	Do not make any changes to this screen.	
Add Constraints	Do not make any changes to this screen.	
Default Part	Select	Boards
	Display Name	Zynq UltraScale+ ZCU102 Evaluation Board
New Project Summary	Project Summary	Review the project summary

4. Click **Finish**. The New Project wizard closes and the project you just created opens in the Vivado design tool.

Creating a Block Design Project

You will now use the IP Integrator to create a Block Design project.

1. In the Flow Navigator, under **IP Integrator**, click **Create Block Design**.




Figure 2-1: Create Block Design Button

The Create Block Design wizard opens.

2. Use the following information to make selections in the Create Block Design wizard.

Table 2-2: Setting in Create Block Design Wizard

Wizard Screen	System Property	Setting or Command to Use
Create Block Design	Design Name	edt_zcu102
	Directory	<Local to Project>
	Specify Source Set	Design Sources

3. Click **OK**.

The Diagram window view opens with a message that states that this design is empty. To get started, you will next add some IP from the catalog.

4. Click the **Add IP** button | + .
5. In the search box, type `zynq` to find the Zynq device IP options.
6. Double-click the **ZYNQ UltraScale+ MPSoC** IP to add it to the Block Design.

The Zynq MPSoC processing system IP block appears in the Diagram view, as shown in the following figure.




Figure 2-2: Zynq UltraScale+ Processing System IP Block

Managing the Zynq UltraScale+ Processing System in Vivado

Now that you have added the processor system for the Zynq MPSoC to the design, you can begin managing the available options.

1. Double-click the **ZYNQ UltraScale+ Processing System** block in the Block Diagram window.

The Re-customize IP dialog box opens, as shown in the following figure. Notice that by default, the processor system does not have any peripherals connected




Figure 2-3: Re-customize IP Dialog Box

2. Click **Cancel** to exit the dialog box without making changes to the design.



TIP: In the Block Diagram window, notice the message stating that designer assistance is available, as shown in the following figure. When designer assistance is available, you can click the link to have Vivado perform that step in your design.




Figure 2-4: Designer Assistance Link

3. You will now use a preset template created for the ZCU102 board. Click the **Run Block Automation** Link.

The Run Block Automation dialog box opens.

4. Click **OK** to accept the default processor system options and make default pin connections.

This configuration wizard enables many peripherals in the Processing System with some multiplexed I/O (MIO) pins assigned to them according to the board layout of the ZCU102 board. For example, UART0 and UART1 are enabled. The UART signals are connected to a USB-UART connector through UART to the USB converter chip on the ZCU102 board.

5. To verify, double-click on the **Zynq UltraScale+ Processing System** block in the block diagram window.

Note the check marks that appear next to each peripheral name in the Zynq UltraScale+ device block diagram, signifying the I/O Peripherals that are active.




Figure 2-5: I/O Unit with Active Peripherals Identified

6. In the block diagram, click one of the green I/O Peripherals, as shown in the previous figure. The IO Configuration dialog box opens for the selected peripheral.




Figure 2-6: I/O Configuration Page of the Re-customize IP Dialog Box

This page enables you to configure low speed and high speed peripherals. For this example, you will continue with the basic connection enabled using Board preset for ZCU102.

7. In the Page Navigator, select **PS-PL Configuration**.
8. In PS-PL Configuration, expand **PS-PL Interfaces** and expand the **Master Interface**.

For this example, because there is no design in PL, you can disable the PS-PL interface. In this case, AXI HPM0 FPD and AXI HPM1 FPD Master Interfaces can be disabled.

9. From the **AXI HPM0 FPD** drop-down list, select **0**. Similarly set **AXI HPM1 FPD** to **0**.

The PS-PL configuration looks like following figure.




Figure 2-7: PS-PL Configuration

10. Click **OK** to close the Re-customize IP wizard.

Validating the Design and Connecting Ports

Use the following steps to validate the design:

1. Right-click in the white space of the Block Diagram view and select **Validate Design**. Alternatively, you can press the **F6** key.
2. A message dialog box opens and states "Validation successful. There are no errors or critical warnings in this design."
3. Click **OK** to close the message.
4. In the Block Design view, click the **Sources** tab.
5. Click **Hierarchy**.
6. Under **Design Sources**, right-click **edt_zcu102** and select **Create HDL Wrapper**.

The Create HDL Wrapper dialog box opens. You will use this dialog box to create a HDL wrapper file for the processor subsystem.



TIP: The HDL wrapper is a top-level entity required by the design tools.

7. Select **Let Vivado manage wrapper and auto-update** and click **OK**.
8. In the Block Diagram, Sources window, under **Design Sources**, expand **edt_zcu102_wrapper**.

9. Right-click the top-level block diagram, titled **edt_zcu102_i : edt_zcu102 (edt_zcu102.bd)** and select **Generate Output Products**.

The Generate Output Products dialog box opens, as shown in the following figure.




Figure 2-8: Generate Output Products Dialog Box

Note: If you are running the Vivado Design Suite on a Linux host machine, you might see additional options under Run Settings. In this case, continue with the default settings.

10. Click **Generate**.

This step builds all required output products for the selected source. For example, constraints do not need to be manually created for the IP processor system. The Vivado tools automatically generate the XDC file for the processor sub-system when **Generate Output Products** is selected.

11. Click **OK**, if you see the message: "Out-of-context module run was launched for generating output products".
12. When the Generate Output Products process completes, click **OK**.

13. In the Block Diagram Sources window, click the **IP Sources** tab. Here you can see the output products that you just generated, as shown in the following figure.




Figure 2-9: Outputs Generated Under IP Sources

Exporting Hardware to SDK

In this example, you will launch SDK from Vivado.

1. From the Vivado toolbar, select **File > Export > Export Hardware**.

The Export Hardware dialog box opens. Make sure that the **Export to** field is set to the default option of **<Local to Project>**.




Figure 2-10: Export Hardware to SDK

2. Click **OK**.



TIP: The hardware is exported in a ZIP file (<project wrapper>.hdf). When SDK launches, the file unzips automatically, and you can find all the files in the SDK project hardware platform folder.

3. Select **File > Launch SDK**.

The Launch SDK dialog box opens.



TIP: You can also start SDK in standalone mode and use the exported hardware. To do this, start SDK, and while creating a new project, point to the new target hardware that was exported.

4. Accept the default selections for **Exported location** and **Workspace**.




Figure 2-11: Launch SDK Dialog Box

5. Click **OK**.

SDK opens. Notice that when SDK launches, the hardware description file is loaded automatically.

The system.hdf tab shows the address map for the entire Processing System, as shown in the following figure.




Figure 2-12: Address Map in SDK system.hdf Tab

What Just Happened?

Vivado exported the hardware specifications to the selected workspace where software development will take place. If <Local to Project> was selected, then Vivado created a new workspace in the Vivado project folder. The name of the workspace is <project_name>.sdk. In this example, the workspace created is C:\edt\edt_zcu102\edt_zcu102.sdk.

The Vivado design tool exported the Hardware Platform Specification for your design (system.hdf in this example) to SDK. In addition to system.hdf, the following additional files are exported to SDK:

- psu_init.c
- psu_init.h
- psu_init.tcl
- psu_init_gpl.c
- psu_init_gpl.h
- psu_init.html

The system.hdf file opens by default when SDK launches. The address map of your system read from this file is shown by default in the SDK window.

The `psu_init.c`, `psu_init.h`, `psu_init_gpl.c`, and `psu_init_gpl.h` files contain the initialization code for the Zynq UltraScale_ MPSoC Processing System and initialization settings for DDR, clocks, phase-locked loops (PLLs), and IOs. SDK uses these settings when initializing the processing system so that applications can be run on top of the processing system. Some settings in the processing system are fixed for the ZCU102 evaluation board.

What's Next?

Now you can start developing the software for your project using SDK. The next sections help you create a software application for your hardware platform.

Example Project: Running the “Hello World” Application from ARM Cortex-A53

In this example, you will learn how to manage the board settings, make cable connections, connect to the board through your PC, and run a simple hello world software application from ARM Cortex-A53 in JTAG mode using System Debugger in Xilinx SDK.

1. Connect the power cable to the board.
2. Connect a USB Micro cable between the Windows Host machine and **J2 USB JTAG** connector on the Target board.
3. Connect a USB micro cable to connector J83 on the target board with the Windows Host machine. This is used for USB to serial transfer.



IMPORTANT: Ensure that SW6 Switch is set to JTAG boot mode as shown in the following figure.



Figure 2-13: SW6 Switch Settings for JTAG Boot Mode

4. Power on the ZCU102 board using the switch indicated in the figure above.




Figure 2-14: ZCU102 Board Power Switch

Note: If SDK is already running, jump to step 6.

5. Open SDK and set the workspace path to your project file, which in this example is C:\edt\edt_zcu102\edt_zcu102.sdk.

Alternately, you can open SDK with a default workspace and later switch it to the correct workspace by selecting **File > Switch Workspace** and then selecting the workspace.

6. Open a serial communication utility for the COM port assigned on your system. SDK provides a serial terminal utility, which will be used throughout the tutorial; select **Window > Show View > Terminal** to open it.
7. Click the **Connect** button  to set the serial configuration and connect it.




Figure 2-15: Terminal Window Header Bar

8. Click the **Settings** button  to open the Terminal Settings dialog box.

9. Verify the port details in the device manager.

UART-0 terminal corresponds to Com-Port with Interface-0. For this example, UART-0 terminal is set by default, so for the Com-port, select the port with interface-0.

The following figure shows the standard configuration for the Zynq UltraScale+ MPSoC Processing System.




Figure 2-16: Terminal Settings Dialog Box

10. Select **File > New > Application Project**.

The new Project wizard opens.

11. Use the information in the table below to make your selections in the wizard screens.

Table 2-3: New Application Project Settings for Standalone APU Application

Wizard Screen	System Properties	Setting or Command to Use
Application Project	Project Name	test_a53
	Use Default Location	Select this option
	Hardware Platform	edt_zcu102_wrapper_hw_platform_0
	Processor	psu_cortexa53_0
	OS Platform	standalone
	Language	C
	Compiler	64-bit
	Hypervisor Guest	No
	Board Support Package	Select Create New and provide the name of test_a53_bsp.
Templates	Available Templates	Hello World

SDK creates the test_a53 application project and test_a53_bsp board support package (BSP) project under the Project Explorer. It automatically compiles both and creates the ELF file.

12. Right-click **test_a53** and select **Run as > Run Configurations**.

13. Right-click **Xilinx C/C++ application (System Debugger)** and click **New**.

SDK creates the new run configuration, named test_a53 Debug.

The configurations associated with the application are pre-populated in the Main tab of the launch configurations.

14. Click the **Target Setup** tab and review the settings.

Notice that there is a configuration path to the initialization Tcl file. The path of psu_init.tcl is mentioned here. This file was exported when you exported your design to SDK; it contains the initialization information for the processing system.

15. Click **Run**.

"Hello World" appears on the serial communication utility in Terminal 1, as shown in the following figure.




Figure 2-17: Output on Serial Terminal

Note: There was no bitstream download required for the above software application to be executed on the Zynq UltraScale+ evaluation board. The ARM Cortex A53 quad core is already

present in the processing system. Basic initialization of this system to run a simple application is done by the Device initialization Tcl script.

16. Power cycle the board and retain same connections and board settings for the next section.

What Just Happened?

The application software sent the "Hello World" string to the UART0 peripheral of the PS section.

From UART0, the "Hello world" string goes byte-by-byte to the serial terminal application running on the host machine, which displays it as a string.

Example Project: Running the “Hello World” Application from ARM Cortex-R5

In this example, you will learn how to manage the board settings, make cable connections, connect to the board through your PC, and run a simple hello world software application from ARM Cortex-R5 in JTAG mode using System Debugger in Xilinx SDK.

Note: If you already set up the board, skip to [step 5](#).

1. Connect the power cable to the board.
2. Connect a USB Micro cable between the Windows Host machine and the **J2 USB JTAG** connector on the Target board.
3. Connect a USB cable to connector **J83** on the target board with the Windows Host machine. This is used for USB to serial transfer.
4. Power on the ZCU102 board using the switch indicated in [\[Ref 2-14\]](#).



IMPORTANT: Ensure that the SW6 switch is set to JTAG boot mode as shown in [Figure 2-13](#).

Note: If SDK is already open, jump to step 6.

5. Open SDK and set the workspace path to your project file, which in this example is C:\edt\edt_zcu102\edt_zcu102.sdk.

Alternately, you can open SDK with a default workspace and later switch it to the correct workspace by selecting **File > Switch Workspace** and then selecting the workspace.

6. Open a serial communication utility for the COM port assigned on your system. SDK provides a serial terminal utility, which will be used throughout the tutorial; select **Window > Show View > Terminal** to open it.




Figure 2-18: Terminal Window Header Bar

7. Click the **Connect** button  to set the serial configuration and connect it.
8. Click the **Settings** button  to open the Terminal Settings dialog box.

The Com-port details can be found in the device manager on host machine. UART-0 terminal corresponds to Com-Port with Interface-0. For this example, UART-0 terminal is set by default, so for the Com-port, select the port with interface-0.

[Figure 2-19](#) shows the standard configuration for the Zynq UltraScale+ MPSoC Processing System.




Figure 2-19: Terminal Settings Dialog Box

9. In SDK, switch back from Debug perspective to C/C++ perspective. For this you have to click **Windows ->Open Perspective -> C/C++**. Ignore this step, if SDK is in C/C++ perspective already.
10. Select **File > New > Application Project**.

The New Project wizard opens.

11. Use the information in the following table to make your selections in the wizard screens.

Table 2-4: New Application Project Settings for Standalone RPU Application

Wizard Screen	System Properties	Setting or Command to Use
Application Project	Project Name	hello_world_r5
	Use Default Location	Select this option
	Hardware Platform	edt_zcu102_wrapper_hw_platform_0
	Processor	psu_cortexr5_0
	OS Platform	standalone
	Language	C
	Board Support Package	Select Create New and provide the name of <code>hello_world_r5_bsp</code> .
Templates	Available Templates	Hello World

SDK creates the `hello_world_r5` application project and `hello_world_r5_bsp` board support package (BSP) project under the Project Explorer. It automatically compiles both and creates the ELF file.

12. Right-click **hello_world_r5** and select **Run as > Run Configurations**.

13. Right-click **Xilinx C/C++ application (System Debugger)** and click **New**.

SDK creates the new run configuration, named `hello_world_r5 Debug`.

The configurations associated with the application are pre-populated in the Main tab of the launch configurations.

14. Click the **Target Setup** tab and review the settings.

Notice that there is a configuration path to the initialization Tcl file. The path of `psu_init.tcl` is mentioned here. This file was exported when you exported your design to SDK; it contains the initialization information for the processing system.

15. Click **Run**.

"Hello World" appears on the serial communication utility in Terminal 1, as shown in the following figure.




Figure 2-20: Output on Serial Terminal

Note: There was no bitstream download required for the above software application to be executed on the Zynq UltraScale+ evaluation board. The ARM Cortex R5 dual core is already present on the board. Basic initialization of this system to run a simple application is done by the Device initialization Tcl script.

What Just Happened?

The application software sent the "Hello World" string to the UART0 peripheral of the PS section.

From UART0, the "Hello world" string goes byte-by-byte to the serial terminal application running on the host machine, which displays it as a string.

Additional Information

Board Support Package

The board support package (BSP) is the support code for a given hardware platform or board that helps in basic initialization at power up and helps software applications to be run on top of it. It can be specific to some operating systems with bootloader and device drivers.



TIP: If you would like to regenerate the BSP, right click the BSP project under the Project Explorer and select **Re-generate BSP Sources**.

If you would like to change the target BSP after project creation:

1. Create a **New Board Support Package** for your target.
 2. In the Project Explorer, right click your application project and select **Change Referenced BSP**, and point the new BSP you want to set.
-

Standalone OS

Standalone is a simple, low-level software layer. It provides access to basic processor features such as caches, interrupts, and exceptions, as well as the basic processor features of a hosted environment. These basic features include standard input/output, profiling, abort, and exit. It is a single threaded semi-hosted environment.



IMPORTANT: The application you ran in this chapter was created on top of the Standalone OS. The BSP that your software application targets is selected during the New Application Project creation process. If you would like to change the target BSP after project creation, you can manage the target BSP by right-clicking the software application and selecting **Change Referenced BSP**.

Build Software for PS Subsystems

This chapter lists the steps to configure and build software for PS subsystems. In this chapter, you will use the Zynq® UltraScale™+ hardware platform (hardware definition file) configured in the Vivado® Design Suite.

In [Chapter 2](#), you created and exported the hardware platform from Vivado. This hardware platform contains the hardware handoff file, the processing system initialization files (`psu_init`), and the PL bitstream. In this chapter, you will use the hardware platform in Xilinx® SDK and PetaLinux to configure software for the processing system.

This chapter serves two important purposes. One, it helps you build and configure the software components that can be used in future chapters. Second, it describes the build steps for a specific PS subsystem.

Processing Units in Zynq UltraScale+

The main processing units in the processing system in Zynq UltraScale+™ are listed below.

- Application Processing Unit: Quad-core ARM® Cortex® A53 MPCore Processors
- Real Time Processing Unit: Dual-core ARM Cortex R5 MPCore Processors
- Graphics Processing Unit: ARM Mali 400 MP2 GPU
- Platform Management Unit (PMU)

This section demonstrates configuring these units using system software. This can be achieved either at the boot level using First Stage Boot Loader (FSBL) or via system firmware, which is applicable to the platform management unit (PMU).

You will use the Zynq UltraScale+ hardware platform in SDK to perform the following tasks:

1. Create a First Stage Boot Loader (FSBL) for the ARM Cortex-A53 64-bit quad-core processor unit (APU) and the Cortex-R5 dual-core real-time processor unit (RPU).
2. Create bare-metal applications for APU and RPU.
3. Create platform management unit (PMU) firmware for the platform management unit using Xilinx SDK.

In addition to the bare-metal applications, this chapter also describes building U-boot and Linux Images for the APU. The Linux images and U-boot can be configured and built using the PetaLinux build system.

Example Project: Create a Bare-Metal Application Project in SDK

For this example, you will launch Xilinx SDK and create a bare-metal application using the hardware platform for Zynq UltraScale+ created using the Vivado Design Suite. [Figure 3-1, page 34](#) shows the SDK New Application Project dialog box and possible options for creating bare-metal (Standalone) applications for processing subsystems in Zynq UltraScale+ devices.

Create First Stage Boot Loader for ARM Cortex A53-Based APU

Start with creating the First Stage Boot Loader (FSBL). Zynq UltraScale+ supports the FSBL to run on either the APU or the RPU. This way, you can load the FSBL on the required ARM processor, and the FSBL will then subsequently load the required application or secondary boot loader on the required core.

In this example, you will create an FSBL image targeted for ARM Cortex A53 core 0.

1. Start SDK if it is not already open.
2. Set the Workspace path based on the project you created in Chapter 2. For example, C:\edt\edt_zcu102\edt_zcu102.sdk.
3. Select **File > New > Application Project**.

The New Project dialog box opens.




Figure 3-1: Application Project Page of New Project Wizard

4. Use the information in the following table to make your selections in the New Project dialog box:

Table 3-1: Settings to Create New Application Project - FSBL_A53

Wizard Screen	System Properties	Setting or Command
Application Project	Project Name	fsbl_a53
	Use Default Location	Select this option
	OS Platform	Standalone
	Hardware Platform	edt_zcu102_wrapper_hw_platform_0
	Processor	psu_cortexa53_0
	Language	C
	Compiler	64-bit
	Hypervisor Guest	No
	Board Support Package	Select Create New and provide the name of a53_bsp.

Table 3-1: Settings to Create New Application Project - FSBL_A53 (Cont'd)

Wizard Screen	System Properties	Setting or Command
Click Next		
Templates	Available Templates	Zynq MP FSBL

5. In the Application Project window, set the following project details:




Figure 3-2: Templates Window of the New Project Wizard

6. Click **Finish**.

SDK creates the board Support package and an FSBL application.

By default, the FSBL is configured to show basic print messages. Next, you will modify the FSBL build settings to enable debug messages.

For a list of the possible debug options for FSBL, refer to the `fsbl_a53 > src > xfsbl_debug.h` file.

For this example, enable FSBL_DEBUG_INFO by doing the following:

1. In the **Project Explorer** folder, right-click the **fsbl_a53** application.
2. Click **C/C++ Build Settings**.
3. Select **Settings > Tool Settings > Symbols**.
4. Click the **Add** button .
5. Enter **FSBL_DEBUG_INFO**.




Figure 3-3: Enter Value Dialog Box

The Symbols settings are as shown in the following figure.




Figure 3-4: Symbols Settings for fsbl_a53 Application

6. Click **OK** to accept the changes and close the Settings dialog box.
7. Right-click the **fsbl_a53** application and select **Clean Project**.

Note: If the **Project > Build Automatically** setting is selected, SDK automatically builds the application for you.

8. The FSBL executable is now saved as `fsbl_a53 > debug > fsbl_a53.elf`.

In this example, the application name `fsbl_a53` is to identify that the FSBL is targeted for APU (the ARM Cortex A53 core).

Create First Stage Boot Loader for ARM Cortex R5 Based RPU

You can also create an FSBL for ARM Cortex R5 Core by doing the following.

1. Click **File > New > Application Project** to open the New Project dialog box.




Figure 3-5: Application Project Page of New Project Wizard

2. Use the information in the following table to make your selections in the Application Project wizard.

Table 3-2: Settings to Create New Application Project - FSBL_R5

Wizard Screen	System Properties	Setting or Command
Application Project	Project Name	fsbl_r5
	Use Default Location	Select this option
	OS Platform	Standalone
	Hardware Platform	edt_zcu102_wrapper_hw_platform_0
	Processor	psu_cortexr5_0
	Language	C
	Board Support Package	Select Create New and provide the name of r5_bsp.
Click Next		
Templates	Available Templates	Zynq MP FSBL

3. Click **Finish**.

This creates the board Support package and an FSBL application targeted for RPU ARM Cortex R5 Core 0 in Zynq UltraScale+.

Create Bare-Metal Application for ARM Cortex A53 based APU

Now that the FSBL is created, you will now create a simple bare-metal application targeted for an ARM A53 Core 0.

For this example, you will use the test_a53 application that you created in [Example Project: Running the "Hello World" Application from ARM Cortex-A53 in Chapter 2](#)

In test_a53, you selected a simple Hello World application. This application can be loaded on APU by FSBL running on either APU or RPU.

SDK also provides few other bare-metal applications templates to make it easy to start running applications on Zynq UltraScale+ devices. Alternatively, you can also select the Empty Application template and copy or create your custom application source code in the application folder structure.

Modify the Application Source Code

1. Click `test_a53 > src > helloworld.c`.

This opens the `helloworld.c` source file for the `test_a53` application

2. Modify the arguments in the `print` command, as shown below.


```

Print("Hello World from APU\n\r");
int main()
{
    init_platform();
    print("Hello World from APU\n\r");
    cleanup_platform();
    return 0;
}

```

Figure 3-6: Application Source Code Snippet: Print Command

3. Type **Ctrl + S** to save the changes.
4. Right-click the `test_a53` project and select **Build Project**.
5. Verify that the application is compiled and linked successfully and the `test_a53.elf` file is generated in the `test_a53 > Debug` folder.



```

CDT Build Console [test_a53]
.
.
.
'Building target: test_a53.elf'
'Invoking: ARM A53 gcc linker'
aarch64-none-elf-gcc -Wl,-Tl,.../src/lscript.ld -L.../a53_bsp/psu_cortexa53_0/lib -o "test_a53.elf"
'Finished building target: test_a53.elf'
.

'Invoking: ARM A53 Print Size'
aarch64-none-elf-size test_a53.elf | tee "test_a53.elf.size"
    text      data      bss      dec      hex filename
    30928     2352     20656    53936    d2b0 test_a53.elf
'Finished building: test_a53.elf.size'
.

14:28:35 Build Finished (took 1s.455ms)

```

Figure 3-7: CDT Build Console

Create Bare-Metal Application for ARM Cortex R5 based RPU

In this example, you will create a bare-metal application project for ARM Cortex-R5 based RPU. For this project, you will need to import the application source files available in the Design Files ZIP file released with this tutorial. For information about locating these design files, refer to [Design Files for This Tutorial in Appendix B](#).

Creating the Application Project

1. In SDK, select **File > New > Application Project** to open the New Project wizard.
2. Use the information in the following table to make your selections in the wizard.

Table 3-3: Settings to Create New RPU Application Project

Wizard Screen	System Properties	Setting or Command to Use
Application Project	Project Name	testapp_r5
	Use Default Location	Select this option
	Hardware Platform	edt_zcu102_wrapper_hw_platform
	Processor	psu_cortexr5_0
	OS Platform	standalone
	Language	C
	Board Support Package	Select Use Existing and select r5_bsp
Templates	Available Templates	Empty Application

Note: The `r5_bsp` board support package was created when you followed the steps in [Create First Stage Boot Loader for ARM Cortex R5 Based RPU](#).

3. Click **Finish**.

The New Project wizard closes and SDK creates the **testapp_r5** application project, which can be found in the Project Explorer.

4. In the Project Explorer tab, expand the **testapp_r5** project.
5. Right-click the **src** directory, and select **Import** to open the Import dialog box.
6. Expand **General** in the Import dialog box and select **File System**.
7. Click **Next**.
8. Select **Browse** and navigate to the design files folder, which you saved earlier (see [Design Files for This Tutorial in Appendix B](#)).
9. Click **OK**.
10. Select the `testapp.c` file.
11. Click **Finish**. SDK automatically builds the application and displays the status in the console window.
12. Open `testapp.c` to review the source code for this application. The application configures the UART interrupt and sets the Processor to WFI mode. This application is reused and explained during run time in [Chapter 5, Boot and Configuration](#).

Modifying the Linker Script

1. In the Project Explorer, expand the `testapp_r5` project.
2. In the `src` directory, double-click `lscript.ld` to open the linker script for this project.
3. In the linker script, in Available Memory Regions, modify the following attributes for `psu_r5_ddr_0_MEM_0`:

- **Base Address:** 0x70000000
- **Size:** 0x10000000

The linker script modification is shown in following figure.

Linker Script: lscript.ld

A linker script is used to control where different sections of an executable are placed in memory. In this page, you can define new memory regions, and change the assignment of sections to memory regions.

Available Memory Regions

Name	Base Address	Size
psu_ocm_ram_0_MEM_0	0xFFFFC0000	0x40000
psu_qspi_linear_0_MEM_0	0xC0000000	0x20000000
psu_r5_0_atcm_MEM_0	0x0	0x10000
psu_r5_0_btcm_MEM_0	0x20000	0x10000
psu_r5_ddr_0_MEM_0	0x70000000	0x10000000
psu_r5_tcm_ram_0_MEM_0	0x0	0x40000

Stack and Heap Sizes

Stack Size	0x2000
Heap Size	0x2000

Figure 3-8: Linker Script Modification

This modification in the linker script ensures that the RPU bare-metal application resides above 0x70000000 (about 1.79 GB) base address in the DDR, and occupies no more than 256 MB of size.

4. Type **Ctrl + S** to save the changes.
5. Right-click the testapp_r5 project and select **Build Project**.
6. Verify that the application is compiled and linked successfully and that the testapp_r5.elf file was generated in the testapp_r5 > Debug folder.

Modifying the Board Support Package

The ZCU102 Evaluation kit has a USB-TO-QUAD-UART Bridge IC from Silicon Labs (CP2108). This enables you to select a different UART port for applications running on A53 and R5 Cores. For this example, let A53 use the UART 0 by default, and send and receive RPU serial data over UART 1. This requires a small modification in the r5_bsp file.

1. Right-click r5_bsp and select **Board Support Package Settings**.
2. Click **Standalone**.

3. Modify the `stdin` and `stdout` values to `psu_uart_1`, as shown in the figure below.




Figure 3-9: Board Support Package Settings for RPU BSP

4. Click **OK**.
5. Right-click the `testapp_r5` project and select **Build Project**.
6. Verify that the application is compiled and linked successfully and that the `testapp_r5.elf` was generated in the `testapp_r5 > Debug` folder.

Create PMU Firmware for Platform Management Unit

Zynq UltraScale+ devices support a Platform Management Unit, and SDK supports firmware generation for this PMU. In this example, you will create PMU firmware for the PMU in Zynq UltraScale+ devices.

1. Select **File > New > Application Project**.
2. In the application dialog box, enter Project name `pmu_fw`.
3. Leave the **Use default location** check box selected.
4. For the OS Platform, select **Standalone**.
5. In the Target Hardware area, do the following:
 - a. Ensure that the hardware platform exported from Vivado in [Chapter 2](#), `edt_zcu102_wrapper_hw_platform_0`, is selected as the Hardware Platform.
 - b. For the processor, select **psu_pmu_0**.
6. In the Target Software area, do the following:
 - a. Select the **C** Language.
 - b. Under **Board Support Package**, select **Create New** and enter **pmu_bsp**.

7. Click **Next**.
8. Select the **ZynqMP PMU Firmware**.
9. Click **Finish**.




Figure 3-10: Templates Page of the New Project Dialog Box

10. Verify that the firmware was compiled and linked successfully to generate the executable in `pmu_firmware > Debug > pmu_fw.elf`.
11. Verify that the PMU BSP is also configured for `UART_1`. Refer to [Modifying the Board Support Package](#).

Example Project: Create Linux Images using PetaLinux

The earlier example highlighted creation of the bootloader images and bare-metal applications for APU, RPU, and PMU using Xilinx SDK. In this chapter, you will configure and build Linux Operating System Platform for ARM Cortex A53 core based APU on Zynq UltraScale+. The PetaLinux tool flow, along with the board-specific BSP, can be used to configure and build Linux images.



IMPORTANT: This example needs a Linux Host machine. [PetaLinux Tools Documentation: Reference Guide \(UG1144\)](#) [Ref 7] for information about dependencies for PetaLinux 2017.2.



IMPORTANT: This example uses the ZCU102 PetaLinux BSP to create a PetaLinux project. Ensure that you have downloaded the ZCU102 BSP for PetaLinux as instructed in [PetaLinux Tools, page 11](#).

1. Create a PetaLinux project using the following command:

```
$petalinux-create -t project -s <xilinx-ZCU102-v2017.2.bsp>
```

Note: `xilinx-v2017.2.bsp` is the PetaLinux BSP for ZCU102 Production Silicon Rev1.0 Board. Use `xilinx-ZCU102-ZU9-ES2-Rev1.0-v2017.2.bsp`, if you are using ES2 Silicon on Rev 1.0 board.

The above step creates a PetaLinux Project Directory, such as:
`xilinx-zcu102-2017.2`.

2. Change to the PetaLinux project directory using the following command:

```
$cd xilinx-zcu102-2017.2
```

The `ZCU102_Petalinux-BSP` is the default ZCU102 Linux BSP. For this example, you reconfigure the PetaLinux Project based on the Zynq UltraScale+ hardware platform that you configured using Vivado Design Suite in [Chapter 2](#).

3. Copy the hardware platform `edt_zcu102_wrapper.hdf` to the Linux Host machine.
4. Reconfigure the project using the following command:

```
$ petalinux-config --get-hw-description=<path containing edt_zcu102_wrapper.hdf>/
```

This command opens the PetaLinux Configuration window. If required, make changes in the configuration. For this example, the default settings from the BSP are sufficient to generate required boot images.

The following steps will verify if PetaLinux is configured to create Linux and boot images for SD Boot.

5. Select **Subsystem AUTO Hardware Settings**.
6. Select **Advanced Bootable Images Storage Settings**.
 - a. Select **boot image settings**.
 - b. Select **Image Storage Media**.
 - c. Select **primary sd** as the boot device.
7. Under the **Advanced Bootable Images Storage Settings** submenu, do the following:
 - a. Select **kernel image settings**.
 - b. Select **Image Storage Media**.
 - c. Select **primary sd** as the storage device.
8. Save the configuration settings and exit the Configuration wizard.
9. Wait until PetaLinux reconfigures the project.

The following steps will build the Linux images, verify them, and generate the boot image.

10. Modify Device Tree to disable UART1, Heartbeat LED and SW19 push button, from the device tree. This can be done by adding the following to the `system-user.dtsi` which can be found in the following location:

```
<Petalinux-project>/project-spec/meta-user/recipes-bsp/device-tree/files/system-user.dtsi
```

11. Add the following to `system-user.dtsi`, so that it looks like:

```
/include/ "system-conf.dtsi"
{
    gpio-keys {
        sw19 {
            status = "disabled";
        };
    };
    leds {
        heartbeat_led {
            status = "disabled";
        };
    };
};

&uart1
{
    status = "disabled";
};
```

12. Build the Linux images using the following command:

```
$petalinux-build
```

13. After the above statement executes successfully, verify the images and the timestamp in the `images` directory in the PetaLinux project folder using the following commands:

```
$cd images/linux/
$ls-al
```

14. Generate the Boot image using the following command:

```
$petalinux-package --boot --fsbl zynqmp_fsbl.elf --u-boot
```

This creates a `BOOT.BIN` image file in the following directory:

`<petalinux-project>/images/linux/BOOT.BIN`

Note: The Logs indicate that the above command includes PMU_FW and ATF in `BOOT.BIN`. You can also add `--pmufw <PMUFW_ELF>` and `--atf <ATF_ELF>` in the above command. Refer `$petalinux-package --boot --help` for more details.

Verify the Image on the ZCU102 Board

To verify the image:

1. Copy files `BOOT.BIN` and `image.ub` to an SD card.
2. Load the SD card into the ZCU102 board, in the J100 connector.

3. Connect Board USB-UART on Board to the Host machine.
4. Connect a Micro USB cable from ZCU102 Board USB UART port (J83), to USB port on the host Machine.
5. Configure the Board to Boot in SD-Boot mode by setting switch SW6 as shown in the following figure.




Figure 3-11: SW6 Switch Settings for SD Boot Mode

6. Connect 12V Power to the ZCU102 6-Pin Molex connector.
7. Start a terminal session, using Tera Term or Minicom depending on the host machine being used. set the COM Port and baud rate for your system, as shown in the following figure.




Figure 3-12: COM Port Set Up

8. For port settings, verify COM Port in the device manager and select the com port with interface-0.
9. Turn on the ZCU102 Board using SW1, and wait until Linux loads on the board.

Create Linux Images using PetaLinux for QSPI Flash

The earlier example highlighted creation of the Linux Images and Boot images to boot from an SD card. This section explains the configuration of PetaLinux to generate Linux images for QSPI flash. Refer to *PetaLinux Tools Documentation: Reference Guide (UG1144)* [Ref 7] for more information about the dependencies for PetaLinux 2017.2.

1. Before starting this example, create a backup of the boot images created for SD card setup using the following commands:

```
$ cd <Petalinux-project-path>/xilinx-zcu102-2017.2/images/linux/
$ mkdir sd_boot
$ cp zynqmp_fsbl.elf sd_boot/
$ cp bl31.elf sd_boot/
$ cp image.ub sd_boot/
$ cp u-boot.elf sd_boot/
$ cp BOOT.BIN sd_boot/
```

2. Change the directory to the PetaLinux Project root directory:

```
$ cd <Petalinux-project-path>/xilinx-zcu102-2017.2
```

3. Launch the top level system configuration menu:

```
$ petalinux-config
```

The Configuration wizard opens.

4. Select **Subsystem AUTO Hardware Settings**.
5. Select **Advanced Bootable Images Storage Settings**.
 - a. Select **boot image settings**.
 - b. Select **Image Storage Media**.
 - c. Select **primary flash** as the boot device.
6. Under the **Advanced Bootable Images Storage Settings** submenu, do the following:
 - a. Select **kernel image settings**.
 - b. Select **Image Storage Media**.
 - c. Select **primary flash** as the storage device.
7. One level above, that is, under **Subsystem AUTO Hardware Settings**,
 - a. Select **Flash Settings** and notice the entries listed in the partition table.
 - b. Note that some memory (0x1E00000 + 0x40000) is set aside for initial Boot partitions and U-boot settings. These values can be modified on need basis.
 - c. Based on this, the offset for Linux Images is calculated as 0x1E40000 in QSPI Flash device. This will be used in Chapter 5, while creating Boot image for QSPI Boot-mode.

The following steps will set the Linux System Memory Size to about 1.79 GB.

8. Under **Subsystem AUTO Hardware Settings**, do the following:

- a. Select **Memory Settings**

- a. Set **System Memory Size** to **0x70000000**

9. Save the configuration settings and exit the Configuration wizard.

Note: For 2017.1 and 2017.2 PetaLinux, see the Xilinx Answer [69382](#) or define CONFIG_ENV_SPI_MAX_HZ with following value in platform-top.h.

```
#define CONFIG_ENV_SPI_MAX_HZ 30000000
```

10. Rebuild using the Petalinux-build command.

11. Take a backup of u-boot.elf and the other images. These will be used in [Chapter 5](#).

Note: For more information, refer to the *PetaLinux Tools Documentation: Reference Guide* (UG1144) [[Ref 7](#)]

In this chapter, you learned how to configure and compile Software blocks for Zynq UltraScale+ devices using Xilinx tools. You will use these images in [Chapter 6](#) to create Boot images for a specific design example.

Next, you will debug software for Zynq UltraScale+ devices using Xilinx SDK in [Chapter 4, Debugging with SDK](#).

Debugging with SDK

This chapter describes debug possibilities with the design flow you have already been working with. The first option is debugging with software using the Xilinx® Software Development Kit (SDK).

SDK debugger provides the following debug capabilities:

- Supports debugging of programs on ARM® Cortex®-A53, ARM Cortex-R5, and MicroBlaze™ processor architectures (heterogeneous multi-processor hardware system debugging)
- Supports debugging of programs on hardware boards
- Supports debugging on remote hardware systems
- Provides a feature-rich IDE to debug programs
- Provides a Tool Command Language (Tcl) interface for running test scripts and automation

The SDK debugger enables you to see what is happening to a program while it executes. You can set breakpoints or watchpoints to stop the processor, step through program execution, view the program variables and stack, and view the contents of the memory in the system.

Xilinx SDK supports debugging through Xilinx System Debugger.

Xilinx System Debugger

The Xilinx System Debugger uses the Xilinx hw_server as the underlying debug engine. SDK translates each user interface action into a sequence of Target Communication Framework (TCF) commands. It then processes the output from System Debugger to display the current state of the program being debugged. It communicates to the processor on the hardware using Xilinx hw_server.

The debug workflow is described in the following figure.



X16794-041816

Figure 4-1: System Debugger Flow

The workflow is made up of the following components:

- **Executable ELF File:** To debug your application, you must use an Executable and Linkable Format (ELF) file compiled for debugging. The debug ELF file contains additional debug information for the debugger to make direct associations between the source code and the binaries generated from that original source. To manage the build configurations, right-click the software application and select **Build Configurations > Manage**.
- **Debug Configuration:** To launch the debug session, you must create a debug configuration in SDK. This configuration captures options required to start a debug session, including the executable name, processor target to debug, and other information. To create a debug configuration, right-click your software application and select **Debug As > Debug Configurations**.
- **SDK Debug Perspective:** Using the Debug perspective, you can manage the debugging or running of a program in the Workbench. You can control the execution of your program by setting breakpoints, suspending launched programs, stepping through your code, and examining the contents of variables. To view the Debug Perspective, select **Window > Open Perspective > Debug**.

You can repeat the cycle of modifying the code, building the executable, and debugging the program in SDK.

Note: If you edit the source after compiling, the line numbering will be out of step because the debug information is tied directly to the source. Similarly, debugging optimized binaries can also cause unexpected jumps in the execution trace.

Debugging Software Using SDK

In this example, you will walk through debugging a hello world application.

If you did not create a hello world application on APU or RPU, follow the steps in [Create Bare-Metal Application for ARM Cortex A53 based APU, page 38](#) to create a new hello world application.

After you create the Hello World Application, work through below example to debug the software using SDK.

1. Follow the steps in [Example Project: Running the "Hello World" Application from ARM Cortex-A53](#) to set the target in JTAG mode and power ON.
2. In the C/C++ Perspective, right-click the `test_a53` Project and select **Debug As > Launch on Hardware (System Debugger)**.

Note: The above step launches the System Debugger in the Debug perspective based on the project settings. Alternatively, you can also create a Debug configuration which looks like [Figure 4-2](#).




Figure 4-2: Debug Configurations

If the **Confirm Perspective Switch** popup window appears, click **Yes**. The Debug Perspective opens.

Note: If the Debug Perspective window does not automatically open, select **Window > Perspective > Open Perspective > Other**, then select **Debug** in the Open Perspective wizard.




Figure 4-3: Application Debug Perspective

Note: The addresses shown on this page might slightly differ from the addresses shown on your system.

The processor is currently sitting at the beginning of `main()` with program execution suspended at line `0x000000000000980`. You can confirm this information in the Disassembly view, which shows the assembly-level program execution also suspended at `0x000000000000980`.

Note: If the Disassembly view is not visible, select **Window > Show View > Disassembly**.

3. The `helloworld.c` window also shows execution suspended at the first executable line of C code. Select the Registers view to confirm that the program counter, `pc` register, contains `0x000000000000980`.

Note: If the Registers window is not visible, select **Window > Show View > Registers**.

4. Double-click in the margin of the `helloworld.c` window next to the line of code that reads `print("Hello World\n\r");`. This sets a breakpoint at the `printf` command. To confirm the breakpoint, review the Breakpoints window.

Note: If the Breakpoints window is not visible, select **Window > Show View > Breakpoints**.

5. Select **Run > Step Into** to step into the `init_platform ()` routine.

Program execution suspends at location `0x000000000000009c8`. The call stack is now two levels deep.

6. Select **Run > Resume** to continue running the program to the breakpoint.

Program execution stops at the line of code that includes the `printf` command. The Disassembly and Debug windows both show program execution stopped at `0x0000000000000984`.

Note: The execution address in your debugging window might differ if you modified the hello world source code in any way.

7. Select **Run > Resume** to run the program to conclusion.

When the program completes, the Debug window shows that the program is suspended in a routine called `exit`. This happens when you are running under control of the debugger.

8. Re-run your code several times. Experiment with single-stepping, examining memory, breakpoints, modifying code, and adding print statements. Try adding and moving views.



TIP: You can use SDK tool debugging shortcuts for step-into (F5), step-return (F7), step-over (F6), and resume (F8).

Debugging Using XSCT

You can use the previous steps to debug bare-metal applications running on RPU and PMU using SDK system Debugger GUI.

Additionally, you can debug in the command line mode using XSDB, which is encapsulated as a part of XSCT. In this example, you will debug the bare-metal application `testapp_r5` using XSCT.

Following steps indicate how to load a bare-metal application on R5 using XSCT.

This example is just to demonstrate the command line debugging possibility using XSDB/XSCT. Based on the requirement, you can choose to debug the code using either the System Debugger graphical interface or the command line debugger in XSCT. All XSCT commands are scriptable and this applies to the commands covered in this example.

Set Up Target

1. Connect a USB cable between USB-JTAG J2 connector on target and the USB port on the host machine.
2. Set the board in JTAG Boot mode, where SW6 is set as shown in following figure.



Figure 4-4: SW6 Switch Settings for JTAG Boot Mode

3. Power on the Board using switch SW1.
4. Open XSCT Console in SDK, click the **XSCT Console** button  in the SDK tool bar.

Alternatively, you can also open the XSCT console from **Xilinx Tools > XSCT Console**.

5. In the XSCT Console, connect to the target over JTAG using the `connect` command:

```
xsct% connect
```

The `connect` command returns the channel ID of the connection.


6. Command **targets** lists the available targets and allows you to select a target through its ID.

The targets are assigned IDs as they are discovered on the JTAG chain, so the target IDs can change from session to session.

For non-interactive usage such as scripting, the `-filter` option can be used to select a target instead of selecting the target through its ID:

```
xsct% targets
```

The targets are listed as shown in the following figure.



```

SDK Log Search XSCT Console X
XSCT Process
xsct% targets
 1 PS TAP
 2 PMU
 3 PL
 4 PSU
 5 RPU (Reset)
 6 Cortex-R5 #0 (RPU Reset)
 7 Cortex-R5 #1 (RPU Reset)
 8 APU (L2 Cache Reset)
 9 Cortex-A53 #0 (APU Reset)
10 Cortex-A53 #1 (APU Reset)
11 Cortex-A53 #2 (APU Reset)
12 Cortex-A53 #3 (APU Reset)
xsct%


```

Figure 4-5: Target List

- Now select PSU target. The ARM APU and RPU clusters are grouped under PSU.

```
xsct% targets -set -filter {name=~ "PSU"}
```

The command target now lists the targets and also shows the selected target highlighted with an asterisk (*) mark. You can also use target number to select a Target, as shown in the following figure.



```

SDK Log Search XSCT Console X
XSCT Process
xsct% target 4
xsct% targets
 1 PS TAP
 2 PMU
 3 PL
 4* PSU
 5 RPU (Reset)
 6 Cortex-R5 #0 (RPU Reset)
 7 Cortex-R5 #1 (RPU Reset)
 8 APU (L2 Cache Reset)
 9 Cortex-A53 #0 (APU Reset)
10 Cortex-A53 #1 (APU Reset)
11 Cortex-A53 #2 (APU Reset)
12 Cortex-A53 #3 (APU Reset)
xsct%

```

Figure 4-6: PSU Target Selected

- Source the `psu_init.tcl` script and run the `psu_init` command to initialize the Processing System of Zynq® UltraScale+™.

```
xsct% source
{C:\edt\edt_zcu102\edt_zcu102.sdk\edt_zcu102_wrapper_hw_platform_0\psu_init.tcl}
xsct% psu_init
```

Note the {} used in above command. These are required on windows machine to enable backward slash (\) in paths. These braces can be avoided by using forward "/" in paths. Considering Linux paths, use forward "/" because the paths in XSCT in Linux can work as is, without any braces.

Load the Application Using XSCT

1. Now download the testapp_r5 application on Arm R5 Core 0.
2. Check and select RPU Cortex-R5 Core 0 target ID

```
xsct% targets
xsct% targets -set -filter {name =~ "Cortex-R5 #0"}
xsct% rst -processor
```

The command `rst -processor` clears the reset on an individual processor core.

This step is important, because when Zynq MPSoC boots up JTAG boot mode, all the A53 and R5 cores are held in reset. You must clear the resets on each core, before debugging on these cores. The `rst` command in XSDB can be used to clear the resets.

Note: The command `rst -cores` clears resets on all the processor cores in the group (such as APU or RPU), of which the current target is a child. For example, when A53 #0 is the current target, `rst -cores` clears resets on all the A53 cores in APU.

```
xsct% dow {C:\edt\edt_zcu102\edt_zcu102.sdk\testapp_r5\Debug\testapp_r5.elf}
```

Or

```
xsct% dow C:/edt/edt_zcu102/edt_zcu102.sdk/testapp_r5/Debug/testapp_r5.elf
```

At this point, you can see the sections from the ELF file downloaded sequentially. The XSCT prompt can be seen after successful download.

Now, configure a serial terminal (Tera Term, Mini com, or the SDK Serial Terminal interface for UART-1 USB-serial connection).

Serial Terminal Configuration

1. Start a terminal session, using Tera Term or Mini com depending on the host machine being used, and the COM port and baud rate as shown in following figure.




Figure 4-7: COM Port Set Up

2. For port settings, verify the COM port in the device manager. There are four USB UART interfaces exposed by the ZCU102 board. Select the COM port associated with the interface with the lowest number. So in this case, for UART-0, select the com-port with interface-0.
3. Similarly, for UART-1, select com-port with interface-1. Remember that R5 BSP has been configured to use UART-1, and so R5 application messages will appear on the com-port with UART-1 terminal.

Run and Debug Application Using XSCT

1. Now before you run the application, set a breakpoint at `main()`.

```
xsct% bpadd -addr &main
```

This command returns the breakpoint ID.

You can verify the breakpoints planted using command `bplist`.

For more details on breakpoints in XSCT, type `help breakpoint` in XSCT,

2. Now resume the processor core.

```
xsct% con
```

The following informative messages will be displayed when the core hits the breakpoint.

```
xsct% Info: Cortex-R5 #0 (target 7) Stopped at 0x10021C (Breakpoint)
```

3. At this point, you can view registers when the core is stopped.

```
xsct% rrd
```


4. View local variables

```
xsct% locals
```

5. Step over a line of the source code and view the stack trace.

```
xsct% nxt
Info: Cortex-R5 #0 (target 6) Stopped at 0x100490 (Step)
xsct% bt
```

You can use the `help` command to find other options:



The screenshot shows the XSCT Console window with the title bar "XSCT Log" and "XSCT Console". The main area displays the output of the "help" command. It starts with "XSCT Process" and then lists various categories with their descriptions. At the bottom, it provides instructions for getting more details or listing all commands.

```

XSCT Process
xsct% help
Available Help Categories

connections      - Target Connection Management
registers        - Target Registers
running          - Program Execution
memory           - Target Memory
download         - Target Download FPGA/BINARY
reset            - Target Reset
breakpoints      - Target Breakpoints/Watchpoints
streams          - Jtag UART
miscellaneous    - Miscellaneous
jtag             - JTAG Access
tfile            - Target File System
sdk              - SDK Projects
petalinux        - Petalinux commands
hsi              - HSI commands


Type "help" followed by above "category" for more details or
help" followed by the keyword "commands" to list all the commands

xsct%

```

Figure 4-8: XSCT Help Categories

You can use the `help running` command to get a list of possible options for running or debugging an application using XSCT.



```

SDK Log XSCT Console X
XSCT Process
xsct% help running
Category commands

state      - Display the current state of the target
stop       - Stop active target
con        - Resume active target
stp        - step into a line of source code
nxt        - step over a line of source code
stpi       - Execute a machine instruction
nxti      - step over a machine instruction
stfout    - step out from current function
dis        - Disassemble Instructions
print      - Get or set the value of an expression
locals     - Get or set the value of a local variable
backtrace - Stack back trace
profile    - Configure and run the GNU profiler
mbprofile - Configure and run the MB profiler

Type "help" followed by above "command", or the above "command" followed by
"-help" for more details
xsct%

```

Figure 4-9: XSCT Help for Debugging Program Execution

6. You can now run the code:

```
xsct% con
```

At this point, you can see the R5 application print message on UART-1 terminal.

Boot and Configuration

This chapter shows integration of components to create a Zynq UltraScale+ system. The purpose of this chapter is to understand how to integrate and load Boot loaders, bare-metal applications (For APU/RPU), and Linux Operating System for a Zynq UltraScale+ system.

The following important points are covered in this chapter:

- System Software: FSBL, U-boot, ARM trusted firmware (ATF)
- Application Processing Unit (APU): Configure SMP Linux for APU
- Real-time Processing Unit (RPU): Configure Bare-metal for RPU in Lock-step
- Create Boot Image for the following Boot sequence:
 - a. APU
 - b. RPU Lock-step
- Create and load Secure Boot Image

Note: For more information on RPU Lock-step, see *Zynq UltraScale+ MPSoC Technical Reference Manual* (UG1085) [Ref 5].

This boot sequence also includes loading the PMU Firmware for the Platform Management Unit (PMU). You can achieve the above configurations using a Xilinx SDK and PetaLinux Tool flow. While [Chapter 3](#) focused only on creating software blocks for each processing unit in the PS, this chapter explains how these blocks can be loaded as a part of a bigger system.

The Create Boot Image wizard (Bootgen - Command Line tool) from SDK is used in generating Boot Image. Create Boot Image Wizard's or Bootgen's principle function is to integrate the partitions (hardware-bitstream and software), and allow you to specify the security options in the design. It can also create the cryptographic keys.

Functionally, Bootgen uses a Bootgen Image Format (BIF) file as an input, and generates a single file image in binary BIN or MCS format. Bootgen outputs a single file image which is loaded into NVM (QSPI, SD Card). The Bootgen GUI facilitates the creation of the BIF input file.

This chapter makes use of Processing System block. [Design Example 1: Using GPIOs, Timers, and Interrupts](#), covers Boot-image which will include the PS partitions used in this chapter and a bitstream targeted for PL fabric.

System Software

The following system software blocks cover most of the Boot and Configuration for this chapter. For detailed boot flow and various Boot sequences, refer to the "System Boot and Configuration" chapter in the *Zynq UltraScale+ MPSoC: Software Developers Guide* (UG1137) [Ref 6].

First Stage Boot Loader

In non-secure Boot mode, the platform management unit (PMU) releases the reset of the configuration security unit, and enters the PMU server mode to monitor power. At this stage the configuration security unit loads the first stage boot loader (FSBL) into on-chip memory (OCM). The FSBL can be run from either RPU or APU. In this example, the FSBL is targeted for APU.

The First Stage Boot Loader initializes important blocks in the processing subsystem. This includes clearing the reset of the processors, initializing clocks, memory, UART, and so on before handing over the control of the next partition in DDR, to either RPU or APU. In this example, the FSBL loads bare-metal application in DDR and handsoff to RPU R5 in Lockstep mode, and similarly loads U-boot to be executed by APU A53 Core-0. For more information, see the *Zynq UltraScale+ MPSoC: Software Developers Guide* (UG1137) [Ref 6]. For this chapter, you can use the FSBL executable that you created in Chapter 3.

Platform Management Unit Firmware

The platform management unit (PMU) and the configuration security unit manage and perform the multi-staged booting process. The PMU primarily controls the pre-configuration stage that executes PMU ROM to set up the system. The PMU handles all of the processes related to reset and wake-up. SDK provides PMU Firmware that can be built to run on the PMU. For more details on the Platform Management and PMU Firmware, see the *Zynq UltraScale+ MPSoC: Software Developers Guide* (UG1137) [Ref 6].

The PMU Firmware can be loaded in the following ways:

1. Using BootRom to load PMU Firmware, as described in [Boot Sequence for SD-Boot](#)
2. Using FSBL to load PMU Firmware, as described in [Boot Sequence for QSPI Boot Mode](#)
3. Load PMU Firmware in JTAG boot mode, as described in [Boot Sequence for QSPI-Boot Mode Using JTAG](#).

For more information, see the [PMU Firmware Xilinx Wiki](#).

U-boot

The U-boot acts as a secondary boot loader. After the FSBL handoff, the U-boot loads Linux on ARM A53 APU. After FSBL, the U-boot configures the rest of the peripherals in the processing system based on board configuration. U-boot can fetch images from different memory sources like eMMC, SATA, TFTP, SD, and QSPI. For this example, U-boot and all other images are loaded from the SD card. Therefore, for this example, the Board will be set to SD-boot mode.

U-boot can be configured and built using the PetaLinux tool flow. For this example, you can use the U-boot image that you created in [Chapter 3](#) or from the design files shared with this document. See [Design Files for This Tutorial, page 147](#) for information about downloading the design files for this tutorial.

ARM Trusted Firmware

The ARM Trusted Firmware (ATF) is a transparent bare-metal application layer executed in Exception Level 3 (EL3) on APU. The ATF includes a Secure Monitor layer for switching between secure and non-secure world. The Secure Monitor calls and implementation of Trusted Board Boot Requirements (TBBR) makes the ATF layer a mandatory requirement to load Linux on APU on Zynq UltraScale+.

The FSBL loads ATF to be executed by APU, which keeps running in EL3 awaiting a service request. The FSBL also loads U-boot in DDR to be executed by APU, which loads Linux OS in SMP mode on APU.

The ATF (`bl31.elf`) is built by default in PetaLinux and can be found in the PetaLinux Project images directory.

For more details on ATF, refer to the "ARM Trusted Firmware" section in the "Security" chapter of the *Zynq UltraScale+ MPSoC: Software Developers Guide* (UG1137) [\[Ref 6\]](#).

Linux on APU and Bare-Metal on RPU

Now that the system software is configured, create Linux Images using PetaLinux Toolflow. You already created the PetaLinux images in [Chapter 3](#). For this example, the PetaLinux is configured to build images for SD-boot. This is the default boot setting in PetaLinux.

The images can be found in the `$<PetaLinux_Project>/images/linux` directory.

For loading Linux on APU, the following images will be used from PetaLinux:

- ATF - `bl31.elf`
- U-boot - `u-boot.elf`

- Linux images - `Image.ub`, which contains:
 - Kernel image
 - Device Tree System.`dtb`
 - Filesystem - `RootFS`

In addition to Linux on APU, this example also loads a bare-metal Application on RPU R5 in Lockstep mode.

For this example, refer the `testapp_r5` application that you created in [Create Bare-Metal Application for ARM Cortex R5 based RPU, page 39](#).

Alternatively you can also find the `testapp_r5.elf` executable in the design files that accompany this tutorial. See [Design Files for This Tutorial, page 147](#) for information about downloading the design files for this tutorial.

Boot Sequence for SD-Boot

Now that all the individual images are ready, let's create the boot image to load all of these components on Zynq UltraScale+. This can be done using the Create Boot Image wizard in SDK, using the following steps:

4. In SDK, select **Xilinx Tools > Create Boot Image**.
5. Select all the partitions referred in earlier sections in this chapter, and set them as shown in the following figure.




Figure 5-1: Create Boot Image for SD Boot Mode

First, add the FSBL partition.

1. In the Create Boot Image dialog box, click **Add** to open the Add partition dialog box.
2. In the Add Partition dialog box, click **Browse** to select the FSBL executable.
3. For FSBL, ensure that the partition type is selected as `bootloader` and the correct destination CPU is selected by the tool. The tool is configured to make this selection based on the FSBL executable.

Note: Ignore the Exception Level drop down, as FSBL is set to EL3 by default. Also, leave the Trustzone setting unselected for this example.




Figure 5-2: Add New Boot Image Partition Dialog Box

- Click **OK** to select FSBL and go back to Create Boot Image wizard.

Next, add the PMU and ATF firmware partitions.

- Click **Add** to open the Add Partition dialog box, shown in the following figure.




Figure 5-3: Add PMUFW Partition

2. Add the PMU firmware partition.

 - a. Browse to and select the PMU Firmware executable.
 - b. For this partition, select **pmu** as the partition type.

Note: The **pmu** partition type also implies that the executable is targeted for PMU. Therefore, the **Destination Device** and **Destination CPU** are grayed out for this setting.

3. Leave the Exception Level and Trustzone settings unselected.

4. Click **OK**.

5. Click **Add** to open Add Partition dialog box.
6. Add the **ATF firmware bl31.elf** partition.

Note: ATF Firmware (bl31.elf) can be found in <PetaLinux Project>/image/linux/. Alternatively, you can also use bl31.elf from [Design Files for This Tutorial](#).

- a. For this partition, select **datafile** as the partition type.
- b. Set the Destination Device as **PS**.
- c. Set the Destination CPU as **ARM A53 0**.
- d. Set the Exception Level to **EL3** and select **Enable Trustzone**.




Figure 5-4: Add ATF partition

7. Click **OK**.

Next, add the R5 executable and enable it in lockstep mode.

1. Click **Add** to add the R5 bare-metal executable.




Figure 5-5: Add RPU Image Partition

2. Set the Destination Device as **PS**.
3. Set the Destination CPU as **R5 Lockstep**.

This sets the RPU R5 cores to run in Lockstep mode.

4. Leave Exception Level and Trustzone unselected.
5. Click **OK**.

Now, add the U-boot.elf partition. You can find U-boot.elf for sd_boot mode in <Petalinux_project>/images/linux/sd_boot

1. Click **Add** to add the U-boot.elf partition.
2. For U-boot, select the Destination Device as PS.
3. Select the Destination CPU as **A53 0**.
4. Set the Exception Level to **EL2**.




Figure 5-6: Add U-boot Partition

5. Click **OK** to return to the Create Boot Image wizard.
6. Click **Create Image** to close the wizard and create the boot image.

You can also create Boot.bin images using the BIF attributes and the Bootgen command.

For this configuration, the BIF file contains following attributes:

```
//arch = zynqmp; split = false; format = BIN
the_ROM_image:
{
    [fsbl_config]a53_x64
    [bootloader]C:\edt\edt_zcu102\edt_zcu102.sdk\fsbl_a53\Debug\fsbl_a53.elf

    [pmufw_image]C:\edt\edt_zcu102\edt_zcu102.sdk\pmu_fw\Debug\pmu_fw.elf
    [destination_cpu = a53-0, exception_level=el-3,
    trustzone]C:\edt\design_files\sd_boot\bl31.elf
    [destination_cpu =
    r5-lockstep]C:\edt\edt_zcu102\edt_zcu102.sdk\testapp_r5\Debug\testapp_r5.elf
    [destination_cpu = a53-0,
    exception_level=el-2]C:\edt\design_files\sd_boot\u-boot.elf
}
```

SDK calls the following Bootgen command to generate the Boot.bin image for this configuration:

```
bootgen -image sd_boot.bif -arch zynqmp -o C:\edt\BOOT.bin
```

Running the Image on the ZCU102 Board

1. Copy the Boot.bin and image.ub images on an SD card and load it in the SD card slot in the Board.
2. Copy files BOOT.BIN and image.ub to an SD card.
3. Load the SD card into the ZCU102 board, in the J100 connector.
4. Connect the Micro USB cable into the ZCU102 Board Micro USB port J83, and the other end into an open USB port on the host Machine. This is for USB UART connection.
5. Configure the Board to Boot in SD-Boot mode by setting switch SW6 to 1-ON, 2-OFF, 3-OFF and 4-OFF, as shown in following figure.



Figure 5-7: SW6 Switch Settings for SD Boot Mode

6. Connect 12V Power to the ZCU102 6-Pin Molex connector.
7. Start a terminal session, using Tera Term or Minicom depending on the host machine being used, as well as the COM Port and baud rate for your system, as shown in following figure.




Figure 5-8: COM Port Set Up

8. For port settings, verify COM Port in device manager.

There are four USB-UART interfaces exposed by the ZCU102 Board.

9. Select the COM Port associated with the interface with the lowest number. In this case, for UART-0, select the com-port with interface-0.
10. Similarly, for UART-1, select com-port with interface-1.

Remember that the R5 BSP has been configured to use UART-1, and so R5 application messages will appear on the com-port with the UART-1 terminal.

11. Turn on the ZCU102 Board using SW1, and wait until Linux loads on the board.

At this point, you can see the initial Boot sequence messages on your Terminal Screen representing UART-0.

You can see that the terminal screen configured for UART-1 also prints a message. This is the print message from the R5 bare-metal Application running on RPU, configured to use UART-1 interface. This application is loaded by the FSBL onto RPU.

The bare-metal application has been modified to include the UART interrupt example. This application now waits in the waiting for interrupt (WFI) state until a user input is encountered from Keyboard in UART-1 terminal.




Figure 5-9: Hello World Displayed on UART-1 from R5-0

Meanwhile, the boot sequence continues on APU and the images loaded can be understood from the messages appearing on the UART-0 terminal. The messages are highlighted in the following figure.

```

Xilinx Zynq MP First Stage Boot Loader
Release 2017.1 - 16:44:24
Reset Mode : System Reset
Platform: Silicon (4.0), Cluster ID 0x80000000
Running on A53-0 (64-bit) Processor, Device Name: XCZU9EG
Board Configuration successful
Processor Initialization Done
===== In Stage 2 =====
SD1 with level shifter Boot Mode
SD: rc= 0
File name is BOOT.BIN
Multiboot Reg : 0x0
Image Header Table Offset 0x8C0
*****Image Header Table Details*****
Boot Gen Ver: 0x1020000
No of Partitions: 0x7
Partition Header Address: 0x440
Partition Present Device: 0x0
Initialization Success
===== In Stage 3, Partition No:1 =====
Partition 1 Load Success
===== In Stage 3, Partition No:2 =====
Partition 2 Load Success
===== In Stage 3, Partition No:3 =====
Partition 3 Load Success
===== In Stage 3, Partition No:4 =====
Partition 4 Load Success
===== In Stage 3, Partition No:5 =====
Partition 5 Load Success
All Partitions Loaded
===== In Stage 4 =====
Protection configuration applied
CPU 0x500 reset release, Exec State 0x8, HandoffAddress: 3C
    ATF running on XCZU9EG/silicon v4/RTL5.1 at 0xffffea000, with PMU firmware
NOTICE: BL31: Secure code at 0x0
NOTICE: BL31: Non secure code at 0x8000000
NOTICE: BL31: v1.3(release):7dia673
NOTICE: BL31: Built : 06:44:20, [REDACTED]

```

FSBL On ARM Cortex A53


```

U-Boot 2017.01 (Jul 02 2017 - 16:02:13 +0530) Xilinx ZynqMP ZCU102

I2C: ready
DRAM: 2 GiB
EL Level: EL2
Chip ID: xczu9eg
MMC: sdhci@ff170000: 0 (SD)
SF: Detected n25q512a with page size 512 Bytes, erase size 128 KiB, total 128 MiB

```

PMU Firmware Loaded

ARM Trusted Firmware

Figure 5-10: Messages from APU During Zynq UltraScale+ Boot Sequence

The U-boot then loads Linux Kernel and other images on ARM® Cortex® A53 APU in SMP mode. The terminal messages indicate when U-boot loads Kernel image and the kernel start up to getting a user interface prompt in Target Linux OS. The Kernel loading and starting sequence can be seen in the following figure.

```

reading image.ub
75735640 bytes read in 4924 ms (14.7 MiB/s)
## Loading kernel from FIT Image at 10000000 ...
Using 'conf@1' configuration
Trying 'kernel@0' kernel subimage
  Description: Linux Kernel
  Type:       Kernel Image
  Compression: uncompressed
  Data Start: 0x100000d8
  Data Size:  13171200 Bytes = 12.6 MiB
  Architecture: AArch64
  OS:         Linux
  Load Address: 0x00080000
  Entry Point: 0x00080000
  Hash algo:   sha1
  Hash value:  f095d304a568f560fbc4e83ddaa1600b6ceb7d8
Verifying Hash Integrity ... sha1+ OK
## Loading ramdisk from FIT Image at 10000000 ...
Using 'conf@1' configuration
Trying 'ramdisk@0' ramdisk subimage
  Description: ramdisk
  Type:       RAMDisk Image
  Compression: uncompressed
  Data Start: 0x10c9a378
  Data Size:  62520042 Bytes = 59.6 MiB
  Architecture: AArch64
  OS:         Linux
  Load Address: unavailable
  Entry Point: unavailable
  Hash algo:   sha1
  Hash value:  91828eafdf9bd095cd965ecefaf79f863f8dd90fda
Verifying Hash Integrity ... sha1+ OK
## Loading fdt from FIT Image at 10000000 ...
Using 'conf@1' configuration
Trying 'fdt@0' fdt subimage
  Description: Flattened Device Tree blob
  Type:       Flat Device Tree
  Compression: uncompressed
  Data Start: 0x10c8fb0
  Data Size:  42737 Bytes = 41.7 KiB
  Architecture: AArch64
  Hash algo:   sha1
  Hash value:  fe11097c8fedecdee3e4bf31d27370e536896e85
Verifying Hash Integrity ... sha1+ OK
Booting using the fdt blob at 0x10c8fb0
Loading Kernel Image ... OK
Loading Ramdisk to 04460000, end 07ffffea ... OK
Loading Device Tree to 0000000004452000, end 000000000445f6f0 ... OK

Starting kernel ...

[    0.000000] Booting Linux on physical CPU 0x0

```

Figure 5-11: Kernel Loading and Start Sequence

Boot Sequence for QSPI Boot Mode

The ZCU102 board also comes with dual parallel QSPI Flashes adding up to 128 MB size. In this example, you will create a boot image and load the images on Zynq UltraScale+ in QSPI boot mode. The images can be configured using the Create Boot Image wizard in SDK. This can be done by doing the following steps.

Note: This section assumes that you have created PetaLinux Images for QSPI Boot mode by following steps from [Create Linux Images using PetaLinux for QSPI Flash](#).

1. If SDK is not already running, start it and set the workspace as indicated in [Chapter 3](#).
2. Select **Xilinx Tools > Create Boot Image**.
3. Select **Zynq MP** as the Architecture.
4. Select the **Create new BIF file** option.
5. Ensure that the **Output format** is set to **BIN**.
6. In the Basic tab, browse to and select the **Output BIF file path** and **Output path**.




Figure 5-12: Create Boot Image for QSPI Boot Mode

Next, add boot partitions.

1. Click **Add** to open the Add Partition dialog box.
2. In the Add Partition dialog box, click the **Browse** button to select the FSBL executable.
 - a. For FSBL, ensure that the **Partition type** is selected as **bootloader** and the correct destination CPU is selected by the tool. The tool is configured to make this selection based on the FSBL executable.




Figure 5-13: Add New Boot Image Partition Dialog Box

- b. Ignore the Exception Level, as FSBL is set to EL3 by default. Also, leave the Trustzone setting unselected for this example.
- c. Click **OK** to select the FSBL and go back to the Create Boot Image wizard.
3. Click **Add** to open the Add Partition window to add the next partition.
4. The next partition is the PMU firmware for the Platform Management Unit.
 - a. Select the **Partition type** as **datafile** and the **Destination Device** as **PS**.
 - b. Select **PMU** for Destination CPU.
 - c. Click **OK**.




Figure 5-14: Add PMU Partition Details

5. The next partition to be added is the **ATF firmware**. For this, set the **Partition type** to **datafile**.
 - a. The ATF executable `b131.elf` can be found in the PetaLinux images folder `<PetaLinux_project>/images/linux/`.
 - b. Select the **Destination Device** as **PS** and the **Destination CPU** as **A53 0**.
 - c. Set the Exception Level to **EL3** and select **Enable Trustzone**.




Figure 5-15: Add ATF Partition

- d. Click **OK**.
6. Click **Add** to add the R5 bare-metal executable.
- Add the R5 executable and enable it in **lockstep** mode, as shown in the following image.
 - Click **OK**.




Figure 5-16: Add RPU Lockstep Image Partition

7. Click **Add** to add the U-boot.elf partition. U-boot.elf can be found in <PetaLinux_Project>/images/linux/
- For U-boot, make the following selections:
 - Set the **Partition Type** to **datafile**.
 - Set the **Destination Device** to **PS**.
 - Set the **Destination CPU** to **ARM A53 0**.
 - Set the Exception Level to **EL2**.




Figure 5-17: Add U-boot Partition

- b. Click **OK**.
8. Click **Add** to add the image.ub Linux image file.
 - a. The `image.ub` image file can be found in PetaLinux project in the `images/Linux` directory.
 - b. For `image.ub`, make the following selections:
 - Set **Partition Type** to **datafile**.
 - Set the **Destination Device** to **PS**.
 - Set the **Destination CPU** to **ARM A53 0**.
 - c. Enter `0x1E40000` as the **Offset**.
 - d. Enter `0x10000000` as the Load Address.
 - e. Leave Exception Level and Trustzone unselected.

Note: The Load Address setting in the above step is optional, and not required if the image is to be loaded to DDR using U-boot. With Step 8.d, the partition will be written to the location (Load Address) in DDR by FSBL. In this example, both FSBL and U-boot are copying the image to DDR. You can chose to load the image by either FSBL/U-boot by setting the `partition_owner = U-boot` (or `FSBL`) flag in the BIF file.



TIP: See [Create Linux Images using PetaLinux for QSPI Flash](#), to understand the offset value.

9. Click **OK** to go back to Create Boot Image wizard.
10. Click **Create Image** to create the `qspi_BOOT.bin` image.

You can also create Boot.bin images using the BIF attributes and the Bootgen command. You can view the BIF attributes for this configuration by clicking **Preview BIF Changes**. For this configuration, the BIF file contains following attributes:

```
//arch = zynqmp; split = false; format = BIN
the_ROM_image:
{
    [fsbl_config]a53_x64
    [bootloader]C:\edt\edt_zcu102\edt_zcu102.sdk\fsbl_a53\Debug\fsbl_a53.elf
    [destination_cpu = pmu]C:\edt\edt_zcu102\edt_zcu102.sdk\pmu_fw\
Debug\pmu_fw.elf
    [destination_cpu = a53-0, exception_level=el-3,
trustzone]C:\edt\design_files\qspi_boot\bl31.elf
    [destination_cpu =
r5-lockstep]C:\edt\edt_zcu102\edt_zcu102.sdk\testapp_r5\Debug\testapp_r5.elf
    [destination_cpu = a53-0,
exception_level=el-2]C:\edt\design_files\qspi_boot\u-boot.elf

    [offset = 0x1E40000, load=0X10000000, destination_cpu =
a53-0]C:\edt\design_files\image.ub
}
```

SDK calls the following Bootgen command to generate the qspi_BOOT.bin image for this configuration.

```
bootgen -image qspi_boot.bif -arch zynqmp -o C:\edt\qspi_BOOT.bin
```

Note: In this boot sequence, the First Stage Boot Loader (FSBL) loads PMU firmware. This is because the PMU Firmware was added as a **datafile** partition type. Ideally, the Boot ROM code can load the PMU Firmware for PMU as witnessed in the earlier section. For more details on PMU Firmware, refer to the "Platform Management" chapter in the *Zynq UltraScale+ MPSoC: Software Developers Guide* (UG1137) [\[Ref 6\]](#).

Running the Image in QSPI Boot Mode on ZCU102 Board

To test the image in this example, you will load the Boot.bin image onto QSPI on the ZCU102 board using the Program Flash utility in SDK. Alternately, you can use the XSDB debugger in Xilinx SDK.

1. In Xilinx SDK, select **Xilinx Tools > Program Flash**.
2. In the Program Flash wizard, browse to and select the qspi_boot.bin image file that was created as a part of this example.
3. Select **qspi_dual_parallel** as the Flash type.
4. Set the **Offset** as **0** and select the FSBL ELF file.
5. Ensure that a USB cable is connected between the USB-JTAG connector on ZCU102 target and the USB port on the Host machine using the following steps.
 - a. Set the **SW6 Boot mode switch** as shown in the following figure.
 - b. Turn on the board.



Figure 5-18: SW6 Switch Settings for JTAG Boot Mode

6. Click **Program** to start the process of programming the QSPI Flash with the `Boot.bin` image.





Figure 5-19: Program Flash Memory Dialog Box

Wait until you see the message “Flash Operation Successful” in the SDK Console, as shown in the following image.



```

Problems Tasks Console Properties SDK Terminal
Program Flash
Connected to hw_server @ TCP:127.0.0.1:3121
Available targets and devices:
Target 0 : jsn-JTAG-SMT2NC-210308A11A32
Device 0 : jsn-JTAG-SMT2NC-210308A11A32-04738093-0
|
Retrieving Flash info...
f probe 0 0 0
Performing Erase Operation...
Erase Operation successful.
INFO: [Xicom 50-44] Elapsed time = 24 sec.
Performing Program Operation...
0%...10%...20%...30%...40%...50%...60%...70%...80%...90%...100%
Program Operation successful.
INFO: [Xicom 50-44] Elapsed time = 1723 sec.

Flash Operation Successful

```

Figure 5-20: SDK Console Program Flash Messages

Set Up the ZCU102 Board

1. Connect Board USB-UART on Board to Host machine. Connect the Micro USB cable into the ZCU102 Board Micro USB port **J83**, and the other end into an open USB port on the host Machine.
2. Configure the Board to Boot in QSPI-Boot mode by switching **SW6** as shown in following figure.




Figure 5-21: SW6 Switch Settings for QSPI Boot Mode

3. Connect 12V Power to the ZCU102 6-Pin Molex connector.
4. Start a terminal session, using Tera Term or Mini com, depending on the host machine being used, and the COM Port and baud rate as shown in following figure.

5. For port settings, verify the Com port in the device manager. There are four USB UART interfaces exposed by the ZCU102.
6. Select the COM port associated with the interface with the lowest number. In this case, for UART-0, select the com-port with interface-0.
7. Similarly, for UART-1, select com-port with interface-1.

Remember, R5 BSP has been configured to use UART-1, so R5 application messages will appear on the com-port with UART-1 terminal.




Figure 5-22: COM Port Settings for UART-1 Terminal

8. Turn on the ZCU102 Board using **SW1**.

At this point, you can see initial Boot sequence messages on your Terminal Screen representing UART-0.

You can see that the terminal screen configured for UART-1 also prints a message. This is the print message from the R-5 bare-metal Application running on RPU, configured to use UART-1 interface. This application is loaded by the FSBL onto RPU.

The bare-metal application has been modified to include the UART interrupt example. This application now waits in the WFI state until a user input is encountered from Keyboard in UART-1 terminal.



Figure 5-23: Hello World Displayed on UART-1 From R5-0

Meanwhile, the boot sequence continues on APU and the images loaded can be understood from the messages appearing on the UART-0 terminal. The messages are highlighted in the following figure.

```

Xilinx Zynq MP First Stage Boot Loader
Release 2017.1 - 15:06:24
Reset Mode : System Reset
Platform: Silicon (4.0), Cluster ID 0x80000000
Running on A53-0 (64-bit) Processor, Device Name: XCZU9EG
Board Configuration successful
Processor Initialization Done
===== In Stage 2 =====
QSPI 32 bit Boot Mode
QSPI is in Dual Parallel connection
FlashID=0x20 0xBB 0x20
MICRON 512M Bits
Multiboot Reg : 0x0
.QSPI Reading Src 0x44, Dest FFFDF020, Length 4
.QSPI Reading Src 0x98, Dest FFFDF050, Length 4
.Image Header Table Offset 0x8C0
.QSPI Reading Src 0x8C0, Dest FFFDA150, Length 40
.*****Image Header Table Details*****
Boot Gen Ver: 0x1020000
No of Partitions: 0x9
Partition Header Address: 0x440
Partition Present Device: 0x0
.QSPI Reading Src 0x1100, Dest FFFDA190, Length 40
.QSPI Reading Src 0x1140, Dest FFFDA1D0, Length 40
.QSPI Reading Src 0x1180, Dest FFFDA210, Length 40
.QSPI Reading Src 0x11C0, Dest FFFDA250, Length 40
.QSPI Reading Src 0x1200, Dest FFFDA290, Length 40
.QSPI Reading Src 0x1240, Dest FFFDA2D0, Length 40
.QSPI Reading Src 0x1280, Dest FFFDA310, Length 40
.QSPI Reading Src 0x12C0, Dest FFFDA350, Length 40
.QSPI Reading Src 0x1300, Dest FFFDA390, Length 40
.Initialization Success
===== In Stage 3, Partition No:1 =====
UnEncrypted data Length: 0x444B
Data word offset: 0x444B
Total Data word length: 0x444B
Destination Load Address: 0xFFDC0000
Execution Address: 0xFFDC79AC
Data word offset: 0x76E0
Partition Attributes: 0x83E
.QSPI Reading Src 0x1DB80, Dest FFDC0000, Length 1112C
.Partition 1 Load Success
===== In Stage 3, Partition No:2 =====
UnEncrypted data Length: 0x100
Data word offset: 0x100
Total Data word length: 0x100
Destination Load Address: 0xFFDDF6E0
Execution Address: 0x0
Data word offset: 0xBB30
Partition Attributes: 0x83E
.QSPI Reading Src 0x2ECC0, Dest FFDDF6E0, Length 400
.Partition 2 Load Success

```

QSPI Boot Mode

Figure 5-24: Messages Appearing on UART-0 Terminal

The U-boot then loads Linux Kernel and other images on ARM Cortex A53 APU in SMP mode. The terminal messages indicate when U-boot loads Kernel image and the kernel start up to getting a user interface prompt in Linux Kernel. The Kernel loading and starting sequence can be seen in following figure.

9. Wait until Linux loads on the Board.

```

reading image.ub
75735640 bytes read in 4924 ms (14.7 MiB/s)
## Loading kernel from FIT Image at 10000000 ...
Using 'conf@1' configuration
Trying 'kernel@0' kernel subimage
Description: Linux Kernel
Type: Kernel Image
Compression: uncompressed
Data Start: 0x100000d8
Data Size: 13171200 Bytes = 12.6 MiB
Architecture: AArch64
OS: Linux
Load Address: 0x00080000
Entry Point: 0x00080000
Hash algo: sha1
Hash value: f095d304a568f560fbc4e83ddaa1600b6ceb7d8
Verifying Hash Integrity ... sha1+ OK
## Loading ramdisk from FIT Image at 10000000 ...
Using 'conf@1' configuration
Trying 'ramdisk@0' ramdisk subimage
Description: ramdisk
Type: RAMDisk Image
Compression: uncompressed
Data Start: 0x10c9a378
Data Size: 62520042 Bytes = 59.6 MiB
Architecture: AArch64
OS: Linux
Load Address: unavailable
Entry Point: unavailable
Hash algo: sha1
Hash value: 91828eaf9bd095cd965ecefa79f863f8dd90fda
Verifying Hash Integrity ... sha1+ OK
## Loading fdt from FIT Image at 10000000 ...
Using 'conf@1' configuration
Trying 'fdt@0' fdt subimage
Description: Flattened Device Tree blob
Type: Flat Device Tree
Compression: uncompressed
Data Start: 0x10c8fb0
Data Size: 42737 Bytes = 41.7 KiB
Architecture: AArch64
Hash algo: sha1
Hash value: fe11097c8fedecdee3e4bf31d27370e536896e85
Verifying Hash Integrity ... sha1+ OK
Booting using the fdt blob at 0x10c8fb0
Loading Kernel Image ... OK
Loading Ramdisk to 04460000, end 07ffffaea ... OK
Loading Device Tree to 000000000445f6f0 ... OK

Starting kernel ...

[    0.000000] Booting Linux on physical CPU 0x0

```

Figure 5-25: Kernel Loading and Starting Sequence

Boot Sequence for QSPI-Boot Mode Using JTAG

Zynq UltraScale+ MPSoC supports many ways to load the boot image. One way is using the JTAG interface. This example XSCT session demonstrates how to download a BOOT.image file in QSPI using the XSDB debugger. After the QSPI is loaded, the BOOT.bin image executes in the same way as QSPI Boot mode in Zynq UltraScale+. You can use the same XSCT session or the System Debugger for debugging similar Boot flows.

The following sections demonstrate the basic steps involved in this Boot mode.

Setting Up the Target

1. Connect a USB cable between the USB-JTAG J2 connector on the target and the USB port on the host machine.
2. Set the board to JTAG Boot mode by setting the **SW6** switch, as shown in the following figure.




Figure 5-26: SW6 Switch Settings for JTAG Boot Mode

3. Power on the Board using switch **SW1**.

Open the XSCT Console in SDK by clicking the XSCT button  . Alternatively, you can also open the XSCT console by selecting **Xilinx Tools > XSCT Console**.

4. In the XSCT console, connect to the target over JTAG using the `connect` command:

```
xsct% connect
```

The `connect` command returns the channel ID of the connection.


5. The `targets` command lists the available targets and allows you to select a target using its ID.

The targets are assigned IDs as they are discovered on the JTAG chain, so the IDs can change from session to session.

Note: For non-interactive usage such as scripting, you can use the `-filter` option to select a target instead of selecting the target using its ID.

```
xsct% targets
```

The targets are listed as shown in the following figure.



```
xsct% targets
 1 PS TAP
 2 PMU
 3 PL
 4 PSU
 5 RPU (Reset)
 6 Cortex-R5 #0 (RPU Reset)
 7 Cortex-R5 #1 (RPU Reset)
 8 APU (L2 Cache Reset)
 9 Cortex-A53 #0 (APU Reset)
10 Cortex-A53 #1 (APU Reset)
11 Cortex-A53 #2 (APU Reset)
12 Cortex-A53 #3 (APU Reset)

xsct%
```

Figure 5-27: XSCT Targets

Load U-boot Using XSCT/XSDB

1. Download the u-boot application on ARM A53 Core 0 using the following commands:

Disable Security gates to make PMU MB target visible to Debugger

```
xsct% targets -set -filter {name =~ "PSU"}
xsct% mwr 0xffca0038 0x1ff
xsct% targets
```

Verify if the PMU MB target is listed under the PMU device. Now, load and run PMUFW

```
xsct% targets -set -filter {name =~ "MicroBlaze PMU"}
xsct% dow {C:\edt\edt_zcu102\edt_zcu102.sdk\pmu_fw\Debug\pmu_fw.elf}
xsct% con
```

Now, reset APU Cortex A53 Core 0 to load and run FSBL

```
xsct% targets -set -filter {name =~ "Cortex-A53 #0"}
xsct% rst -processor
```



TIP: `rst -processor` clears the reset on an individual processor core.

This step is important, because when Zynq UltraScale+ boots up in JTAG bootmode, all the APU and RPU cores are held in reset. You must clear resets on each core before performing debugging on these cores. You can use the `rst` command in XSCT to clear the resets.

Note: `rst -cores` clears resets on all the processor cores in the group (such as APU or RPU) of which the current target is a child. For example, when A53 #0 is the current target, `rst -cores` clears resets on all the A53 cores in APU.

Load and run FSBL

```
xsct% dow {C:\edt\edt_zcu102\edt_zcu102.sdk\fsbl_a53\Debug\fsbl_a53.elf}
xsct% con
```


Verify FSBL messages on Serial Terminal and stop FSBL after couple of seconds

```
xsct% stop
```

Load and Run ATF and U-boot

```
xsct% dow {C:\edt\design_files\sd_boot\u-boot.elf}
xsct% dow {C:\edt\design_files\sd_boot\bl31.elf}
```

2. Configure a serial terminal (Tera Term, Mini com, or SDK Serial Terminal interface for UART-0 USB-serial connection).
3. For serial terminal settings, see [Figure 5-22](#).



```
xsct% dow {C:\edt_zcu102\u-boot.elf}
Downloading Program -- C:/edt_zcu102/u-boot.elf
    section, .data: 0x08000000 - 0x0806c70f
100%   0MB   0.1MB/s  00:03
Setting PC to Program Start Address 0x08000000
Successfully downloaded C:/edt_zcu102/u-boot.elf
xsct%
```

Figure 5-28: Verify the Image on the ZCU102 Board

4. Run u-boot, using the `con` command in XSDB.

```
xsct% con
```

5. In the target serial terminal, press any key to stop the U-boot auto boot.
6. Stop the core using the `stop` command in XSDB.

```
xsct% stop
```

Load Boot.bin in DDR Using XSDB

1. Download the Boot.bin binary into DDR on ZCU102. Use the same Boot.bin created for QSPI boot mode.

```
xsct% dow -data {C:\edt\qspi_BOOT.bin} 0x2000000
```

2. Now continue the U-boot again, using the `con` command in XSDB.

```
xsct% con
```

Load the Boot.bin Image in QSPI Using U-boot

1. Execute the following commands in the U-boot console on the target terminal. These commands erase QSPI and then write the Boot.bin image from DDR to QSPI.

```
U-Boot-Petalinux> sf probe 0 30000000 0
U-Boot-Petalinux> sf erase 0 0x4000000
U-Boot-Petalinux> sf write 0x2000000 0 0x4000000
```

2. After successfully writing the image to QSPI, turn off the board and set up the ZCU102 board as described in [Set Up the ZCU102 Board, page 80](#).

You can see Linux loading on the UART-0 terminal and the R5 application executing in the UART-1 terminal.

This chapter focused mostly on system boot and different components related to system boot. In the next chapter, you will focus on applications, Linux and Standalone (bare-metal) applications which will make use of PS peripherals, PL IPs, and processing power of APU Cores and RPU cores.

Boot Sequence for USB Boot Mode

Zynq Ultrascale+ MPSoC also supports USB Slave Boot Mode. This is using the USB DFU Device Firmware Upgrade (DFU) Device Class Specification of USB. Using a standard update utility such as [OpenMoko's DFU-Util](#), you will be able to load the newly created image on Zynq UltraScale+ via the USB Port. The following steps list the required configuration to load Boot images using this Boot mode. The DFU Utility is also shipped with Xilinx SDK and Petalinux.

Configure FSBL to Enable USB Boot Mode

There are few changes required in FSBL to enable USB Boot Mode. Considering that the FSBL project is used extensively throughout this tutorial, we will not be changing the existing FSBL project. For the same reason, this section will make use of new FSBL project.

Create First Stage Boot Loader for ARM Cortex A53-Based APU

1. In SDK, select **File > New > Application Project** to open the New Project wizard.
2. Use the information in the table below to make your selections in the wizard.

Table 5-1: Wizard Properties and Commands

Wizard Screen	System Properties	Setting or Command to Use
Application Project	Project Name	fsbl_usb_boot
	Use Default Location	Select this option
	Hardware Platform	edt_zcu102_wrapper_hw_platform_0
	Processor	psu_cortexa53_0
	OS Platform	Standalone
	Language	C
	Compiler	64-bit
	Hypervisor Guest	No
	Board Support package	Select Use Existing and select a53_bsp
Templates	Available Templates	Zynq MP FSBL

3. Click Finish.
4. In the Project Explorer tab, expand the fsbl_usb_boot project and open `xfsbl_config.h` from:

`FSBL_usb_boot > src > xfsbl_config.h`

5. In `xfsbl_config.h` change or set following settings:

```
#define FSBL_QSPI_EXCLUDE_VAL (1U)
#define FSBL_SD_EXCLUDE_VAL    (1U)
#define FSBL_USB_EXCLUDE_VAL   (0U)
```

6. Use **CTRL + S** to save these changes.
7. Re-build FSBL.

Creating Boot Images for USB Boot

In this section, you will create the Boot Images to be loaded, via USB using DFU utility. Device Firmware Upgrade (DFU) is intended to download and upload firmware to/from devices connected over USB. In this boot mode, the Boot loader (FSBL) and the PMUFW which are loaded by Boot ROM are copied to Zynq Ultrascale+ On Chip Memory (OCM) from Host Machine USB port using DFU Utility. Given the size limitation of the OCM, only FSBL and PMUFW are stitched into the first Boot .bin, which is copied to OCM. Rest of the Boot partitions will be stitched in another Boot image and copied to DDR to be loaded by

the FSBL which is already loaded and running at this stage. Follow the below steps to create Boot images for this boot mode.

1. In SDK, select **Xilinx Tools > Create Boot Image**.
2. Select `fsbl_usb_boot.elf` and `pmu_fw.elf` partitions and set them as shown in the following figure.




Figure 5-29: Create Boot Image for USB Boot

3. Ensure that PMU Partition is set to be loaded by BootROM.
4. Click on Create Image to generate `Boot.bin`.

The following steps describe how to create a `usb_boot.bin` comprising rest of the partitions.

Note: PetaLinux U-boot has to be modified to support the DFU_RAM command. See Xilinx Answer [69378](#) and follow steps 3 to 8, to modify and re-build PetaLinux U-boot, to generate `U-boot.elf` with DFU commands. Copy the newly generated U-boot to `C:\edt\usb-edt\`. The `u-boot.elf` is also available in [Design Files for This Tutorial](#).

1. In SDK, select **Xilinx Tools > Create Boot Image**.
2. Select FSBL and rest of the partitions and set them as shown in the following figure. For this you can also choose to import the BIF File from SD Boot Sequence.




Figure 5-30: Create Boot Image with Rest of the Partitions

3. Notice that PMUFW partition is not required in this image, as it will be loaded by the Boot ROM before this image (`usb_boot.bin`) is loaded.
4. Click on Create Image to generate `usb_boot.bin`.

Note: In addition to `BOOT.bin` and `usb_boot.bin`, the Linux image like `image.ub` is required to boot till Linux. This `image.ub` will be loaded by DFU utility separately.

Boot using USB Boot

In this section you will load the boot images on ZCU102 target using DFU utility. Before you start, set the board connections as shown below:

1. Set ZCU102 for USB Boot mode by setting SW6 (1-OFF, 2-OFF, 3-OFF, and 4-ON), as shown below:




Figure 5-31: SW6 Settings for USB Boot Mode

2. Connect a USB 3.0 Cable to J96 USB 3 ULPI Connector, and the other end of the Cable to USB port on Host Machine.
3. Connect a USB Micro cable between USB-UART port on Board (J83) and Host Machine.
4. Start a terminal session, using Tera Term or Minicom depending on the host machine being used, as well as the COM Port and baud rate for your system, as shown in [Figure 5-31](#).
5. Power ON the board.

The following steps will load the boot images via USB using DFU utility, which can be found in `SDK\2017.2\tps\lnx64\dfu-util-0.9`.

Alternatively you can also install DFU utility on Linux using Package Manager supported by Linux Distribution being used.

Boot Commands for Linux Host Machine

1. Check if the DFU can detect the USB target.

```
$ sudo dfu-util -l
```

The USB device should be enumerated with VendorId : ProductId which is 03fd:0050. You should see something like below:

```
Found DFU: [03fd:0050] ver=0100, devnum=30, cfg=1, intf=0, alt=0, name="Xilinx DFU Downloader", serial="2A49876D9CC1AA4"
```

Note: If you do not see the 'Found DFU' message, verify the connection and retry.

2. Now download the `BOOT.bin` that was created in [Creating Boot Images for USB Boot](#).

```
$ sudo dfu-util -d 03fd:0050 -D <USB_Boot_Image_Path>/Boot.bin
```

Verify from Serial Terminal if the FSBL is loaded successfully.

3. Now download the `usb_boot.bin`. Before this start another terminal session for UART-1 serial console.

```
$ sudo dfu-util -d 03fd:0050 -D <USB_Boot_Image_Path>/ usb_boot.bin
```

Check UART 0 terminal and wait until U-boot loads.

4. On U-boot prompt, type Enter to terminate autoboot. Verify from the UART1 console that the R5 application is also loaded successfully.
5. In U-boot console start `DFU_RAM` to enable downloading Linux Images

```
U-boot> run dfu_ram
```

6. Download Linux Image Image.ub using following Command from Host Machine Terminal:

```
$ sudo dfu-util -d 03fd:0300 -D <Petalinux_project>/images/linux/image.ub -a 0
```

7. Now execute CTRL+C on U-boot console to stop dfu_ram.
8. Run bootm command from U-boot Console.

U-boot> bootm

9. Verify that Linux loads successfully on the target

Note: In this example, image.ub is copied to DDR location based on #define DFU_ALT_INFO_RAM settings in U-boot configuration. The same can be modified to copy other image files to DDR location. Then, if required, these images can be copied to QSPI using u-boot commands listed in [Boot Sequence for QSPI-Boot Mode Using JTAG](#).

Boot Commands for Windows Host Machine

1. In SDK, Select **Xilinx Tools** -> **Launch Shell**.

2. In Shell, use Check if the DFU can detect the USB target

```
> dfu-util.exe -l
```

Note: dfu-util.exe can be found in
 <SDK_Installation_path>\SDK\2017.2\tps\Win64\dfu-util-0.9\dfu-util.exe

3. The USB device should be enumerated with VendorId : ProductId which is 03fd:0050

Note: If you do not see the message starting with "Found DFU", download and install "zadig" software. Open the software and click on options and select "List all devices". Select device "Xilinx Dfu Downloader" and click on Install driver tab.

4. Now download the Boot.bin that was created in [Creating Boot Images for USB Boot](#).

```
$ dfu-util.exe -d 03fd:0050 -D BOOT.bin
```

5. Verify from Serial Terminal (UART 0) that FSBL is loaded successfully.

6. Now download the usb_boot.bin. Before this start another terminal session for UART-1 serial console.

```
$ dfu-util.exe -d 03fd:0050 -D usb_boot.bin
```

7. On U-boot prompt type Enter to terminate auto-boot. Verify from UART1 console that the R5 application is also loaded successfully.

Note: At this point, use Zadig utility to install drivers for "Usb download gadget" with device ID 03fd:0300. Without this, zadig software does not show "Xilinx DFU Downloader" after booting u-boot on target.

8. In U-boot console start DFU_RAM to enable downloading Linux Images

U-boot> dfu_ram

9. Download Linux Image `image.ub` using following Command from Host Machine Terminal

```
$ dfu-util.exe -d 03fd:0050 -D image.ub -a 0
```

10. Run `bootm` command from U-boot Console.

```
U-boot> bootm
```

11. Verify that Linux loads successfully on the target.

Secure Boot Sequence

The secure boot functionality in Zynq UltraScale+ MPSoC allows you to support confidentiality, integrity, and authentication of partitions. Secure boot is accomplished by combining the Hardware Root of Trust (HROT) capabilities of the Zynq UltraScale+ device with the option of encrypting all boot partitions. The HROT is based on the RSA-4096 asymmetric algorithm in conjunction with SHA-3/384, which is hardware accelerated, or SHA-2/256, implemented as software. Confidentiality is provided using 256 bit Advanced Encryption Standard - Galois Counter Mode (AES-GCM). This section focuses on how to use and implement the following:

- Hardware Root of Trust with Key Revocation
- Partition Encryption with Differential Power Analysis (DPA) Countermeasures
- Black Key Storage using the Physically Unclonable Function (PUF)

The section [Secure Boot System Design Decisions](#) outlines high level secure boot decisions which should be made early in design development. The Hardware Root of Trust section discusses the use of a Root of Trust (Rot) in boot. The Boot Image Confidentiality section discusses methods to use AES encryption.

The [Enabling DPA Protections](#) section discusses the use of the operational key and key rolling techniques as countermeasures to a DPA attack. Changing the AES key reduces the exposure of both the key and the data protected by the key.

A red key is a key in unencrypted format. The [Black Key Storage](#) section provides a method for storing the AES key in encrypted, or black format. Black key store uses the physically unclonable function (PUF) as a Key Encryption Key (KEK).

The [Practical Methods in Secure Boot](#) section provides steps to develop and test systems that use AES encryption and RSA authentication.

Secure Boot System Design Decisions

The following are device level decisions affecting Secure Boot:

- Boot Mode
- AES Key Storage Location
- AES Storage State (encrypted or unencrypted)
- Encryption and Authentication requirements
- Key Provisioning

The boot modes which support secure boot are Quad Serial Peripheral Interface (QSPI), SD, eMMC, and NAND. The AES key is stored in either eFUSES (encrypted or unencrypted), Battery Backed Random Access Memory (BBRAM) (unencrypted only), or in external NVM (encrypted only).

In Zynq UltraScale+ MPSoC, partitions can be encrypted and/or authenticated on a partition basis. Xilinx generally recommends that all partitions be RSA authenticated. Partitions that are open source (U-Boot, Linux), or do not contain any proprietary or confidential information, typically do not need to be encrypted. In systems in which there are multiple sources/suppliers of sensitive data and/or proprietary IP, encrypting the partitions using unique keys may be important.

DPA resistance requirements are dictated by whether the adversary has physical access to the device.

[Table 5-2](#) can be a good reference while deciding on features required to meet a specific secure system requirement. Next sections will discuss the features in more detail.

Table 5-2: System Level Security Requirements

System Consideration/ Requirement	Zynq UltraScale+ Feature
Ensure that only the users SW and HW runs on the device	HWROT
Guarantee that the users SW and HW are not modified	HWROT
Ensure that an adversary cannot clone or reverse engineer SW/HW	Boot Image Confidentiality
Protect sensitive data and proprietary Intellectual Property (IP)	Boot Image Confidentiality
Ensure that Private Key (AES key) is protected against side channel attacks	DPA Protections
Private/Secret keys (AES key) is stored encrypted at rest	Black Key Storage

Hardware Root of Trust

Root of trusts are security primitives for storage (RTS), integrity (RTI), verification (RTV), measurement (RTM), and reporting (RTR). RoT consists of hardware, firmware, and software. The HROT has advantages over software RoTs because the HROT is immutable, has a smaller attack surface, and the behavior is more reliable.

The HROT is based on the CSU, eFUSES, BBRAM, and isolation elements. The HROT is responsible for validating that the operating environment and configuration have not been modified. The RoT acts as an anchor for boot, so an adversary can not insert malicious code before detection mechanisms start.

Firmware and software run on the HROT during boot. Zynq UltraScale provides immutable BootROM code, a first stage boot loader, device drivers, and the XILSKEY and XILSECURE libraries which run on the HROT. These provide a well-tested, proven in use API so that developers do not create security components from scratch with limited testing.

Data Integrity

Data integrity is the absence of corruption of hardware, firmware and software. Data integrity functions verify that an adversary has not tampered with the configuration and operating environment.

Zynq UltraScale+ verifies the integrity of partition(s) using both symmetric key (AES-GCM) and asymmetric key (RSA) authentication. RSA uses a private/public key pair. The fielded embedded system only has the public key. Theft of the public key is of limited value since it is not possible, with current technology, to derive the private key from the public key. Encrypted partitions are also authenticated using the Galois Counter Mode (GCM) mode of AES.

The flow in secure boot is first authenticated and then decrypted.

Authentication

Figure 5-32 shows RSA signing and verification of partitions. From a secure facility, the SDK Bootgen tool signs partitions, using the private key. In the device, the ROM verifies the FSBL and either the FSBL or U-Boot verifies the subsequent partitions, using the public key. Primary and secondary private/public key pairs are used. The function of the primary private/public key pair is to authenticate the secondary private/public key pair. The function of the secondary key is to sign/verify partitions.




Figure 5-32: Zynq UltraScale+ RSA Authentication

To sign a partition, Bootgen first calculates the SHA3 of the partition data. The 384 bit hash is then RSA signed using the private key. The resulting RSA signature is placed in the authentication certificate. In the image, each signed partition has partition data followed by an authentication certificate which includes the RSA signature.

Verification of the FSBL is handled by the CSU ROM code. To verify the subsequent partitions, the FSBL or U-Boot uses the XILSECURE library.

Boot Image Confidentiality and DPA

AES is used to ensure confidentiality of sensitive data and IP. Zynq UltraScale+ uses AES Galois Counter Mode (GCM). Zynq UltraScale+ uses a 256 AES bit key. The principle AES enhancements provided by Zynq UltraScale+ are increased resistance to Differential Power Analysis (DPA) attacks and the availability of AES encryption/decryption post boot.

Bootgen and FSBL software support AES encryption. Private keys are used in AES encryption, and AES encryption is done by Bootgen using key file. The key file can be generated by Bootgen or OpenSSL. In addition to this, the operational key is included in the boot header. The use of the operational key limits the exposure of the device key. The use of the operational key in key rolling is discussed in the next section. To maintain Boot image confidentiality, Encrypted Boot images can be created using Bootgen. Software examples to program keys to BBRAM and eFUSE are also available in Xilinx SDK. One such example is discussed in [Practical Methods in Secure Boot](#).

DPA Protections

Key rolling is used for DPA resistance. Key rolling and black key store can be used in the same design. In key rolling, software and bitstream is broken up into multiple data blocks, each encrypted with a unique AES key. The initial key is stored in BBRAM or eFUSE NVM. Keys for successive data blocks are encrypted in the previous data block. After the initial key, the key update register is used as the key source.

A 96 bit initialization vector is included in the NKY key file. The IV uses 96 bits to initialize AES counters. When key rolling is used, a 128 bit IV is provided in the booheader. The 32 least significant bits define the block size of data to decrypt using the current key. The block sizes following the initial block defined in the IV are defined as attributes in the Bootgen Image Format (BIF) file.

An efficient method of key rolling uses the operational key. With the operational key, Bootgen creates an encrypted secure header with the user specified operational key and the first block IV. The AES key in eFUSE or BBRAM is used only to decrypt the 384 bit secure header with the 256 bit operational key. This limits the exposure of the device key to DPA attacks.

Black Key Storage

The PUF enables storing the AES key in encrypted (black) format. The black key can be stored either in eFUSES or in the booheader. When needed for decryption, the encrypted key in eFUSES or the booheader is decrypted using the PUF generated key encrypting key (KEK).

There are two steps in using the PUF for black key storage. In the first, PUF registration software is used to generate PUF helper data and the PUF KEK. The PUF registration data allows the PUF to re-generate the identical key each time the PUF generates the KEK. For more details on the use of PUF registration software, see [PUF Registration - Boot Header Mode](#). For more information on PUF Registration - eFUSE mode, see *Programming BBRAM and eFUSES* (XAPP1319) [\[Ref 13\]](#).

The helper data and encrypted user key must both be stored in eFUSES if the PUF eFUSE mode is used, and in the booheader if the PUF Booheader mode is used. The procedure for the PUF booheader mode is discussed in [Using PUF in Booheader Mode](#). For the procedure to use PUF in eFUSE mode, see *Programming BBRAM and eFUSES* (XAPP1319) [\[Ref 13\]](#).

Practical Methods in Secure Boot

This section outlines the steps to develop secure boot in a Zynq UltraScale+ system. Producing a secure embedded system is a two-step process. In the first phase, the cryptographic keys are generated and programmed into NVM. In the second phase, the secure system is developed and tested. Both steps use the Xilinx Software Design Kit (SDK) to create software projects, generate the image, and program the image. For the second phase, a test system can be as simple as `fsbl.elf` and `hello.elf` files. In this section, you will use the same images used in [Boot Sequence for SD-Boot](#), but this time the images will have secure attributes enabled as a part of the secure boot sequence.

This section starts by showing how to generate AES and RSA keys. Following key generation, systems using the advanced AES and RSA methods are developed and tested. Keys generated in this section are also included in the [Design Files for This Tutorial](#), released with this tutorial.

The methods used to develop AES functionality are provided in the following sections:

- AES key in BBRAM
- Key Rolling
- Operational Key
- AES key in eFUSE
- Physically Unclonable Function Use

The RSA section provides the steps to authenticate all partitions loaded at boot. The RSA section also shows how to revoke keys.

A requirement in the development of a secure system is to add security attributes which are used in image generation. SDK's Bootgen generates a Boot Image Format (BIF) file. The BIF file is a text file. In its simplest form, the BIF is a list of partitions to be loaded at boot. Security attributes are added to the BIF to specify cryptographic functionality. In most cases, the Bootgen GUI (Create Boot Image wizard) is used to generate the BIF file. In some cases, adding security attributes requires editing the Bootgen generated BIF file. In Create Boot Image Wizard in Xilinx SDK, after the Security tab is selected, the Authentication and Encryption tabs are used to specify security attributes.

After implementing AES and RSA cryptography in secure boot, a Boot test is done. The system loads successfully and displays the FSBL messages on the terminal. The FSBL debug messages indicate the cryptographic operations performed on each partition. [Appendix A, Debugging Problems with Secure Boot](#) provides steps that are required to use, if the secure boot test fails.

Generating Keys

This section describes the process of creating an AES key and key pairs that are used for authenticating secure partitions.

Creating an AES Key

The following steps describe the process of creating an AES Key:

1. Use a text editor to create `generate_aes_key.bif` with the following contents:

`generate_aes_key:`

```
{
    [aeskeyfile] c:\edt\secureboot_sd\bbram.nky
    [bootloader, encryption=aes]
    C:\edt\edt_zcu102\edt_zcu102.sdk\fsbl_a53\Debug\fsbl_a53.elf
}
```

2. Save the `generate_aes_key.bif` file in `c:\edt\secureboot_sd`.

3. Select **Xilinx Tools > Launch Shell.**

4. From c:\edt\secureboot_sd\ run

```
bootgen -image generate_aes_key.bif -w -o test.bin -arch zynqmp -encrypt bbram -p xczu9eg
```

5. Verify that the AES key bbram.nky is generated.

Note: The key file for AES encryption can be generated using external tools like OpenSSL.

Alternatively, you can also generate the nky key while creating the boot image in Xilinx SDK. While creating the boot image, set the path for the nky file and the device part name. The *.nky file will be created at the same path, provided *.nky file with same name does not exist already.

Creating RSA Private/Public Key Pairs

For this example, you will create the Primary and Secondary keys in the PEM format. The keys are generated using Bootgen command-line options. Alternately, you can create the keys using external tools like OpenSSL.

The following steps describe the process of creating the RSA Private/Public Key Pairs:

1. Launch the shell for SDK.

2. Select **Xilinx Tools > Launch Shell.**

3. Create a file named generate_pem.bif with the following content:

```
generate_pem:
{
    [pskfile]C:\edt\secureboot_sd\keys\psk0.pem
    [sskfile]C:\edt\secureboot_sd\keys\ssk0.pem
}
```

This file indicates the location where the Primary and Secondary PEM keys are to be created.

Note: Ensure that *.PEM files are not present in the provided location, in order for the PEM keys to be created. The FSBL partition in this BIF file is only to have a partition present in the BIF file. The FSBL has no effect on generation of PEM files.

4. Save the generate_pem.bif file in C:\edt\secureboot_sd\keys.

5. Navigate to the folder containing the bif file.

```
cd C:\edt\secureboot_sd\keys
```

6. Run the following Bootgen command to generate the keys:

```
bootgen -generate_keys auth pem -arch zynqmp -image generate_pem.bif
```

Note: Do not consider the warning about missing partitions.

7. Verify that the keys are generated at the location stated in the BIF file:

```
C:\edt\secureboot_sd\keys
```

The Authentication Keys are generated. This can also be created using OpenSSL or used from HSM.

Generate SHA3 of Public Key in RSA Private/Public Key Pair

The following steps are required only for RSA Authentication with eFUSE mode, and can be skipped for RSA authentication with Bootheader mode. The 384 bits from sha3.txt can be programmed to eFUSE for RSA Authentication with the eFUSE Mode. For more information, see *Programming BBRAM and eFUSES* (XAPP1319)[\[Ref 13\]](#).

Use Bootgen to calculate the hash of the primary public key (PPK), as follows:

1. Use a text editor to create the generate_hash_ppk.bif file in C:\edt\secureboot_sd\keys\ as shown below.

```
generate_hash_ppk:
{
[pskfile] C:\edt\secureboot_sd\keys\psk0.pem
[sskfile] C:\edt\secureboot_sd\keys\ssk0.pem
[bootloader, destination_cpu=a53-0, authentication=rsa]
C:\edt\edt_zcu102\edt_zcu102.sdk\fsbl_a53\Debug\fsbl_a53.elf
}
```

2. Save the generate_hash_ppk.bif file in C:\edt\secureboot_sd\keys.
3. Use the bootgen command to calculate the hash of the PPK:

```
bootgen -image generate_hash_ppk.bif -arch zynqmp -w -o test.bin -efuseppkbts
sha3.txt
```

4. Open sha3.txt in a text editor and verify that the sha3.txt file contains 384 bits:

Additional RSA Private/Public Key Pair

This section shows steps to generate Secondary RSA Private/Public key pair required for Key Revocation, which requires programming of eFUSE. For more information, see *Programming BBRAM and eFUSES* (XAPP1319)[\[Ref 13\]](#). You can skip this section if you do not intend to use Key Revocation.

Repeat steps from Create RSA Private/Public Key Pairs and Generate SHA3 of Public Key in RSA Private/Public Key Pair to generate the second RSA private/public key pair and generate the SHA3 of the second PPK.

1. Change the 0 appendix to 1 in generate_pem1.bif in C:\edt\secureboot_sd\keys. The generate_pem1.bif will look like:

```
generate_pem:
{
[pskfile] C:\edt\secureboot_sd\keys\psk1.pem
[sskfile] C:\edt\secureboot_sd\keys\ssk1.pem
}
```

2. Re-run the Bootgen command in Create RSA Private/Public Key Pairs to generate the keys.

```
bootgen -generate_keys auth pem -arch zynqmp -image generate_pem1.bif
```

3. Change the 0 appendix to 1 in generate_hash_ppk.bif, which will now look like:

```
generate_hash_ppk:
{
    [pskfile] C:\edt\secureboot_sd\keys\psk1.pem
    [sskfile] C:\edt\secureboot_sd\keys\ssk1.pem
    [bootloader, destination_cpu=a53-0, authentication=rsa]
C:\edt\edt_zcu102\edt_zcu102.sdk\fsbl_a53\Debug\fsbl_a53.elf
}
```

4. Re-run the Bootgen command in Generate SHA3 of Public Key in RSA Private/Public Key Pair to generate the SHA3 of PPK 1. Notice the change, that is the sha3_1.txt in the following command:

```
bootgen -image generate_hash_ppk.bif -arch zynqmp -w -o test.bin -efuseppkbts
sha3_1.txt
```

Enabling Image Confidentiality

Image confidentiality is discussed in [Boot Image Confidentiality and DPA](#) section. In this section you will create Boot Images with Boot Image Confidentiality enabled using AES Encryption.

Using AES Encryption

In this section, different methods of using AES are demonstrated. The different methods are defined in part by the key source used.

Encryption Using the AES Key in BBRAM is as follows:

1. If SDK is not open, open it and select **Xilinx Tools -> Create Boot Image**.
2. Select **Zynq MP Architecture** and click on **Create new BIF File**.
3. In Basic Tab, Set Output BIF file Path to
C:\edt\secureboot_sd\aes\aes_encrypt_boot.bif




Figure 5-33: BIF Settings

4. Click the Security tab ' Click the Encryption tab ' and check Use Encryption.
5. In the **Key Store** drop-down, select **BBRAM RED**
6. In the Key File dialog box, browse to select c:\edt\secureboot_sd\bbbram.nky .




Figure 5-34: Encryption Settings

Note: The Part name field is grayed out because bbram.nky key exists at given location (created in Generating Keys section). The Key can also be created using GUI mode, wherein SDK generates the key, if it is missing at the set location. For this you will need to enter the Device ID, for example xzcu9eg in this case.

7. Next, add the FSBL Partition,
 - a. Click **Add** to open the Add Partition dialog box.
 - b. In the Add Partition dialog box, click **Browse** to select the FSBL executable.
 - c. For FSBL, ensure that the partition type is selected as bootloader and the correct destination CPU is selected by the tool. The tool is configured to make these selections based on the FSBL executable.
8. Set AES Encryption, click **OK**.




Figure 5-35: Add Boot Image Partition with AES Encryption Enabled

- Add the rest of the partitions as described in [Boot Sequence for SD-Boot](#). The difference this time is that you need to set the AES encryption for all the partitions, except U-boot.

Finally, verify that you have added all the partitions listed below, and that AES is set for all partitions. Ensure that you have set correct Exception Levels for ATF (EL-3, Trustzone) and U-boot (EL-2) Partitions. The final settings are shown in the following figure.




Figure 5-36: Create Boot Image with Encryption Enabled

The encryption and authentication for PMU is blurred as this setting has no effect, when PMU firmware is loaded by the Boot ROM. In this case (PMU loaded by BootROM), the bootloader (FSBL) settings are applicable by default for PMU Firmware.

10. Click **Create Image**.

11. Click **OK** to generate **BOOT.BIN**.

Follow the below steps to program the AES Key in BBRAM:

Before you run the boot image, load the Encryption key **bbram.nky**, that you created in Set Encryption settings, into BBRAM. The following section describes how to create an application to burn the user key to BBRAM. This key is used by the AES engine to decrypt the encrypted images.

In SDK, modify **a53_bsp** to include the LibXil SKey library, as follows:

1. Right click on **a53_bsp > Board Support Package Settings**.
2. Enable the Xilinx secure key library (**xilskey**) as shown in the following figure.




Figure 5-37: Enable LibXil SKey in the BSP

3. Click **OK** to save the settings and close the BSP Settings window.
4. In the Project Explorer, expand **a53_bsp** and double-click **system.mss**.




Figure 5-38: Open BSP System.mss File

5. Scroll down to the libraries section in the system.mss file and click **Import Examples** for the xilskey 6.2 library.




Figure 5-39: Import LibXil SKey Example Application

6. Select xilskey_bbramps_zynqmp_example.
7. Click **OK** to select this example, and exit out of the Examples for xilskey dialog box.

You will now see that the new application, a53_bsp_xilskey_bbramps_zynqmp_example_1, is added in the Project Explorer window.

8. For easy reference, right-click on this application and rename it bbram_app.
9. Open xilskey_bbramps_zynqmp_example.c.
10. Set XSK_ZYNQMP_BBRAMPS_AES_KEY (the 256 bit key). The key is to be entered in HEX format and should be the same key from the bbram.nky file that you generated in [Creating an AES Key](#).

You can find a sample key below:

68D58595279ED1481C674383583C1D98DA816202A57E7FE4F67859CB069CD510

Note: Do not copy this key. Refer to the bbram.nky file for your key.

Next, you will create a boot image to program the key in BBRAM.

1. Select **Xilinx_Tools > Create Boot Image**.

2. Create a Boot image with the settings shown in following figure.
3. Add FSBL and bbram_app.elf (destination CPU=A53) partitions to the Boot image, as shown in following figure.




Figure 5-40: Load BBRAM Boot Image

Run this BOOT.BIN on ZCU102 to Load the Key in BBRAM:

1. Copy BOOT.bin to an SD card.
2. Load the SD card into the ZCU102 board, in the J100 connector.
3. Connect the USB-UART on the Board to the Host machine.
4. Connect the Micro USB cable into the ZCU102 Board Micro USB port J83, and the other end into an open USB port on the host Machine.
5. Configure the Board to Boot in SD-Boot mode by setting switch SW6 as shown in [Figure 5-7](#).

6. Connect 12V Power to the ZCU102 6-Pin Molex connector.
7. Start a terminal session, using Tera Term or Minicom depending on the host machine being used, as well as the COM Port and baud rate for your system, as shown in [Figure 5-8](#).
8. For port settings, verify the COM Port in the device manager.
9. There are four USB-UART interfaces exposed by the ZCU102 Board.
10. Select the COM Port associated with the interface with the lowest number. In this case, for UART-0, select the com-port with interface-0.
11. Turn on the ZCU102 Board using SW1 and notice the messages on the terminal.




Figure 5-41: BBRAM App on ZCU102

12. Ideally, the application will exit with status 00000000; if not, there was some error in programming.

Follow the below steps to run the image using AES Encryption:

1. Copy the encryption enabled boot image created by Boot.bin to an SD card. The image is in C:\edt\secureboot_sd\aes\Boot.bin.
2. For this example, you can use the same image.ub file that was used in [Running the Image on the ZCU102 Board](#). Copy image.ub to an SD card.
3. Load the SD card into the SD card slot in the Board.
4. Repeat the rest of the steps as stated in [Running the Image on the ZCU102 Board](#), and verify that the image loads on the target.
5. Compare the FSBL Logs for Non-secure SD Boot sequence and Encryption enabled Boot Sequence. Verify if the partitions are used in all the partitions loaded.

For more details, see this [link](#) in the *Zynq UltraScale+ MPSoC Technical Reference Manual* (UG1085) [\[Ref 5\]](#) and "Boot Time Security" in the *Zynq UltraScale+ MPSoC: Software Developers Guide* (UG1137) [\[Ref 6\]](#).

Enabling DPA Protections

This section provides the steps to use an operational key and key rolling effective counter measures, against the differential power analysis.

Create an Operational Key

Follow the below steps to generate a new key (`operational.nky`) at the following location:

`C:\edt\secureboot_sd\aes_opt\operational.nky`

1. Use a text editor to create `generate_opt_key.bif` with the following contents:

```
generate_opt_key:
{
    [aeskeyfile]C:\edt\secureboot_sd\aes_opt\operational.nky
    [keysrc_encryption]bbram_red_key
    [fsbl_config]opt_key
    [bootloader, destination_cpu=a53-0, encryption =
aes]C:\edt\edt_zcu102\edt_zcu102.sdk\fsbl_a53\Debug\fsbl_a53.elf
}
```

2. Save the `generate_opt_key.bif` file at following location:

`C:\edt\secureboot_sd\aes_opt\`

3. Select Xilinx Tools > Launch Shell.

4. From `C:\edt\secureboot_sd\aes_opt\ run`

```
bootgen -image generate_opt_key.bif -arch zynqmp -w -o test.bin -encrypt bbram -p
xczu9eg
```

5. Verify that the Operational key `operational.nky` is generated.

6. Open `operational.nky` and replace Key 0 with Key 0 from `bbram.nky` generated earlier.

Note: This example uses step 6 only to avoid reprogramming the BBRAM with new key. For actual development/production flow, you can chose to the `operational.nky` key (created in step 1) or use external tools, and program the key 0 from same to BBRAM/eFUSE.

Encryption Using the Operational Key

1. In SDK, select **Xilinx Tools > Create Boot Image**.
2. Select **Zynq MP Architecture** and click on **Import from existing BIF File**.
3. In the Basic Tab
 - a. Set Import BIF file path to `C:\edt\secureboot_sd\aes\aes_encrypt_boot.bif`
 - b. Set Output BIF file Path to `C:\edt\secureboot_sd\aes_opt\aes_operational.bif`
4. Click **Security tab > Encryption tab > check Optional Key**.
5. In the **Key Store** drop-down, select **BBRAM RED**

6. In the Key File dialog box, browse to select
C:\edt\secureboot_sd\aes_opt\operational.nky
7. Click **Create Image** to create a Boot Image using Operational Key.
8. Test this image on Board by repeating steps from [Follow the below steps to run the image using AES Encryption:](#), and verify that Target boots successfully to load Linux OS and the RPU applications.

Encryption Using Key Rolling

1. In SDK, select **Xilinx Tools > Create Boot Image**.
2. Select **Zynq MP Architecture** and click on Import from existing BIF File.
3. In the Basic Tab:
 - a. Set Import BIF file path to **C:\edt\secureboot_sd\aes\aes_encrypt_boot.bif**
 - b. Set Output BIF file Path to **C:\edt\secureboot_sd\aes_keyrolling\aes_keyrolling.bif**
4. Click **Create Image** to generate Boot.Bin image. Manually edit **aes_keyrolling.bif** to add the block attribute for each partition:
blocks=4096;4096;1024;8196
5. Modify the contents of the **aes_encrypt_keyrolling.bif** file to resemble the following:

```
//arch = zynqmp; split = false; format = BIN; key_part_name = xcuz9eg
the_ROM_image:
{
  [aeskeyfile]C:\edt\secureboot_sd\aes_keyrolling\multiple_keys.nky
  [keysrce_encryption]bbram_red_key
  [fsbl_config]opt_key
  [bootloader, destination_cpu=a53-0, encryption =
aes,blocks=4096;4096;1024;8196]C:\edt\edt_zcu102\edt_zcu102.sdk\fsbl_a53\Debug\fsbl
_a53.elf
  [pmufw_image]C:\edt\edt_zcu102\edt_zcu102.sdk\pmu_fw\Debug\pmu_fw.elf
  [encryption = aes, destination_cpu =
a53-0,blocks=4096;4096;1024;8196,exception_level = el-3,
trustzone]C:\edt\design_files\sd_boot\bl31.elf
  [encryption = aes, destination_cpu =
r5-lockstep,blocks=4096;4096;1024;8196]C:\edt\edt_zcu102\edt_zcu102.sdk\testapp_r5\
Debug\testapp_r5.elf
  [destination_cpu = a53-0, exception_level =
el-2]C:\edt\design_files\sd_boot\u-boot.elf
}
```

6. Save and close the BIF file.
7. Using a text editor, create **multiple_keys.nky**, with multiple 256 bit keys and initialization vectors as shown below. If the number of keys in **multiple_keys.nky** exceeds the number of blocks in the BIF, the extra keys are ignored. If the number of keys in **multiple_keys.nky** are less than the number of blocks, the last key in **multiple_keys.nky** is used for all remaining blocks.

Like in earlier section, ensure that the **key 0** (and IV 0) in `multiple_keys.nky` is same as the **key 0** (and IV) in `bbram.nky` (essentially the same key that was programmed in BBRAM).

```
Device xczu9eg;
Key 0 68D58595279ED1481C674383583C1D98DA816202A57E7FE4F67859CB069CD510;
Key 1 CA4079947071A044D1179111DE1BD6274CAE61A3D9D0490A6928BA69E4DCD5A0;
IV 0 E1757A6E6DD1CC9F733BED31;
IV 1 945435B80C7CA66A912BDB68;
Key Opt      FC8C285364D4C82D7E164C6196FBB6CFF8C673DBEB38AF15E9932492D96DF962;
```



```
multiple_keys.nky
Device xczu9eg;
Key 0 68D58595279ED1481C674383583C1D98DA816202A57E7FE4F67859CB069CD510;
Key 1 CA4079947071A044D1179111DE1BD6274CAE61A3D9D0490A6928BA69E4DCD5A0;
IV 0 E1757A6E6DD1CC9F733BED31;
IV 1 945435B80C7CA66A912BDB68;
Key Opt      FC8C285364D4C82D7E164C6196FBB6CFF8C673DBEB38AF15E9932492D96DF962;
```

Figure 5-42: Multiple Keys File

8. In SDK, select **Xilinx Tools > Create Boot Image**.
9. Select **Import** from the existing BIF File option.
10. Select the modified `aes_keyrolling.bif` file.
11. Click **Create Image** to close the wizard and create the boot image.
12. Test this image on Board by repeating steps from [Follow the below steps to run the image using AES Encryption:](#), and verify that Target boots successfully to load Linux OS and the RPU applications.

As stated earlier, the AES Keys can also be programmed to eFUSE. Similar to what we saw for programming AES key in BBRAM, SDK provides an application example for programming eFUSE. This example will not program the eFUSE keys as this is more permanent.

Using Hardware Root of Trust (HROT)

Using RSA Authentication

The two RSA authentication modes supported by Zynq UltraScale+ are Booheader mode and eFUSE mode. This example will focus on the RSA Authentication using Booheader mode. In this section, RSA authentication is done on each of the partitions loaded, first using the primary public key programmed into the Boot Header.

Follow the below steps to use the Hash of the PPK in the Boot Header:

1. Open SDK if not open, and select **Xilinx Tools -> Create Boot Image**.
2. Select **Architecture -> Zynq MP**.
3. Click on the **Create new BIF File** radio button, open and add path for the BIF File.
`C:\edt\secureboot_sd\rsa_auth\rsa_auth_boot_bh.bif`
4. Click the **Security tab**.

5. Click the **Authentication tab**.
6. The GUI provides the user the option to use either Public Keys or Private Keys. The Public Key dialog box is on the left. The Private Key dialog box is on the right. The Public Key is used when there is an independent Hardware Security Module (HSM) used to handle the keys. This key management method can protect against an insider attack.
7. Browse to C:\edt\secureboot_sd\keys and add psk0.pem and ssk0.pem as shown



Figure 5-43: Add RSA Key Pairs

8. Check the **Use BH Auth** box.
9. Add the partitions as described in [Boot Sequence for SD-Boot](#). The difference this time is that you need to set the RSA authentication for all the partitions.
10. Verify that the Bootgen GUI has the content shown below:




Figure 5-44: Boot Image Partitions - RSA Authentication

11. Click **Create Image**.
12. Insert the SD card into the PC and copy BOOT.BIN and image.ub to the SD card.

13. Move the SD card to the IO Carrier Card SD card slot on ZCU102 Target.
14. Power up the board.
15. Review the FSBL log file to verify that authentication is done, and verify that U-boot/Linux Images load.

Note: The above steps employ the Boot Header based Authentication, which can be used in a development flow. The RSA Authentication with eFUSE mode is advisable for Production targets. For RSA Authentication with eFUSE mode, uncheck the Use BH Auth box while creating Boot image, and program the eFUSE (which can be programmed only once) using the SDK application example to program eFUSE. RSA Authentication with eFUSE mode is not covered in this tutorial.

Using Key Revocation

Key revocation allows a user to revoke a RSA primary or secondary public key. Key revocation may be used due to elapsed time of key use or if there is an indication that the key is compromised. The primary and secondary key revocation is controlled by one time programmable eFUSES. The Xilinx Secure Key Library is used for key revocation, allowing key revocation in fielded devices. Key revocation is discussed further in *Zynq UltraScale+ MPSoC Technical Reference Manual (UG1085)* [Ref 5].

Using the PUF

In this section, the PUF is used for black key storage in the PUF Bootheader mode. RSA authentication is required when the PUF is used. This section shows how to create a BIF for using the PUF. It starts with creating the baseline BIF `puf_0.bif`, similar to the `bh_auth.bif`, discussed in [Using RSA Authentication](#) section. The `puf_0.bif` is edited using a text editor to generate `puf_bh.bif`.

PUF Registration - Boot Header Mode

The PUF registration software is included in the XILSKEY library. The PUF registration software operates in a Bootheader mode or eFUSE mode. The Bootheader mode allows development without programming the OTP eFUSES. The eFUSE mode is used in production. This lab runs through PUF registration in Bootheader Mode only. For PUF registration using eFUSE, see *Programming BBRAM and eFUSES (XAPP1319)*[Ref 13].

The PUF registration software accepts a red (unencrypted) key as input, and produces syndrome data (helper data), which also contains CHASH and AUX, and a black (encrypted) key. When the PUF Bootheader mode is used, the output is put in the bootheader. When the PUF eFUSE mode is used, the output is programmed into eFUSES.

1. In SDK, right click on **a53_bsp** and click on Board Support Package Settings
2. Ensure that `xilskey` and the `xilsecure` libraries are enabled.




Figure 5-45: Select Xilskey and Xilsecure Libraries

3. Click **OK**. Now open **a53_bsp > system.mss**.
4. Scroll to the Libraries section. Double click on **xilskey 6.2 Import Examples**.
5. In the dialog box, select the **xilskey_puf_registration** example. Click **OK**.




Figure 5-46: Import PUF Registration Example

6. In Project Explorer, right click **a53_bsp_xilskey_puf_registration_1**. Click **Rename** and rename to **puf_registration** and click **OK**.




Figure 5-47: Rename PUF Registration Project

7. In Project Explorer, Puf_registration App 'Src' double click xilskey_puf_registration.h to open in SDK.
8. Edit xilskey_puf_registration.h as follows:
 - a. Change #define XSK_PUF_INFO_ON_UART from FALSE to TRUE
 - b. Ensure that #define XSK_PUF_PROGRAM_EFUSE is set to FALSE
 - c. Set XSK_PUF_AES_KEY (the 256 bit key).

The key is to be entered in HEX format and should be the same key from the bbram.nky file that you generated in Create an AES Link. You can find a sample key below:

```
#define XSK_PUF_AES_KEY
"68D58595279ED1481C674383583C1D98DA816202A57E7FE4F67859CB069CD510"
```

Note: Do not copy this key. Refer to the bbram.nky file for your key.

- d. Set the XSK_PUF_IV. The initialization vector IV is a 12 byte data of user choice.

```
#define XSK_PUF_IV "E1757A6E6DD1CC9F733BED31"
```

```

149
150 #define XSK_PUF_INFO_ON_UART      TRUE
151 #define XSK_PUF_PROGRAM_EFUSE    FALSE
152 #define XSK_PUF_IF_CONTRACT_MANUFATURER FALSE
153
154 /* For programming/reading secure bits of PUF */
155 #define XSK_PUF_READ_SECUREBITS   FALSE
156 #define XSK_PUF_PROGRAM_SECUREBITS FALSE
157
158 #if (XSK_PUF_PROGRAM_SECUREBITS == TRUE)
159 #define XSK_PUF_SYN_INVALID     FALSE
160 #define XSK_PUF_SYN_WRLK        FALSE
161 #define XSK_PUF_REGISTER_DISABLE FALSE
162 #define XSK_PUF_RESERVED        FALSE
163 #endif
164
165 #define XSK_PUF_AES_KEY         "CA4079947071A044D1179111DE1BD6274CAE61A3D9D0490A6928BA69E4DCD5A0"
166 #define XSK_PUF_IV              "945435B80C7CA66A912BDB68"
167

```

Figure 5-48: PUF Registration in Bootheader Mode

9. Save the file and exit.
10. In Project Explorer, right click on the **puf_registration project** and select **Build Project**

11. In SDK, select **Xilinx Tools -> Create Boot Image.**

12. Select Zynq MP in the Architecture dialog box.

13. In the Output BIF file path: dialog box, specify

C:\edt\secureboot_sd\puf_registration\puf_registration.bif

14. In the Output Path dialog box, specify

C:\edt\secureboot_sd\puf_registration\BOOT.bin

15. In the Boot Image Partitions pane, click Add. Add the partitions:

C:\edt\edt_zcu102\edt_zcu102.sdk\fsbl_a53\Debug\fsbl_a53.elf

C:\edt\edt_zcu102\edt_zcu102.sdk\puf_registration\Debug\puf_registration.elf

16. Click on **Create Image** to create the Boot Image for PUF registration




Figure 5-49: PUF Registration Software

17. Insert a SD card into the PC SD card slot.

18. Copy C:\edt\secureboot_sd\puf_registration\BOOT.bin to the SD Card

19. Move the SD card from the PC SD card slot to the ZCU102 card slot.

20. Start a terminal session, using Tera Term or Minicom depending on the host machine being used, as well as the COM Port and baud rate for your system, as shown in [Figure 3-12](#).

21. In the communication terminal menu bar, select **File -> Log**. Enter

C:\edt\secureboot_sd\puf_registration\puf_registration.log in the dialog box.

22. Power cycle the board.

23. After the puf_registration software has run, exit the communication terminal.
24. The `puf_registration.log` content is used in [Using PUF in Bootheader Mode](#). Open `puf_registration.log` in a text editor.
25. Save the PUF Syndrome data that starts after App PUF Syndrome data Start!!!; and ends at PUF Syndrome data End!!!, non-inclusive, to a file named `helperdata.txt`.
26. Save the black key IV identified by App: Black Key IV - to a file named `black_iv.txt`.
27. Save the black key to a file named `black_key.txt`.
28. The files `helperdata.txt` and `black_iv.txt` can be saved in
`C:\edt\secureboot_sd\aes_puf\`

Using PUF in Bootheader Mode

Follow the below steps to create a Boot image for AES Encryption using PUF. This section will make use of the Syndrome data and Black Key created during PUF registration process.

1. In PUF Registration - Boot Header Mode, a text file with the syndrome data and black key is generated in `C:\edt\secureboot_sd\aes_puf` directory.
2. In SDK, select **Xilinx Tools** -> **Create Boot Image**.
3. Click on the **Create new BIF file** and set the Output BIF File Path as `aes_using_puf.bif`
4. Select the **Security tab**.
5. Select **Encryption** and then select **Authentication**.
6. Add the partitions as described in [Boot Sequence for SD-Boot](#). The difference this time is that you need to set the RSA authentication for all partitions, and the AES encryption for all the partitions except U-boot.
7. Provide inputs such that the Create Boot Image has the following content:




Figure 5-50: Boot Image Partitions




Figure 5-51: Authentication and RSA Key Pairs




Figure 5-52: Encryption Settings

8. Ignore the Key Store source for Encryption. This will be changed in next few steps.
9. Click **Create Image**.
10. Use a text editor to edit `aes_using_puf.bif`. Use the PUF with syndrome data in the Boot header:

```
//arch = zynqmp; split = false; format = BIN
the_ROM_image:
{
    [pskfile]C:\edt\secureboot_sd\keys\psk0.pem
    [sskfile]C:\edt\secureboot_sd\keys\ssk0.pem
    [auth_params]ppk_select = 0
    [aeskeyfile]C:\edt\secureboot_sd\bbram.nky
    [keysrc_encryption] bh_blk_key
    [bh_keyfile]black_key.txt
    [bh_key_iv]black_iv.txt
    [puf_file] helperdata.txt
    [fsbl_config] pufhd_bh, shutter=0x01000005E, bh_auth_enable, puf4kmode
    [bootloader, destination_cpu=a53-0, encryption = aes, authentication =
rsa]C:\edt\edt_zcu102\edt_zcu102.sdk\fsbl_a53\Debug\fsbl_a53.elf
    [pmufw_image]C:\edt\edt_zcu102\edt_zcu102.sdk\pmu_fw\Debug\pmu_fw.elf
    [encryption = aes, authentication = rsa, destination_cpu = a53-0, exception_level
= el-3, trustzone]C:\edt\design_files\sd_boot\bl31.elf
    [encryption = aes, authentication = rsa, destination_cpu =
r5-lockstep]C:\edt\edt_zcu102\edt_zcu102.sdk\testapp_r5\Debug\testapp_r5.elf
    [authentication = rsa, destination_cpu = a53-0, exception_level =
el-2]C:\edt\design_files\sd_boot\u-boot.elf
}
```

11. Ensure that the key files and the helperdata files are saved in C:\edt\secureboot_sd\aes_puf.
12. Run Xilinx Tools > **Launch Shell**.
13. Change Directory to C:\edt\secureboot_sd\aes_puf and run the following command:
`bootgen -image aes_using_puf.bif -arch zynqmp -o BOOT.BIN -w`
14. Insert an SD card into the PC card slot and copy BOOT.BIN to the SD card. Move the SD card to the IO Carrier Card SD slot.
15. Switch the power on to the IO Carrier Card.
16. Verify that U-boot loads in the communication terminal.

Note: The above steps can also be executed with PUF in eFUSE mode. In this case you can repeat the previous steps, using the PUF in eFUSE mode. In this case, the BIF would need to modify to use encryption key from eFUSE. PUF in eFUSE mode is not covered in this tutorial, to avoid programming the eFUSE permanently.

```
[keysrc_encryption]efuse_blk_key
```

System Design Examples

This chapter guides you through building a system based on Zynq® UltraScale+™ devices using available tools and supported software blocks. This chapter highlights how you can use the software blocks you configured in [Chapter 3](#) to create a Zynq UltraScale+ system. It does not discuss domain-specific designs, but rather highlights different ways to use low-level software available for Zynq UltraScale+ devices.

Design Example 1: Using GPIOs, Timers, and Interrupts

The Zynq ZCU102 UltraScale+ Evaluation Board comes with few user configurable Switches and LEDs. This design example makes use of bare-metal and Linux applications to toggle these LEDs, with the following details:

- The Linux applications configure a set of PL LEDs to toggle using a PS Dip Switch, and another set of PL LEDs to toggle using a PL Dip Switch (SW17).
- The Linux APU A-53 Core 0 hosts this Linux application, while the RPU R5-0 hosts another bare-metal application.
- The R5-Core 0 application uses an AXI Timer IP in Programmable logic to toggle PS LED (DS50). The application is configured to toggle the LED state every time the timer counter expires, and the Timer in the PL is set to reset periodically after a user-configurable time interval. The system is configured such that the APU Linux Application and RPU Bare-metal Application run simultaneously.

Configuring Hardware

The first step in this design is to configure the PS and PL sections. This can be done in Vivado IP integrator. You start with adding the required IPs from the Vivado IP catalog and then connect the components to blocks in the PS subsystem.

1. If the Vivado Design Suite is already open, start from the block diagram (shown in [Figure 2-2](#)) and jump to [step 4](#).
2. Open the Vivado Project that you created:

```
C:/edt/edt_zcu102/edt_zcu102.xpr
```

3. In the Flow Navigator, under **IP Integrator**, click **Open Block Design** and select **edt_zcu102.bd**.




Figure 6-1: Open Block Design

4. Right click in the block diagram and select **Add IP** from the IP catalog.

Adding and Configuring IPs

1. In the catalog, select **AXI Timer**.

The IP Details information displays, as shown in the following figure.




Figure 6-2: IP Details Information

2. Double-click the **AXI Timer** IP to add it to the design.

3. Double-click the **AXI Timer** IP again to configure the IP, as shown in following figure.




Figure 6-3: Re-customize IP Dialog Box for AXI Timer

4. Click **OK**.
5. Again, right-click in the block diagram and select **Add IP**.
6. Search for “AXI GPIO” and double-click the **AXI GPIO** IP to add it to the design.
7. Repeat [step 5](#) and [step 6](#) to add another instance of AXI GPIO IP.
8. Double-click **axi_gpio_0** and select **Push button 5bits** from the GPIO Board Interface drop-down list.




Figure 6-4: Re-customize IP Dialog Box for AXI GPIO

9. Click **OK** to configure the AXI_GPIO for Push buttons.
10. Double-click on `axi_gpio_1`.
11. Configure `axi_gpio_1` for PL LEDs by selecting `led_8bits` from the **GPIO Board Interface** drop-down list, as shown in the following figure.




Figure 6-5: Configuring GPIO for led_8bits

12. Click **OK** to configure the AXI_GPIO for Push buttons.

Connecting IP Blocks to Create a Complete System

Make the initial connections using Board presets. To do this, follow the below steps:

1. Double-click the **Zynq UltraScale+ IP Block**, and select a PL-PS interrupt as shown in [Figure 6-6](#) (Ignore and move to the next step, if this is selected by default).




Figure 6-6: Selecting PL to PS Interrupt

2. In PS-PL Configuration, expand **PS-PL Interfaces** and expand the **Master Interface**.

3. Expand **AXI HPM0 LPD** and set the **AXI HPM0 LPD Data Width** drop-down to **128 bit**, as shown in [Figure 6-7](#).




Figure 6-7: Set Data Width for AXI HPM0 LPD

4. Click **OK** to complete the configuration and return to the block diagram.
5. Click **Run Connection Automation**. Do not click on Run Block Automation.

* Designer Assistance available. [Run Block Automation](#) [Run Connection Automation](#)

Figure 6-8: Run Connection Automation Link

6. In the Run Connection Automation dialog box, click **All Automation**.
7. Click **OK**.
8. In the diagram view, connect the interrupt port from `axi_timer_0` to `pl_ps_irq[0:0]`.
9. In the Address Editor view, verify that the corresponding IPs are allocated the same Address Map, as shown in the following figure. If not, set the offset address such that they match the following figure.

Cell	Slave Interface	Base Name	Offset Address	Range	High Address
zynq_ultra_ps_e_0					
Data (40 address bits : 0x0080000000 [512M])					
axi_timer_0	S_AXI	Reg	0x00_8000_0000	64K	0x00_8000_FFFF
axi_gpio_0	S_AXI	Reg	0x00_8001_0000	64K	0x00_8001_FFFF
axi_gpio_1	S_AXI	Reg	0x00_8002_0000	64K	0x00_8002_FFFF

Figure 6-9: Address Map for PL IPs

10. Validate the design and generate the output files for this design, as described in the following sections.

Validating the Design and Generating Output

1. Return to the block diagram view and save the Block Design (press **Ctrl + S**).
2. Right-click in the white space of the Block Diagram view and select **Validate Design**.

Alternatively, you can press the **F6** key.

A message dialog box opens and states "Validation successful. There are no errors or critical warnings in this design."

3. Click **OK** to close the message.
4. In the Block Design view, click the **Sources** tab.
5. Click **Hierarchy**.
6. In the Block Diagram, Sources window, under Design Sources, expand `edt_zcu102_wrapper`.
7. Right-click the top-level block diagram, titled `edt_zcu102_i : edt_zcu102 (edt_zcu102.bd)` and select **Generate Output Products**.

The Generate Output Products dialog box opens, as shown [Figure 6-10](#).




Figure 6-10: Generate Output Products Dialog Box

Note: If you are running the Vivado Design Suite on a Linux host machine, you might see additional options under Run Settings. In this case, continue with the default settings.

8. Click **Generate**.
9. When the Generate Output Products process completes, click **OK**.
10. In the Block Diagram Sources window, click the **IP Sources** tab. Here you can see the output products that you just generated, as shown in the following figure.




Figure 6-11: Outputs Generated Under IP Sources

Synthesizing the Design, Running Implementation, and Generating the Bitstream

1. You can now synthesize the design. In the Flow Navigator pane, under **Synthesis**, click **Run Synthesis**.




Figure 6-12: Run Synthesis Button

2. If Vivado prompts you to save your project before launching synthesis, click **Save**.

While synthesis is running, a status bar displays in the upper right-hand window. This status bar spools for various reasons throughout the design process. The status bar signifies that a process is working in the background.




Figure 6-13: Status Bar

When synthesis completes, the Synthesis Completed dialog box opens.

3. Select Run Implementation and click **OK**.

Again, notice that the status bar describes the process running in the background. When implementation completes, the Implementation Completed dialog box opens.

4. Select Generate Bitstream and click **OK**.

When Bitstream Generation completes, the Bitstream Generation Completed dialog box opens.

5. Click **Cancel** to close the window.

6. After the Bitstream generation completes, export the hardware to SDK.

Exporting Hardware to SDK

In this example, you will launch SDK from Vivado.

1. From the Vivado toolbar, select **File > Export > Export Hardware**.

The Export Hardware dialog box opens. Make sure that the **Include bitstream** check box is checked (only when design has PL design and bitstream generated), and that the **Export to** field is set to the default option of **<Local to Project>**.

2. Click **OK**.

At this point a warning message appears to indicate that the Hardware Module has already been exported.

3. Click **Yes** to overwrite the existing HDF file.




Figure 6-14: Permission to Overwrite Existing Hardware Files

4. Once the Hardware files are exported, SDK also detects the new HDF and shows the following warning message.




Figure 6-15: SDK Warning Message about Detecting Updated HDF

The warning message is also to check if SDK can update the project in sync with the new HDF.

5. Click **Yes**.

Now the SDK project is updated in sync with the new HDF file. To verify this, look for the GPIO and AXI_Timer drivers, which were added in the BSP packages in the existing project.

Configuring Software

This use case has a bare-metal application running on an R5 core and a Linux Application running on APU Linux Target. Most of the software blocks will remain the same as mentioned in [Chapter 3](#). The software for this design example requires additional drivers for components added in the PL Logic. For this reason, you will need to generate a new Bare-metal BSP in SDK using the Hardware files generated for this design. Linux also requires the Linux BSP to be reconfigured in sync with the new hardware design file (HDF). Before you configure the software, first look at the application design scheme.

The system has a bare-metal application on RPU, which starts with toggling the PS LEDs for a user configurable period. The LEDs are set to toggle in synchronization with PL AXI Timer running in the PL block. The application sets the AXI Timer in generate mode and generates an interrupt every time the Timer count expires. The application is designed to toggle the PS LED state after handling the Timer interrupt. The application runs in an infinite while loop and sets the RPU in WFI mode after toggling the LEDs for the user-configured time period. This LED toggling sequence can be repeated again by getting the RPU out of WFI mode using an external interrupt. For this reason, the UART interrupt is also configured and enabled in the same application. While this application runs on the RPU, the Linux target also hosts another Linux application. The Linux application uses user Input from PS or PL switches to toggle PL LEDs. This Linux application also runs in an infinite while loop, waiting for user input to toggle PL LEDs. The next set of steps show how to configure System software and build user applications for this design.

First, create the Linux images using PetaLinux. The Linux images must be created in sync with the hardware configuration for this design. You will also need to configure PetaLinux to create images for SD boot.

Refer to [Example Project: Create Linux Images using PetaLinux in Chapter 3](#), and repeat steps from [step 2](#) to [step 12](#) to update the device tree and build Linux images using PetaLinux. Alternatively, you can also use the Linux image files shared with this tutorial. The images for this section can be found in <design_files>/design.

Follow [step 13](#) to verify the images. The next step is to create a Bare-metal Application targeted for ARM cortex R5 based RPU.

For this design example, you must import the application source files available in the Design Files ZIP file released with this tutorial. For information about locating these design files, refer to [Design Files for This Tutorial in Appendix B](#).

Creating the Bare-Metal Application Project

1. In SDK, select **File > New > Application Project**.

The New Project wizard opens.

2. Use the information in the table below to make your selections in the wizard.

Table 6-1: Settings to Create Timer-Based RPU Application Project

Wizard Screen	System Properties	Setting or Command to Use
Application Project	Project Name	tmr_psled_r5
	Use Default Location	Select this option.
	Hardware Platform	edt_zcu102_wrapper_hw_platform_0
	Processor	psu_cortexr5_0
	OS Platform	standalone
	Language	C
	Board Support Package	Select Use Existing and select r5_bsp .
Templates	Available Templates	Empty Application

4. Click **Finish**.

The New Project wizard closes and SDK creates the tmr_psled_r5 application project, which you can view in the Project Explorer.

5. In the Project Explorer tab, expand the tmr_psled_r5 project.
6. Right-click the `src` directory, and select **Import** to open the Import dialog box.
7. Expand **General** in the Import dialog box and select **File System**.
8. Click **Next**.
9. Select **Browse** and navigate to the design files folder, which you saved earlier (see [Additional Resources and Legal Notices in Appendix B](#)).
10. Click **OK**.
11. Add the `timer_psled_r5.c` file.
12. Click **Finish**.

SDK automatically builds the application and displays the status in the console window.

Modifying the Linker Script


1. In the Project Explorer, expand the tmr_psled_r5 project.
2. In the `src` directory, double-click `lscript.ld` to open the linker script for this project.

3. In the linker script, in Available Memory Regions, modify the following attributes for psu_r5_ddr_0_MEM_0:

Base Address: 0x70000000

Size: 0x10000000

The following figure shows the linker script modification.



Linker Script: lscript.ld

A linker script is used to control where different sections of an executable are placed in memory. In this page, you can define new memory regions, and change the assignment of sections to memory regions.

Available Memory Regions

Name	Base Address	Size
psu_ocm_ram_0_MEM_0	0xFFFFC0000	0x40000
psu_qspi_linear_0_MEM_0	0xC0000000	0x20000000
psu_r5_0_atcm_MEM_0	0x0	0x10000
psu_r5_0_btcm_MEM_0	0x20000	0x10000
psu_r5_ddr_0_MEM_0	0x70000000	0x10000000
psu_r5_tcm_ram_0_MEM_0	0x0	0x40000

Stack and Heap Sizes

Stack Size

Heap Size

Figure 6-16: Linker Script Modification

This modification in the linker script ensures that the RPU bare-metal application resides above 0x70000000 (about 1.79 GB) base address in the DDR, and occupies no more than 256 MB of size.

4. Type **Ctrl + S** to save the changes.
5. Right-click the tmr_psled_r5 project and select **Build Project**.
6. Verify that the application is compiled and linked successfully and that the tmr_psled_r5.elf file was generated in the tmr_psled_r5\Debug folder.
7. Verify that the BSP is configured for UART_1. Refer to [Modifying the Board Support Package in Chapter 3](#).

Creating the Linux Application Project

1. In SDK, select **File > New > Application Project**.

The New Project wizard opens.

2. Use the information in the table below to make your selections in the wizard.

Table 6-2: Settings to Create New Linux Application Project

Wizard Screen	System Properties	Setting or Command to Use
Application Project	Project Name	ps_pl_linux_app
	Use Default Location	Select this option
	Processor	psu_cortexA53
	OS Platform	Linux
	Language	C
	Compiler	64-bit
Templates	Available Templates	Linux Empty Application

3. Click **Finish**.

The New Project wizard closes and SDK creates the `ps_pl_linux_app` application project, which can be found in the Project Explorer.

4. In the Project Explorer tab, expand the `ps_pl_linux_app` project.
5. Right-click the `src` directory, and select **Import** to open the Import dialog box.
6. Expand **General** in the Import dialog box and select **File System**.
7. Click **Next**.
8. Select **Browse** and navigate to the design files folder, which you saved earlier (see [Design Files for This Tutorial in Appendix B](#)).
9. Click **OK**.
10. Add the `ps_pl_linux_app.c` file.

Note: The application might fail to build because of a missing reference to the pthread Library. The next section shows how to add the pthread library.

Modifying the Build Settings

This application makes use of Pthreads from the pthread library. Add the pthread library as follows:

1. Right-click ps_pl_linux_app, and click on **C/C++ Build Settings**.
2. Refer to the following figures to add the `pthread` library.




Figure 6-17: C/C++ Build Settings




Figure 6-18: Add pthread Library

3. Click **OK**.

SDK automatically builds the application and displays the status in the console window.

Creating a Boot Image

Now that all the individual images are ready, you will create the boot image to load all of these components on a Zynq UltraScale+ device. This can be done using the Create Boot Image wizard in SDK, using the following steps. This example creates a Boot Image BOOT.bin in C:\edt\design1.

1. Launch SDK, if it is not already running.
2. Set the workspace based on the project you created in [Chapter 2](#). For example:
C:\edt\edt_zcu102\edt_zcu102.sdk
3. Select **Xilinx Tools > Create Boot Image**.
4. Refer to the following figure for settings in the Create Boot Image wizard.
5. Add the partitions as shown in the following figure.

Note: For detailed steps on how to add partitions, refer to [Boot Sequence for SD-Boot](#).




Figure 6-19: Create Boot Image for SD Boot Mode

Note: This Boot image requires PL bitstream `edt_zcu102_wrapper.bit` (Partition Type - Datafile, Destination Device - PL). The Bitstream Partition needs to be added right after the Bootloader while you create the boot image. Also note that the R5 application `tmr_psled_r5.elf` is added as partition in this boot image.

6. After adding all the partitions, click **Create Image**.



IMPORTANT: Ensure that you have set the correct exception levels for ATF (EL-3, Trustzone) and U-boot (EL-2) partitions. These settings can be ignored for other partitions.

Running the Image on a ZCU102 Board

Prepare the SD Card

Copy the images and executables on an SD card and load it in the SD card slot in the Board.

1. Copy files `BOOT.BIN` and `image.ub` to an SD card.

Note: `BOOT.BIN` is located in `C:\edt\design1`.

2. Copy the Linux application, `ps_pl_linux_app.elf`, to the same SD Card. The application can be found in:

`C:\edt\edt_zcu102\edt_zcu102.sdk\ps_pl_linux_app\Debug`

Target Setup

1. Load the SD card into the ZCU102 board, in the J100 connector.
2. Connect the USB-UART on the Board to the Host machine.
3. Connect the Micro USB cable into the ZCU102 Board Micro USB port J83, and the other end into an open USB port on the host Machine.
4. Configure the Board to Boot in SD-Boot mode by setting switch SW6 as shown in the following figure.




Figure 6-20: SW6 Switch Settings for SD Boot Mode

5. Connect 12V Power to the ZCU102 6-Pin Molex connector.
6. Start a terminal session, using TeraTerm or Minicom depending on the host machine being used, as well as the COM Port and baud rate for your system, as shown in [Figure 5-8](#).
7. For port settings, verify the COM Port in the device manager.

There are four USB-UART interfaces exposed by the ZCU102 Board.

8. Select the COM Port associated with the interface with the lowest number. In this case, for UART-0, select the com-port with interface-0.
9. Similarly, for UART-1, select com-port with interface-1.

Remember that the R5 BSP has been configured to use UART-1, and so R5 application messages will appear on the com-port with the UART-1 terminal

Power ON Target and Run Applications

1. Turn on the ZCU102 Board using SW1, and wait until Linux loads on the board.

You can see the initial Boot sequence messages on your Terminal Screen representing UART-0.

You can see that the terminal screen configured for UART-1 also prints a message. This is the print message from the R-5 bare-metal Application running on RPU, configured to use UART-1 interface. This application is loaded by the FSBL onto RPU.

2. Now that this application is running, notice the PS LED being toggled by the application, and follow the instructions in the application terminal.

```

PS LED Turned ON
PS LED Turned OFF
PS LED Turned ON
PS LED Turned OFF
PS LED Turned ON

RPU in WFI mode. Press any key to repeat the sequence

```

Figure 6-21: R5-0 Bare Metal Application

Running Linux Applications

After Linux is up on the ZCU102 system, log in to the Linux target. The Linux target is now ready for running applications.

Run the Linux application using following steps.

1. Copy the application from SD card mount point to /tmp

```
# cp /run/media/mmcblk0p1/ps_pl_linux_app.elf /tmp
```

Note: Mount the SD card manually if you fail to find SD card contents in this location.


```
# mount /dev/mmcblk0p1 /media/
```

2. Copy the application to /tmp.

```
# cp /media/ps_pl_linux_app.elf /tmp
```

3. Run the application.

```
# /tmp/ps_pl_linux_app.elf
```



```
Application Started
Press Sw 17 or Sw 19 on the board

PS Switch Pressed, observe PL LED [4:7]
```

Figure 6-22: Linux Terminal

At this point, your entire system is up and running.

Design Example 2: Example Setup for Graphics and Display Port Based Sub-System

This design example is primarily based on the Graphics Processing Unit and the Display Port on a Zynq UltraScale+ MPSoC device. The main idea behind this example is to demonstrate the configurations, packages, and tool flow required for running designs based on GPU and DP on a Zynq UltraScale+ MPSoC device. This design example can be broken down into the following sections:

1. Configuring the hardware.
2. Configuring PetaLinux RootFS to include the required packages:
 - a. GPU related packages
 - b. X Window System and dependencies
3. Building Boot images and Linux images using PetaLinux.
4. Building a Graphics OpenGL ES application targeted for Mali GPU. This application is based on the X Window System.
5. Loading Linux on the ZCU102 board and running the Graphics Application on the target to see the result on the display port.

Configuring the Hardware

In this section, you will configure the processing system to set Dual lower GT lanes for the display port. The hardware configuration in this section is based on the same Vivado project that you created in [Design Example 1: Using GPIOs, Timers, and Interrupts](#).

Configuring Hardware in Vivado IP Integrator

1. Ensure that the edt_zcu102 project and the block design are open in Vivado.
2. Double-click the Zynq UltraScale+ Processing System block in the Block Diagram window and wait till the Re-customize IP dialog box opens.
3. In Re-customize IP window, click on **I/O Configuration > High Speed**
4. De-select PCIe peripheral connection
5. Expand Display Port, and set Lane Selection to Dual Lower, as shown in following figure:




Figure 6-23: Display Port Lane Selection

Note: The Display port lane selection is set to Dual lane to support UHD@30 resolution in the design example of this tutorial. This configuration will lock display for UHD@30 as well as lower resolution like 1080p 60 and others, for corresponding monitors.

6. Click **OK** to close the Re-customize IP wizard.



CAUTION! Do not click the Run Block Automation link. Clicking the link will reset the design as per board preset and disable the design updates you made using in this section.

7. Click **File > Save Block Design** to save the block design. Alternatively, you can press **CTRL + S** to save the block design.
8. Click **Generate Bitstream**, to re-synthesize the design and generate the Bitstream.
9. After the Bitstream is generated successfully, click **File > Export > Export Hardware** to export the hardware design.
10. Select **Include Bistream**.
11. Click **OK**.

The exported design can be found at following location:

`<edt_zcu102_Vivado_project_path>\edt_zcu102.sdk\edt_zcu102_wrapper.hdf`

For this example, it can be found in

`C:\edt\edt_zcu102\edt_zcu102.sdk\edt_zcu102_wrapper.hdf`

12. Copy the HDF file to a Linux Host machine.

The next section describes steps to build Linux for your Hardware configuration and also add additional software packages for GPU and the X Window System.

Modifying the Configuration and Building Linux Images using PetaLinux

Re-configure the PetaLinux BSP in sync with the new hardware changes. This section uses the PetaLinux project you created in [Example Project: Create Linux Images using PetaLinux](#).

1. Change to the PetaLinux directory using the following command:

```
$ cd xilinx-zcu102-2017.2
```

2. Copy the hardware platform `edt_zcu102_wrapper.hdf` in the Linux Host machine.

3. Reconfigure the BSP using the following command:

```
$ petalinux-config --get-hw-description=<path containing edt_zcu102_wrapper.hdf>/
```

The PetaLinux configuration wizard opens.

4. Save and exit the wizard without any additional configuration settings.

Wait until PetaLinux reconfigures the project.

5. Clean the existing Bootloader image. This is to ensure that the bootloader is recreated in sync with new hardware design.

```
$ petalinux-build -c bootloader -x distclean
```

6. Modify Device-tree for Dual Lane display port configuration by following the instructions in Xilinx Answer [69248](#). The `system-user.dtsi` (with these changes) is available in [Design Files for This Tutorial](#).

Building the Mali OpenGLES Application

This section leads you through building a Triangle-based Cube application. This application is written in OpenGLES and is based on the X Window System. For more details and for the application source code, refer to `tricube` in the `design_files` folder of the zip file that accompanies this tutorial. See [Design Files for This Tutorial](#).

Use the following steps to build the OpenGLES application:

1. Copy the entire application source directory of `tricube` to the Linux host machine in the `recipe-apps` directory of the PetaLinux project.

```
<PetaLinux-Project>/project-spec/meta-user/recipes-apps/tricube
```

2. Add the newly created `tricube` in `petalinux-image.bbappend`, which is located in

```
<plnx_project>/project-spec/meta-user/recipes-core/images/petalinux-image.bbappend
```

With this addition, the file will look like below. Notice the new application in bold.

```
IMAGE_INSTALL_append = " peekpoke"
```

```
IMAGE_INSTALL_append = " gpio-demo"
IMAGE_INSTALL_append = " tricube"
```

3. Refer to recipe `tricube/tricube.bb` for detailed instructions and libraries used for building this application. The X Window System (X11) packages included while building the above application is application dependent. Libraries included in `tricube.bb` recipe are based on the packages that were used in the application.

Enable GPU Libraries and Other Packages in RootFS

In this section, you will use the PetaLinux rootfs Configuration wizard to add the Mali GPU libraries. PetaLinux is shipped with Mali GPU libraries and device drivers for Mali GPU. By default, the Mali driver is enabled in the kernel tree, but Mali user libraries need to be configured (on an as-needed basis) in the rootfs. In addition to this, you will use the same wizard to include the X Window System libraries.

1. Open the PetaLinux rootfs Configuration wizard -

```
$ Petalinux-config -c rootfs
```

2. Navigate to and enable the following packages:

```
Filesystem Packages > libs > libmali-xlnx > libmali-xlnx
Filesystem Packages > libs > libmali-xlnx > libmali-xlnx-dev
```

These packages enable you to build and Run OpenGL ES applications targeted for Mali GPU in the Zynq UltraScale+ MPSoC device.

3. Add X11 package groups to add X window related packages:

```
Filesystem Packages > misc > packagegroup-petalinux-x11 >
packagegroup-petalinux-x11
```

```
Filesystem Packages > misc > packagegroup-petalinux-x11 >
packagegroup-petalinux-x11-dev
```

4. Add the OpenGL ES application created in the earlier section:

```
User Packages > tricube
```

5. After enabling all the packages, save the config file and exit the rootfs configuration settings.

6. Build the Linux images using the following command:

```
$ petalinux-build
```

7. Verify that the `image.ub` Linux image file is generated in the `images/linux` directory.

8. Generate the Boot image for this design example as follows:

```
$ petalinux-package --boot --fsbl images/linux/zynqmp_fsbl.elf --fpga
images/linux(edt-zcu102_wrapper.bit --u-boot
```

A `BOOT.BIN` Boot image is created. It is composed of the FSBL boot loader, the PL bitstream, PMU firmware and ATF, and u-boot. Alternatively, see the steps in [Creating a Boot Image](#) to create this boot image.



IMPORTANT: This example uses the GPU packages based on X window system, which is the default setting in PetaLinux 2017.2. To enable Frame Buffer fbdev based GPU Packages in PetaLinux 2017.2, add the following line in <PetaLinux_project>/project-spec/meta-user/conf/petalinuxbsp.conf.

DISTRO_FEATURES_remove_zynqmp = "x11"

See example eglfbdev application (based on fdev) available in [Design Files for This Tutorial](#). For more information, see the Xilinx Answer [68821](#).

Loading Linux and Running the OpenGL ES Application on the Target and Viewing the Result on the Display Port

Preparing the SD Card

Now that the Linux images are built and the application is also built, copy the following images in an SD card and load the SD card in ZCU102 board. Also, copy the runtricube.sh (available in [Design Files for This Tutorial](#)) script to SD card.

- BOOT.BIN
- Image.ub
- runtricube.sh

Running the Application on a Linux Target

Setting Up the Target

Do the following to set up the Target:

1. Load the SD card into the J100 connector of the ZCU102 board.
2. Connect the USB-UART from the Board to the Host machine.
3. Connect the Micro USB cable into the ZCU102 Board Micro USB port J83, and the other end into an open USB port on the host Machine.
4. Connect a Display Port monitor to the ZCU102 Board. The display port cable from the DP monitor can be connected to the display port connector on the ZCU102 board.

Note: These images were tested on a UHD@30 Hz and a FullHD@60 Hz Display Port capable monitor.

5. Configure the Board to Boot in SD-Boot mode by setting switch SW6 as shown in the following figure.




Figure 6-24: SW6 Switch Settings for SD Boot Mode

6. Connect 12V Power to the ZCU102 6-Pin Molex connector.
7. Start a terminal session, using TeraTerm or Minicom depending on the host machine being used, as well as the COM Port and baud rate for your system, as shown in [Figure 5-8](#).
8. For port settings, verify the COM Port in the device manager.

There are four USB-UART interfaces exposed by the ZCU102 Board. Select the COM Port associated with the interface with the lowest number. In this case, for UART-0, select the com-port with interface-0.

Powering On the Target and Running the Applications

1. Turn on the ZCU102 Board using SW1, and wait until Linux loads on the board.
2. After Linux loads, log in to the target Linux console using `root` for the login and password.
3. Mount the SD on target

```
# mount /dev/mmcblk0p1 /media
```

4. Run the `runtricube.sh` script to run the tricube application.

```
# chmod 755 /media/runtricube.sh
# /media/runtricube.sh
```

At this point, you can see a rotating multi-colored cube and a rotating triangle on the display port. Notice that the cube is also made of multi-colored triangles.




Figure 6-25: Rotating Cube and Triangle

Debugging Problems with Secure Boot

This appendix describes how to debug security failures. One procedure determines if PUF registration has been run on the device. A second procedure checks the value of the Boot Header in the boot image.

Determine if PUF Registration is Running

The following steps can be used to verify if the PUF registration software has been run on the device:

1. In SDK, select **Xilinx Tools > XSCT Console**
2. Enter the following commands at the prompt:

```
xsct% connect
xsct% targets
xsct% targets -set -filter {name =~ "Cortex-A53 #0"}
xsct% rst -processor
xsct% mrd -force 0xFFCC1050 (0xFFCC1054)
```

3. This location contains the CHASH and AUX values. If non-zero, PUF registration software has been run on the device.
-

Test the Bootheader Value Used in the Boot Image

You can use the Bootgen Utility to verify the Bootheader value used in the Boot Image.

1. Change to the directory containing BOOT.bin
2. Run

```
bootgen_utility -bin BOOT.bin -out myfile -arch zynqmp
```

3. Look for "BH" in myfile.

Additional Resources and Legal Notices

Xilinx Resources

For support resources such as Answers, Documentation, Downloads, and Forums, see [Xilinx Support](#).

Solution Centers

See the [Xilinx Solution Centers](#) for support on devices, software tools, and intellectual property at all stages of the design cycle. Topics include design assistance, advisories, and troubleshooting tips.

Documentation Navigator and Design Hubs

Xilinx Documentation Navigator provides access to Xilinx documents, videos, and support resources, which you can filter and search to find information. To open the Xilinx Documentation Navigator (DocNav):

- From the Vivado IDE, select **Help > Documentation and Tutorials**.
- On Windows, select **Start > All Programs > Xilinx Design Tools > DocNav**.
- At the Linux command prompt, enter docnav.

Xilinx Design Hubs provide links to documentation organized by design tasks and other topics, which you can use to learn key concepts and address frequently asked questions. To access the Design Hubs:

- In the Xilinx Documentation Navigator, click the **Design Hubs View** tab.
- On the Xilinx website, see the [Design Hubs](#) page.

Note: For more information on Documentation Navigator, see the [Documentation Navigator](#) page on the Xilinx website.

Xilinx Documentation Navigator

The Xilinx® Documentation Navigator is a free tool that you can use to access documentation while using Xilinx products. The Documentation Navigator is available as part of the Vivado® Installer. When it is installed on your system, you can access it by going to **Start > Programs > Xilinx Design Tools > DocNav** and clicking the **DocNav** icon.

For detailed information about using the Xilinx Documentation Navigator, refer to [this link](#) in *Vivado Design Suite User Guide: Getting Started* (UG910) [Ref 1].

Related Design Hubs

Available in Documentation Navigator, design hubs provide quick access to documentation, training, and information for specific design tasks. The following design hubs are applicable to embedded development and the methods described in this guide:

- PetaLinux Tools Design Hub
 - Software Development Kit Design Hub
-

Design Files for This Tutorial

The ZIP file associated with this document contains the design files for the tutorial. You can download this file from [here](#) and follow the below steps:

1. Download and extract the contents from the ZIP file to C:\edit. Design files contain the HDF files, source code and prebuilt images for all the sections.
-

Xilinx Resources

The following Xilinx Vivado Design Suite and Zynq® UltraScale+™ guides are referenced in this document.

1. *Vivado Design Suite User Guide: Getting Started* ([UG910](#))
2. *Vivado Design Suite Tutorial: Embedded Processor Hardware Design* ([UG940](#))
3. *Vivado Design Suite User Guide: Release Notes, Installation, and Licensing* ([UG973](#))
4. *UltraFast Embedded Design Methodology Guide* ([UG1046](#))
5. *Zynq UltraScale+ MPSoC Technical Reference Manual* ([UG1085](#))
6. *Zynq UltraScale+ MPSoC Software Developer Guide* ([UG1137](#))

7. *PetaLinux Tools Documentation: Reference Guide* ([UG1144](#))
8. *Xilinx Software Development Kit (SDK) User Guide: System Performance Analysis* ([UG1145](#))
9. Zynq UltraScale+ Processing System Product Guide ([PG201](#))
10. *Measured Boot of Zynq-7000 All Programmable SoCs* ([XAPP1309](#))
11. *Secure Boot of Zynq-7000 All Programmable SoC* ([XAPP1175](#))
12. *Changing the Cryptographic Key in Zynq-7000 AP SoC* ([XAPP1223](#))
13. *Programming BBRAM and eFUSES* ([XAPP1319](#))

Support Resources

14. [Xilinx Zynq UltraScale+ MPSoC Solution Center](#)
15. Xilinx Petalinux Web page: <http://www.xilinx.com/PetaLinux>
16. The Software Zone:
<http://www.xilinx.com/products/design-tools/software-zone/sdsoc.html#docsdownload>

Additional Resources

17. The Effect and Technique of System Coherence in ARM Multicore Technology by John Goodacre, Senior Program Manager, ARM Processor Division
(<http://www.mpsoc-forum.org/previous/2008/slides/8-6%20Goodacre.pdf>)
18. Xilinx GitHub website: <https://github.com/xilinx>
19. The Linux Kernel Module Programming Guide:
<http://tldp.org/LDP/lkmpg/2.6/html/index.html>

Training Resources

Xilinx provides a variety of training courses and QuickTake videos to help you learn more about the concepts presented in this document. Use these links to explore related videos:

1. [Vivado Design Suite QuickTake Video Tutorials](#)

Please Read: Important Legal Notices

The information disclosed to you hereunder (the "Materials") is provided solely for the selection and use of Xilinx products. To the maximum extent permitted by applicable law: (1) Materials are made available "AS IS" and with all faults, Xilinx hereby DISCLAIMS ALL WARRANTIES AND CONDITIONS, EXPRESS, IMPLIED, OR STATUTORY, INCLUDING BUT NOT LIMITED TO WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, OR FITNESS FOR ANY PARTICULAR PURPOSE; and (2) Xilinx shall not be liable (whether in contract or tort, including negligence, or under any other theory of liability) for any loss or damage of any kind or nature related to, arising under, or in connection with, the Materials (including your use of the Materials), including for any direct, indirect, special, incidental, or consequential loss or damage (including loss of data, profits, goodwill, or any type of loss or damage suffered as a result of any action brought by a third party) even if such damage or loss was reasonably foreseeable or Xilinx had been advised of the possibility of the same. Xilinx assumes no obligation to correct any errors contained in the Materials or to notify you of updates to the Materials or to product specifications. You may not reproduce, modify, distribute, or publicly display the Materials without prior written consent. Certain products are subject to the terms and conditions of Xilinx's limited warranty, please refer to Xilinx's Terms of Sale which can be viewed at <http://www.xilinx.com/legal.htm#tos>; IP cores may be subject to warranty and support terms contained in a license issued to you by Xilinx. Xilinx products are not designed or intended to be fail-safe or for use in any application requiring fail-safe performance; you assume sole risk and liability for use of Xilinx products in such critical applications, please refer to Xilinx's Terms of Sale which can be viewed at <http://www.xilinx.com/legal.htm#tos>.

AUTOMOTIVE APPLICATIONS DISCLAIMER

AUTOMOTIVE PRODUCTS (IDENTIFIED AS "XA" IN THE PART NUMBER) ARE NOT WARRANTED FOR USE IN THE DEPLOYMENT OF AIRBAGS OR FOR USE IN APPLICATIONS THAT AFFECT CONTROL OF A VEHICLE ("SAFETY APPLICATION") UNLESS THERE IS A SAFETY CONCEPT OR REDUNDANCY FEATURE CONSISTENT WITH THE ISO 26262 AUTOMOTIVE SAFETY STANDARD ("SAFETY DESIGN"). CUSTOMER SHALL, PRIOR TO USING OR DISTRIBUTING ANY SYSTEMS THAT INCORPORATE PRODUCTS, THOROUGHLY TEST SUCH SYSTEMS FOR SAFETY PURPOSES. USE OF PRODUCTS IN A SAFETY APPLICATION WITHOUT A SAFETY DESIGN IS FULLY AT THE RISK OF CUSTOMER, SUBJECT ONLY TO APPLICABLE LAWS AND REGULATIONS GOVERNING LIMITATIONS ON PRODUCT LIABILITY.

© Copyright 2017 Xilinx, Inc. Xilinx, the Xilinx logo, Artix, ISE, Kintex, Spartan, Virtex, Vivado, Zynq, and other designated brands included herein are trademarks of Xilinx in the United States and other countries. All other trademarks are the property of their respective owners.