

User Manual

Vibro Bran Finisher · UVK-45/100

1. Safety

The Vibro Bran Finisher must only be operated by trained personnel. Before maintenance or cleaning, isolate the machine at the main switch, then lock and tag it out. Guards must remain closed during operation.

2. Description

The Vibro Bran Finisher is designed for flour and semolina mills. The machine is delivered with the standard equipment of the UVK-45/100 series.

3. Installation

Place the machine on a level, vibration-free floor according to the dimensions in the technical sheet. Check the levelling after anchoring. The electrical connection must be made by a qualified electrician according to the rating plate.

4. First start-up

Check the direction of rotation against the arrow on the motor. Run the machine empty for at least 15 minutes; if there is no abnormal noise, vibration or heating, open the product feed gradually.

5. Adjustments

Capacity and separation quality depend on feed rate and air adjustment together. Make adjustments in small steps and check the product after each change.

6. Troubleshooting

Low capacity: check the feed and screen surfaces. Excessive vibration: check springs, fixing bolts and bearings. Motor protection trips: check current values and mechanical blockage.