## **SK WP CALIBRATION**

	Display
Remove cal cover	
With the scale on press the cal switch	Cal 0
Press <rezero></rezero>	Cal F
Place full load on to weigh pan.	END
Press <rezero></rezero>	
Press <on off=""> twice to return to</on>	
weigh mode	