AND AD 4406

INITALISATION PROCEDURE

- 1. With the display off, press & hold the **NET/GROSS** key and press the **ON/OFF** key until the display shows
- 2. Press the **NET/GROSS** key display shows software version.
- 3. Press the **TARE** key twice display shows "init F"
- 4. Press the CAL key display shows "init C".
- 5. Press and hold the **NET/GROSS** key and then press the **ENTER key**, display shows "-----"and then "Cal C".
- 6. Press ON/OFF to turn the indicator off and exit the init procedure.