102   1031000427G	No	Parts No.	Description	Applied to
103   033015352A	101	1031000427G	UPPER CASE	
104   1044016766B	102	1043009780B	DUST PLATE	
1083015360	103	1033015352A	PAN SUPPORT	
108   1083015361	104	1044016766B	WEIGHING PAN	
108   1074020515   DISPLAY FILTER		1083015360	KEY SHEET (HR-A)	
106				
107   1084029071   COMPANY LABEL(HR-A/AZ)   1074024145A   LEVEL VIAL WINDOW   1084020147A   KEY TOP   TPZ-5900C   MAIN BOARD HR-A   FX-CT   TPZ-5900D   MAIN BOARD HR-AZ   FZ-CT   ISKEVQPAC09K   TOUCH SWITCH   IEBCR2032   BATTERY   IUCF3738-HRAZ-3   CPU   IEDGWMV9922A   LCD   IEJ0470-01-230   POWER JACK   IEDGWMV9922A   LCD   IEJ0470-01-230   POWER JACK   I16   1074021043   UNDER CASE WATERPROOF COVER   IB64020145   FOOT   IB64020145   FOOT   IB64020145   FOOT   IB64020145   FOOT   IB64020067A-2   MODEL LABEL (HR250A)   JA   I084029067A-2   MODEL LABEL (HR150A)   JA   I084029067A-2   MODEL LABEL (HR150A)   JA   I084029067A-2   MODEL LABEL (HR250A2)   JA   I084029068A-2   MODEL LABEL (HR250A2)   JA   I084029068A-3   MODEL LABEL (HR150A2)   JA   I084029068A-3   MODEL LABEL (HR150A2)   JA   I084029068A-3   MODEL LABEL (HR100A2)   JA   I084029068A-3   MODEL MR100A2   JA   I084029068A-3   MODEL MR100A2   JA   I084029068A-3   MODEL MR100A2   JA   I084029068	106		·	
108				
109   1064020147A				
TPZ-5900C   MAIN BOARD HR-A   FX-CT   TPZ-5900D   MAIN BOARD HR-AZ   FZ-CT   TPZ-5900D   MAIN BOARD HR-AZ   FZ-CT   TSKEVQPAC09K   TOUCH SWITCH   TOUCH SWITCH SWITCH SWITCH   TOUCH SWITCH SWI				
TPZ-5900D				FX-CT
TSKEVQPAC09K				
IEBCR2032   BATTERY     IUCF3738-HRAZ-3   CPU				12 01
1UCF3738-HRAZ-3				
1EDGWMV9922A				
1EJ0470-01-230				
114   110NO-7529				
115	114			
116				
117				
118				
1084031728   MODEL LABEL (HR251A)   JA     1084029067A-1   MODEL LABEL (HR250A)   JA     1084029067A-2   MODEL LABEL (HR150A)   JA     1084029067A-3   MODEL LABEL (HR100A)   JA     1084029068A-3   MODEL LABEL (HR251AZ)   JA     1084029068A-1   MODEL LABEL (HR250AZ)   JA     1084029068A-2   MODEL LABEL (HR150AZ)   JA     1084029068A-3   MODEL LABEL (HR100AZ)   JA     1084029068A-1   MODEL LABEL (HR100AZ)   JA     1084029068A-2   MODEL LABEL (H				
120 120 120 120 120 120 120 120 120 120				10
120				
120				
1084031729   MODEL LABEL (HR251AZ)   JA     1084029068A-1   MODEL LABEL (HR250AZ)   JA     1084029068A-2   MODEL LABEL (HR150AZ)   JA     1084029068A-3   MODEL LABEL (HR100AZ)   JA     121   1044017357A   BLANK PLATE     122   1064018064   RS232C COVER     123   1064020146   RUBBER COVER     124   1074028244A   PAN SUPPORT ARM GUIDE     125   104402117   BREEZE BRAKE RING     126   1064015658   AIR FIITER     203   1044023214   FLEXURE BEAM (1BHM4023214)     206   1044018780A   FULCRUM FLEXURE     209   1044018779A   TENSION FLEXURE     214   1044030312A   2ND LEVER     305   1134023285   MASS ELEVATING CUFF   HR-AZ only     316   1LSCJV08-A03A1   SOLENOID VALVE   HR-AZ only     401   1072001346B   BREEZE BRAKE FRONT     402   1071000619   BREEZE BRAKE TOP FIXATION SCREW     414   1073009777C   BREEZE BRAKE TOP SLIDE     415   1072001349   BREEZE BRAKE SIDE DOOR     AX-FXI-31-EX   PROTECTIVE COVER(EX)				
1084029068A-1   MODEL LABEL (HR250AZ)				
1084029068A-2   MODEL LABEL (HR150AZ)   JA   1084029068A-3   MODEL LABEL (HR100AZ)   JA   121   1044017357A   BLANK PLATE     122   1064018064   RS232C COVER       123   1064020146   RUBBER COVER       124   1074028244A   PAN SUPPORT ARM GUIDE     125   1044022117   BREEZE BRAKE RING       1064015658   AIR FIITER				
1084029068A-3         MODEL LABEL (HR100AZ)         JA           121         1044017357A         BLANK PLATE           122         1064018064         RS232C COVER           123         1064020146         RUBBER COVER           124         1074028244A         PAN SUPPORT ARM GUIDE           125         1044022117         BREEZE BRAKE RING           126         1064015658         AIR FIITER           203         1044023214         FLEXURE BEAM (1BHM4023214)           206         1044018780A         FULCRUM FLEXURE           209         1044018779A         TENSION FLEXURE           214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349				
121         1044017357A         BLANK PLATE           122         1064018064         RS232C COVER           123         1064020146         RUBBER COVER           124         1074028244A         PAN SUPPORT ARM GUIDE           125         1044022117         BREEZE BRAKE RING           126         1064015658         AIR FIITER           203         1044023214         FLEXURE BEAM (1BHM4023214)           206         1044018780A         FULCRUM FLEXURE           209         1044018779A         TENSION FLEXURE           214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C				
122         1064018064         RS232C COVER           123         1064020146         RUBBER COVER           124         1074028244A         PAN SUPPORT ARM GUIDE           125         1044022117         BREEZE BRAKE RING           126         1064015658         AIR FIITER           203         1044023214         FLEXURE BEAM (1BHM4023214)           206         1044018780A         FULCRUM FLEXURE           209         1044018779A         TENSION FLEXURE           214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP SLIDE           414         1073009777C         BREEZE BRAKE TOP RAIL           415         1072001349         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COV	121			UA
123         1064020146         RUBBER COVER           124         1074028244A         PAN SUPPORT ARM GUIDE           125         1044022117         BREEZE BRAKE RING           126         1064015658         AIR FIITER           203         1044023214         FLEXURE BEAM (1BHM4023214)           206         1044018780A         FULCRUM FLEXURE           209         1044018779A         TENSION FLEXURE           214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX				
124         1074028244A         PAN SUPPORT ARM GUIDE           125         1044022117         BREEZE BRAKE RING           126         1064015658         AIR FIITER           203         1044023214         FLEXURE BEAM (1BHM4023214)           206         1044018780A         FULCRUM FLEXURE           209         1044018779A         TENSION FLEXURE           214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT         HR-AZ only           402         1071000619         BREEZE BRAKE BASE         HR-AZ only           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP RAIL           415         1072001349         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
125         1044022117         BREEZE BRAKE RING           126         1064015658         AIR FIITER           203         1044023214         FLEXURE BEAM (1BHM4023214)           206         1044018780A         FULCRUM FLEXURE           209         1044018779A         TENSION FLEXURE           214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         107300977C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
126         1064015658         AIR FIITER           203         1044023214         FLEXURE BEAM (1BHM4023214)           206         1044018780A         FULCRUM FLEXURE           209         1044018779A         TENSION FLEXURE           214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT         HR-AZ only           402         1071000619         BREEZE BRAKE BASE         HR-AZ only           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
203         1044023214         FLEXURE BEAM (1BHM4023214)           206         1044018780A         FULCRUM FLEXURE           209         1044018779A         TENSION FLEXURE           214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP RAIL           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
206         1044018780A         FULCRUM FLEXURE           209         1044018779A         TENSION FLEXURE           214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT         HR-AZ only           402         1071000619         BREEZE BRAKE BASE         HR-AZ only           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW         HR-AZ only           414         1073009777C         BREEZE BRAKE TOP SLIDE         BREEZE BRAKE TOP RAIL           415         1072001349         BREEZE BRAKE TOP RAIL         BREEZE BRAKE SIDE DOOR           418         1073009778C         BREEZE BRAKE SIDE DOOR         AX-FXI-31-EX         PROTECTIVE COVER(EX)				
209         1044018779A         TENSION FLEXURE           214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
214         1044030312A         2ND LEVER           305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
305         1134023285         MASS ELEVATING CUFF         HR-AZ only           313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
313         7PZ-4740         PUMP CONTROL BOARD (1PZ4740)         HR-AZ only           315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				HR-A7 only
315         1LMMAP1002A         COMPACT PUMP         HR-AZ only           316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
316         1LSCJV08-A03A1         SOLENOID VALVE         HR-AZ only           401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)			, ,	
401         1072001346B         BREEZE BRAKE FRONT           402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
402         1071000619         BREEZE BRAKE BASE           412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				/ LE Offing
412         1074020172         BREEZE BRAKE TOP FIXATION SCREW           414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
414         1073009777C         BREEZE BRAKE TOP SLIDE           415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
415         1072001349         BREEZE BRAKE TOP RAIL           418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
418         1073009778C         BREEZE BRAKE SIDE DOOR           AX-FXI-31-EX         PROTECTIVE COVER(EX)				
AX-FXI-31-EX PROTECTIVE COVER(EX)				
	- 110			
	500			
1073009456A PROTECTIVE COVER	300		-	









