
## AD

## 7Pin DIN to AD-8121 Printer CABLE WIRING

7 PIN DIN			DB25 AD-8121 Printer	
TXD	3	Orange	3	RXD
RXD	2	n/c	<u> </u>	
SG	5	Violet	7	SG

Remove 25 way DB25 connector from printer cable. Find the Orange and Violet wires and solder them to the Din connector as above.



View of Din Socket in panel

## **HV/W-G FUNCTION SETTINGS**

F4 Determines the Baud rate. Ensure it is set to the same as the printer.

F4 0 is the factory default: 2400bps

F5 Determines the Output mode.

F5 0 is the factory default, which is Stream mode.

Refer to section 15 of the HV/W-G Instruction Manual for more detail.