AD4329 Initialization Procedure

	KEY FUNCTION	DISPLAY
Step 1.	With the display off <mode> & <on></on></mode>	F-00
Step 2.	Press <mode></mode>	r101
Step 3.	Press <m+></m+>	CHECK
Step 4.	Press <mode></mode>	init
Step 5.	Press <tare> & <print></print></tare>	
	Indicator is now initialized	
Step 6.	Press < Operate/ Standby> twice	