Ridgeline 2 — User Manual

Two-person backpacking tent

In the bag

Inner tent, rain fly, one aluminium pole set, 12 pegs, 4 guy lines, repair patch and stuff sack. Total weight: 2.1 kg.

Pitching the tent

1. Choose a flat spot and clear away stones and sticks.
2. Lay out the inner tent and peg the four corners.
3. Assemble the pole set and clip the inner tent to the poles.
4. Throw the rain fly over the tent, match the colour-coded corners and fasten the buckles.
5. Peg out the guy lines, especially in wind.

Pitching takes about 8 minutes the first time and 4 minutes with practice.

Weather

The rain fly is waterproof to 3,000 mm. In strong wind, pitch the narrow end of the tent towards the wind.

Technical data

Property	Ridgeline 2
Sleeping places	2
Total weight	2.1 kg
Minimum weight (without pegs and stuff sack)	1.8 kg
Inner tent (length × width × height)	215 × 130 × 105 cm
Vestibules	2, each 0.8 m²
Rain fly	Ripstop polyester, 3,000 mm waterproof
Floor	Nylon, 5,000 mm waterproof
Poles	Aluminium, 8.5 mm
Packed size	45 × 16 cm
Seasons	3 (spring, summer, autumn)

Taking the tent down

Take the tent down in the reverse order. Shake out dirt and dry the tent before packing. Fold the poles from the middle to avoid stretching the elastic cord.

Spare parts

Spare poles, pegs and guy lines can be ordered from our customer support with the model name. Warranty on poles, frames and seams: 5 years.