

1. Powering On the Router

To turn on the router, plug the power adapter into the DC port.

Press and hold the power button on the back for 2 seconds.

The power LED turns solid green when the router is on.

2. Resetting the Router to Factory Settings

To reset the router, locate the small RESET pinhole on the back panel.

Using a paperclip, press and hold the RESET button for 10 seconds.

Release when all LEDs blink; the router restarts with default settings.

3. Troubleshooting: No Internet Connection

If the internet is down, first check that the WAN LED is solid green.

Try rebooting the router: unplug it, wait 10 seconds, then plug it back in.

If the problem persists, restart the router or contact support with your router serial number printed on the label underneath the device.