

FOREGROUND FOLDER //CNC\_MEM/USER/PATH1/  
BACKGROUND FOLDER //CNC\_MEM/USER/PATH1/

|           |              |            |      |
|-----------|--------------|------------|------|
| USED PAGE | 0 [KBYTE]    | USED FILES | 11   |
| FREE PAGE | 8291 [KBYTE] | FREE FILES | 1000 |

DEVICE : CNC MEM ( CURRENT FOLDER: /USER/LIBRARY/ )

RETURN TO UPPER FOLDER <FOLDER>

A>\_  
P: /F:5  
MDI \*\*\* 15:47:21

< F SET P SET CAN EXEC P GET