

Turning Maintenance Mode ON/OFF

Refer to [3A.2 Turning Maintenance Mode ON / OFF](#)

Confirming Pallet Number

Refer to [3A.3 Confirming Pallet Number](#)

Actuating APC Solenoid and Signal confirmation

Refer to [3A.4 Actuating APC Solenoid and Signal Confirmation](#)

APC Sequence and Recovery

Refer to [3A.5 APC Sequence and Recovery](#)

APC Sequence

Refer to [3A.5.1 APC Sequence](#)

APC Auto Recovery

Refer to [3A.5.2 APC Auto Recovery](#)

APC Manual Recovery

Refer to [3A.5.3 APC Manual Recovery](#)

APC Related Signal Details

Refer to [3A.6 APC Related Signal Details](#)