

Turning Maintenance Mode ON/OFF	Refer to 3B.2 Turning Maintenance Mode ON / OFF
Confirming Pallet Number	Refer to 3B.3 Confirming Pallet Number
Actuating APC Solenoid and Signal Confirmation	Refer to 3B.4 Actuating APC Solenoid and Signal Confirmation for Pallet UP/DOWN
Moving APC to Pallet 1 or 2 End positions	Refer to 3B.5 Moving APC to Pallet 1 or 2 End positions
Displaying APC position	Refer to 3B.6 Display of APC position
Moving APC Servo Axis	Refer to 3B.7 Moving APC servo axis
Inertia Active Control (IAC)	Refer to 3B.8 Inertia Active Control (IAC)
APC Sequence and Recovery	Refer to 3B.9 APC Sequence and Recovery
APC Sequence	Refer to 3B.9.1 APC Sequence
Condiiton for APC	Refer to 3B.9.1 A. Conditions to do Auto Pallet Change
Sequence	Refer to 3B.9.1 B. Sequence
Prepare pallet ready	Refer to 3B.9.1 C. Preparing Pallet Ready
Cancel pallet ready	Refer to 3B.9.1 D. Cancel Pallet Ready
APC auto recovery	Refer to 3B.9.2 APC Auto Recovery
APC manual recovery	Refer to 3B.9.3 APC Manual Recovery
APC Related Signal Details	Refer to 3B.10 APC Related Signal Details