

Turning Maintenance mode ON/OFF

Refer to [2.2 Turning Maintenance Mode ON / OFF](#)

Display of Spindle Tool Number

Refer to [2.3 Display of Spindle Tool Number](#)

Display of Magazine Index Pot

Refer to [2.4 Display of Magazine Index Pot](#)

Display of ATC Position

Refer to [2.5 Display of ATC Position](#)

Moving Magazine Servo Axis

Refer to [2.6 Moving Magazine Servo Axis](#)

Reference Position Return Operation

Refer to [2.6.1 Reference Position Return Operation](#)

Inching Operation

Refer to [2.6.2 Inching Operation](#)

Jog Operation

Refer to [2.6.3 Jog Operation](#)

Index Operation

Refer to [2.6.4 Index Operation](#)

Spindle Taper Clean

Refer to [2.7 Spindle Taper Clean](#)

Tool Change Position

Refer to [2.8 Tool Change Position](#)

ATC Sequence and Recovery

Refer to [2.9 ATC Sequence and Recovery](#)

ATC Auto Recovery

Refer to [2.9.1 ATC Auto Recovery](#)

ATC Manual Recovery

Refer to [2.9.2 ATC Manual Recovery](#)