

SRAM DATA UTILITY

- 1. SRAM BACKUP (CNC -) MEMORY CARD)
- 2. SRAM RESTORE (MEMORY CARD -) CNC)
- 3. AUTO BKUP RESTORE (FROM -) CNC)
- 4. END

*** MESSAGE ***

SELECT MENU AND HIT SELECT KEY.

(1 [SEL 2] [YES 3] [NO 4] [UP 5] [DOWN 6] 7)