

Fixture Configuration Explanation

Refer to [4.2 Fixture Configuration Explanation](#)

Fixture Setup Procedure

Refer to [4.3 Fixture Setup Procedure](#)

Fixture Status Screen

Refer to [4.3.1 Fixture Status Screen](#)

Condition Screen (Interlocking Between Stacks)

Refer to [4.3.2 Fixture Condition Screen](#)

Sequence Screen

Refer to [4.3.3 Fixture Sequence Screen](#)

Fixture Signal Details

Refer to [4.3.4 Fixture Signal Details](#)

Work Setup Side operation

Refer to [4.4 Work Setup Side Operation](#)

Work Setup Operator Panel

Refer to [4.4.1 Work Setup Operator Panel](#)

Work Setup Screen

Refer to [4.4.2 Work Selection Screen](#)

Auto Cycle Sequence

Refer to [4.4.3 Auto Cycle Sequence](#)

Fixture Coolant ON Timing

Refer to [4.4.4 Fixture Coolant ON Timing](#)

Work Setup Side Signal List

Refer to [4.4.5 Work Setup Side Signal List](#)