

AIR SEAT SENSOR

SEATING-1	LS1781	☐
SEATING-2	LS1782	☐
SEATING-3	LS1783	☐
SEATING-4	LS1784	☐
SEATING-5	LS1785	☐
SEATING-6	LS1786	☐
SEATING-7	LS1787	☐
SEATING-8	LS1788	☐

MDI **** LMG ALM 12:16:19  NONE

(COND.	SEQUENCE	INPUT	ON	MAINT
--------	----------	-------	----	-------