

ATC MAINTENANCE

MAINTENANCE MODE : OFF / ON

ATC RECOVERY : OFF / ON

SPINDLE TOOL POT : 0

MAGAZINE INDEX POT : 0

ATC POSITION : 0.000

FEED MODE : REF / INCH / JOG / INDEX

FEED OVERRIDE : 100% / 50% / 25% / 0%

INCHING DATA : 0.000

SP. TAPER CLEAN : OFF / ON

TOOL CHANGE POSITION

X : 0.000

Y : 0.205

Z : 0.000

INPUT LINE

OUTUT LINE

MDI ****

16:36:41



MAKINO

OFF

ON

