

Turning Maintenance mode ON/OFF	Refer to 2.2 Turning Maintenance Mode ON / OFF
Display of Spindle Tool Number	Refer to 2.3 Display of Spindle Tool Number
Display of Magazine Index Pot	Refer to 2.4 Display of Magazine Index Pot
Display of ATC Position	Refer to 2.5 Display of ATC Position
Moving Magazine Servo Axis	Refer to 2.6 Moving Magazine Servo Axis
Reference Position Return Operation	Refer to 2.6.1 Reference Position Return Operation
Inching Operation	Refer to 2.6.2 Inching Operation
Jog Operation	Refer to 2.6.3 Jog Operation
Index Operation	Refer to 2.6.4 Index Operation
Spindle Taper Clean	Refer to 2.7 Spindle Taper Clean
Tool Change Position	Refer to 2.8 Tool Change Position
ATC Sequence and Recovery	Refer to 2.9 ATC Sequence and Recovery
ATC Auto Recovery	Refer to 2.9.1 ATC Auto Recovery
ATC Manual Recovery	Refer to 2.9.2 ATC Manual Recovery