

M07 / M756 (Air Blow ON) is commanded or Air Blow is turned ON from main operation panel (Function Screen).

DO: SL181 0→1

Solenoid valve SL181 (Air Blow) is energized and air is supplied to tip of Spindle.

Workpiece machining is completed.

Solenoid valve SL181 (Air Blow) is de-energized and air supply stops.

DI: LS181 1→0