

Tool unclamping is commanded.

DO: SL01B 0→1

DO: SL01A 1→0

Solenoid valve SL01B (Tool Unclamp) is energized.

Hydraulic oil is supplied to rear of hydraulic cylinder
and the piston moves forward.

DI: LS00 1→0

Piston comes into contact with rear of draw bar
and draw bar compresses disk spring.

DI: LS601 1→0

DI: LS602 1→0

Collet closes and release Tool Holder.

Draw bar pushes Tool Holder out of Spindle Taper.

Limit switch LS01 (Tool Unclamp) changes from "0" to "1"

DI: LS01 0→1

Tool unclamp completed.