

\*OMAL1 circuit opens when malfunction occurs in spindle cooler.



DI: \*OMAL1 1→

Machine controller detects a malfunction and an alarm is triggered.



- Operation (program) stops.
- Feed axes stop (axis interlocks are applied).
- Spindle stops.
- Chip disposal devices stop.
- Spindle cooler controller pump stops.