

Author	Title	Description
Angellotti	test case 1 VF179	Parking assistance system - Pam status set in OFF

|

|


|

|

Step Name	Step Instruction
A	Power OFF Power ON Key ON No fault on the PAM
B	Set TRANSM2.ShiftLeverPosition=P and wait TFilter after Key on
C	Press the PAM button

--	--

Expected Result
Pam start initialization phase STATUS_PAM.signal = default value PARK_INFO.signal = default value STATUS_PAM.PAMSystemSts = ON_Inactive
PAM enter in the OFF state STATUS_PAM.PAMSystemSts = OFF STATUS_PAM.RearSensorSts = Active STATUS_PAM.PAM_LedControlSts = Continous light
LIN_BCM_IGW1.PAMRequestSts = Pressed PAM enter in ON_Inactive STATUS_PAM.PAMSystemSts = ON_Inactive STATUS_PAM.RearSensorSts = Active STATUS_PAM.PAM_LedControlSts = OFF PARK_INFO.DisplayActivation = Not Active



Requirement ID Link

PAM STATE 1.11.1.1.2


|

|

[illegible]

--	--

[illegible]



[illegible]

7.10.1 Parameters variable table (Development)

Parameter variable name (Dev)	Description
back_roll	Min speed for backward rolling logic
delta_distance	Delta distance object detection
max_actv_speed	Maximum speed value for PAM activation
max_voltage	Maximum Voltage supported
min_voltage	Minimum Voltage supported
std_tol	Tolerance speed for standstill vehicle
time_std_1	Debounce time for acoustic warning in standstill
time_std_2	Debounce time for acoustic warning for wall presence

7.10.2 EOL parameter table

EOL parameter name	Description	Default
actv_time	Roger beep duration	500 ms
Approaching Hysteresis	Hysteresis is used to avoid display flickering	0 mm
back_roll_presence	Backroll function	0x01
BB_presence	Balestrino presence	0x00
Departing Hysteresis	Hysteresis is used to avoid display flickering	40 mm
Dist_arc_1_max	Max distance Arc 1	400 m
Dist_arc_2_max	Max distance Arc 2	1050 m
Dist_arc_3_max	Max distance Arc 3	1350 m
Dist_arc_4_max	Max distance Arc 4	1650 m
hyst_speed	Hysteresis for speed activation conditions	1 km/h

Dist_arc_3_max	Max distance Arc 3	1350 m
Dist_arc_4_max	Max distance Arc 4	1650 m
hyst_speed	Hysteresis for speed activation conditions	1 km/h
lat_cover	Vehicle width	2550 m
lat_wall	Lateral wall function	0x01
Model	Vehicle model type	0x00
overhang_value	Overhang management	0 mm
rog_beep	Roger beep tone	0 ms
roger_beep_enable	Enable/disable roger beep sound	0x01
std_temp	Standard temperature	10 °C
temp_sens_presence	Temperature sensor presence	0x01
time_arc1	Duration time acoustic warning Arc_1	0 ms
time_arc2	Duration time acoustic warning Arc_1	100 ms

temp_sens_presence	Temperature sensor presence	0x01
time_arc1	Duration time acoustic warning Arc_1	0 ms
time_arc2	Duration time acoustic warning Arc_1	100 ms
time_arc3	Duration time acoustic warning Arc_1	200 ms
time_arc4	Duration time acoustic warning Arc_1	350 ms
trailer_hitch_presence	Trailer hitch installed on vehicle	0x00
Version	Vehicle version	0x00
wh_base	Vehicle wheelbase	3000 mm

	Default Value	Range [min; max]
	-2 km/h	[-5;0] km/h
	5 cm	[0;10] cm
	8 km/h	[0; 15]km/h
	16 V	[0;24] V
	9 V	[0;24] V
	1 km/h	[0;3] km/h
still	120 sec	[0;120] sec
presence	5 sec	[0;10] sec

	Default value	Value
	500 ms	[0;1500] ms
y flickering	0 mm	[0;50] mm
	0x01	0x00= logic disabled 0x01= logic enabled
	0x00	0x00= absent 0x01= present
y flickering	40 mm	[0;100] mm
	400 mm	[0;2000] mm
	1050 mm	[0;2000] mm
	1350 mm	[0;2000] mm
	1650 mm	[0;2000] mm
nditions	1 km/h	[0;5] km/h

EOS-4

The PAM

CCVS5_0
ETC2.Tra

If the foll
CCVS5_0
ETC2.Tra

If EOL pa

The PAM
obstacles
Active wi

If EOL pa
The PAM

EOS-4

The PAM

StsEcm2_
PB_BcmE

The syste
the follow

StsEcm2_
PB_BcmE

	1350 mm	[0;2000] mm
	1650 mm	[0;2000] mm
Conditions	1 km/h	[0;5] km/h
	2550 mm	[2000;3100] mm
	0x01	0x00= logic disabled 0x01= logic enabled
	0x00	0x00= 35S 0x01= 35C 0x02= 50C 0x03= 42S 0x04= 70C 0x05= 38S 0x06= 40C 0x07= 65C 0x08= 45C 0x09= 72C 0x0A= 60C 0x0B= 38S (35S) 0x0C= 38S (42S) 0x0D= Reserved 0x0E= Reserved 0x0F= Reserved
	0 mm	[0;400] mm
	0 ms	[0;375] ms
	0x01	0x00= Disabled 0x01= Enabled
	10 °C	[-10; 40] °C
	0x01	0x00= sensor absent 0x01= sensor present
c_1	0 ms	[0;375] ms
c_1	100 ms	[0;375] ms

	0x01	0x00= sensor absent 0x01= sensor present
c_1	0 ms	[0;375] ms
c_1	100 ms	[0;375] ms
c_1	200 ms	[0;375] ms
c_1	350 ms	[0;375] ms
	0x00	0x00= trailer hitch absent 0x01= trailer hitch present
	0x00	0x00= CAB LOW 0x01= CAB HIGH 0x02= VAN STANDARD 0x03= VAN POP 0x04= VAN DISABILI
	3000 mm	0x00= Invalid/Not Programmed 0x01= 3000mm 0x02= [3300;3450]mm 0x03= [3750;3950]mm 0x04= 4100mm 0x05= 4350mm 0x06= 4750mm 0x07= 3520mm 0x08= 3050mm (unused) 0x09= 3400mm (unused) 0x0A= [5000;5500]mm 0x0B= 5500mm (unused) 0x0C= Reserved 0x0D= Reserved 0x0E= Reserved 0x0F= Reserved

40868

shall monitor the following messages:

B.DirVehSpeed
InsmCurGear

Following conditions are verified (AND logic):

B.DirVehSpeed ≤ **back_roll**
InsmCurGear ≠ 0x7C Reverse

Parameter **back_roll_presence** = 0x01 (function available)

shall be activated (Active State) and inform the driver about the presence of
; (see 6.4.4 Active and
th object detection states)

Parameter **back_roll_presence** = 0x00 (function not available)
has to work in the normal way

40869

shall monitor the following messages:

_C.EassEngSts
Data_21.EassMngReq

em shall remain active until the engine is reactivated if
ving conditions are verified in (AND logic):

_C.EassEngSts = 00b
Data_21.EassMngReq = 1b