Launch Control XL 3 — Track 009 — happy house (one controller)

Classy, dry happy house in A major, 124 BPM. Jojo plays the foundation (kick, organ bass, drums, congas), Jonas the colour (piano, strings, guitar, Rhodes, voices) and the global column 8.

Every row means the same everywhere: row 1 = brightness, row 2 = space, row 3 = character, fader = level, button 1 = next pattern (at the next bar), button 2 = a moment while held.

Start with all faders down. Nothing sounds until Jonas' master fader (column 8) is up. Chapter (Jonas, column 8) changes the chords for everybody at the next 4-bar phrase.

One controller: Mode 1 = Jojo (foundation, columns 1–7; Jojo's column 8 (Shaker / Tamb.) stays off; Mode 1 sends the same CCs as Mode 16), Mode 2 = Jonas (colour). Column 8 is global on both pages.

Knob Fader Button global (all modes) unused

Mode 1 — Jojo: Foundation (beat + bass) · same CCs as Mode 16

	1 Kick	2 Noise Pump	3 Sub	4 Organ Bass	5 Clap + Snare	6 Hats	7 Congas	8 Global
Row 1 Brightness	CC 13 **Brightness** 0 = full and punchy ↔ extra click on top (lpf 3–16 kHz).	CC 14 **Brightness** dull whoosh ↔ airy hiss (lpf 2–14 kHz).	CC 15 **Brightness** 0 = sine with a few overtones (audible on small speakers) ↔ warm and full.	CC 16 **Brightness** 0 = round and woody ↔ reedy organ buzz (lpf 500–4000 Hz).	CC 17 **Brightness** warm ↔ sharp crack (lpf 3–14 kHz).	CC 18 **Brightness** soft hiss ↔ crisp and sharp (lpf 5–16 kHz).	CC 19 **Brightness** warm and woody ↔ crisp slap (lpf 2–14 kHz).	CC 20 **Fog** 0 = clear, up = every filter pulled down to ~6 %: muffled, as if from outside the club.
Row 2 Space	CC 21 **Space** dry and close ↔ in a room (reverb).	CC 22 **Space** dry ↔ far away (reverb + echo).	CC 23 **Space** dry ↔ a little room (reverb).	CC 24 **Space** dry ↔ a little room (reverb).	CC 25 **Space** dry ↔ far away (reverb + echo).	CC 26 **Space** dry ↔ far away (reverb + echo).	CC 27 **Space** dry ↔ far away (reverb + echo).	CC 28 **Room** 0 = each sound's own room (row 2), up = everything drowns in reverb.
Row 3 Character	CC 29 **Softness** 0 = punchy 909 kick ↔ 1 = soft, round thump.	CC 30 **Motion** still ↔ the filter breathes and the noise wanders left and right.	CC 31 **Length** long, pumping notes ↔ short, bouncing ones.	CC 32 **Groove** the line as it is ↔ extra 16th notes bouncing in between.	CC 33 **Ghost notes** plain ↔ a quiet clap before beat 3 ↔ + small double taps.	CC 34 **Density** the pattern as it is ↔ + quiet 16ths ↔ + little 32nd rolls.	CC 35 **Density** steady pattern ↔ + fingertip ghost notes ↔ + agogo bells.	CC 36 **Tension** build-up: echo grows, filters open, from the middle a snare roll (clap fader). 0 = release.
Fader Level	CC 5 **Level** 0 = gone. Four-on-the-floor kick, tuned to A.	CC 6 **Level** noise that pumps with the kick.	CC 7 **Level** sub on the chord's bass note, follows the chapter.	CC 8 **Level** organ bass, follows the chapter.	CC 9 **Level** clap + snare on 2 and 4. Also the level of Tension's snare roll.	CC 10 **Level** off-beat open hat. Keeps playing in the break.	CC 11 **Level** congas and bongos. Keep playing in the break.	CC 12 **Master Level** volume of everything, both controllers. 0 = silence.
Button 1 Change	CC 37 **Change** straight → pickup before the 1 → gap every 4th bar.	CC 38 **Change** pump → off-beat → swoosh (2 bars).	CC 39 **Change** pump → off-beat → half bars.	CC 40 **Change** organ off-beat → octave bounce → funk.	CC 41 **Change** plain → pickup → double clap.	CC 42 **Change** off-beat → + 16ths → disco (swelling 16ths).	CC 43 **Change** pillow → gallop → latin.	CC 44 **Chapter** next chord progression for all, at the next 4-bar phrase.
Button 2 Moment	CC 45 **Drop out** kick pauses while held.	CC 46 **Riser** a noise sweep rises over 2 bars while held.	CC 47 **Slide** every note bends up into its pitch while held.	CC 48 **Octave** one octave up while held.	CC 49 **Roll** snare roll, growing over the bar, while held.	CC 50 **Open** open hats on every 8th while held.	CC 51 **Fill** a conga run over the bar while held.	CC 52 **Break / Drop** 1st: beat out. 2nd: all back on the one.

Mode 2 — Jonas: Colour (chords + melodies) · CC + 48

	1 Strings	2 Piano	3 Funk Guitar	4 Vocal Hook	5 Organ	6 Rhodes	7 Choir Chops	8 Global
Row 1 Brightness	CC 61 **Brightness** soft and far ↔ silky, bright (lpf 1.5–10 kHz).	CC 62 **Brightness** warm ↔ bright, ringing (lpf 1.5–14 kHz).	CC 63 **Brightness** warm and muted ↔ bright, snappy (lpf 1.5–12 kHz).	CC 64 **Brightness** soft and hushed ↔ open, clear voice (lpf 1–8 kHz).	CC 65 **Brightness** soft ↔ clear and bright (lpf 1.5–10 kHz).	CC 66 **Brightness** soft and mellow ↔ bell-like tine (lpf 1.5–12 kHz).	CC 67 **Brightness** muffled ↔ bright, airy voices (lpf 1.5–10 kHz).	CC 20 **Fog** 0 = clear, up = every filter pulled down to ~6 %: muffled, as if from outside the club.
Row 2 Space	CC 69 **Space** dry ↔ a big hall (reverb + echo).	CC 70 **Space** dry ↔ the echoes repeat into the room.	CC 71 **Space** dry ↔ far away (reverb + echo).	CC 72 **Space** dry ↔ far away (reverb + echo).	CC 73 **Space** dry ↔ far away (reverb + echo).	CC 74 **Space** dry ↔ far away (reverb + echo).	CC 75 **Space** dry ↔ far away (reverb + echo).	CC 28 **Room** 0 = each sound's own room (row 2), up = everything drowns in reverb.
Row 3 Character	CC 77 **Pump** 0 = held strings. Up = they pump with the kick (re-struck every beat, like a sidechain).	CC 78 **Length** stabs that ring a little ↔ short, choppy stabs.	CC 79 **Density** a few notes of the riff ↔ every 16th, plus a lower string.	CC 80 **Glide** plain notes ↔ notes bend gently into their pitch (at most a semitone).	CC 81 **Voices** 0 = single notes, 0.5 = + the chord tone below, 1 = + two below: full organ stabs.	CC 82 **Density** a few notes per bar ↔ busy licks (~60 % of the 16ths).	CC 83 **Amount** subtle (the rhythm only) ↔ + extra “ooh” chops an octave up, with echo.	CC 36 **Tension** build-up: echo grows, filters open, from the middle a snare roll (clap fader). 0 = release.
Fader Level	CC 53 **Level** strings on the chapter's chords.	CC 54 **Level** house piano on the chapter's chords.	CC 55 **Level** funk guitar on the chord.	CC 56 **Level** the vocal hook on the chord.	CC 57 **Level** organ phrase, every second bar.	CC 58 **Level** Rhodes licks on the chord.	CC 59 **Level** choir chops on the chord.	CC 12 **Master Level** volume of everything, both controllers. 0 = silence.
Button 1 Change	CC 85 **Change** high chord → octave line (disco) → low and warm.	CC 86 **Change** next of 6 piano riffs.	CC 87 **Change** next of 6 guitar riffs.	CC 88 **Change** next of 8 hooks.	CC 89 **Change** next of 8 phrase rhythms (new notes too).	CC 90 **Change** next of 8 random licks.	CC 91 **Change** next of 8 chop rhythms (new notes too).	CC 44 **Chapter** next chord progression for all, at the next 4-bar phrase.
Button 2 Moment	CC 93 **Freeze** holds the current chord while held, for everybody.	CC 94 **Stab** a chord on every off-beat while held.	CC 95 **Strum** full chord strums on the off-beats while held.	CC 96 **Echo throw** long echo on the hook while held.	CC 97 **Answer** the phrase plays in every bar while held.	CC 98 **Run** a quick run up the chord while held.	CC 99 **Stutter** the chop stutters on every 16th while held.	CC 52 **Break / Drop** 1st: beat out. 2nd: all back on the one.

Guide

Playing together

Jojo builds the floor: kick first, then sub and the off-beat hats, then clap, organ bass and the groove (congas, shaker). The noise pump glues to the kick.

Jonas colours it: the piano first (it is the heart of the track), then guitar or Rhodes. Strings, vocal hook and choir chops are for the peaks.

Chapter changes the chords for both players at the next 4-bar phrase: sub, bass and every melody follow. Strings button 2 (freeze) holds the chord for everybody.

Build-up and drop: Jonas turns Tension up (echo, open filters, snare roll), presses Break at the top: the beat goes out, piano and strings float. Jojo holds the noise riser, Jonas presses Break again: everything is back on the one. Then let Tension go.

Every position sounds good

Space 0 is dry and close, as the track is meant to be; room is a colour you add. No filter closes completely.

Status box

The status box at the bottom right of the Strudel page shows chapter, break and each stem's pattern. Its button “als Fenster” opens it as a small window that stays on top (Chrome/Edge).

Playing alone

A run is: build the beat in Mode 1, switch to Mode 2, add colour, use column 8 for the drop. Mode 1 is set up in Components with the same CCs as Mode 16.

Faders are shared hardware: after a mode switch each sound keeps its value until you touch its fader, then it jumps to where the fader physically is. Move faders gently after switching.