Launch Control XL 3 — House Keys Lab 5 (lab/keys, round 5 for 009: blends at equal loudness)

Column 1 = the favourite patterns with the sound mix. Columns 2-8 = seven softer organs, each alone (the mix knobs do not affect them), same patterns on button 1. Pull up one fader at a time.

Sound: hold any column's button 2 and turn its knobs: 1 = piano → Rhodes, 2 = B3 → M1, 3 = vibraphone → marimba. Each knob: 0 silent, first third the first sound fades in, middle third blends into the second at equal loudness, last third the second fades out. Also with shift: fader 1 = echo, fader 2 = touch, column 5 button 1 = harmony, fader 6 = drums, fader 7 = bass. In Mode 2: faders 1-4 = grand, Rhodes, organ, vibraphone layers; knob 3 above each changes its character. Column 5 button 1 = harmony.

"? LC groß" in the status box opens the dashboard: every control, its value, the pattern and the beat.

Knob | Fader | Button | unused

Mode 16 — Rhythms

	1 Mix	2 Mix played	3 Drawbar	4 Sine 8'+4'	5 Sine + fifth	6 Triangle	7 M1 built	8 B3 + Leslie
Row 1 Brightness	CC 13 **Brightness** dull ↔ bright (lpf 250 Hz – 12 kHz, a little resonance): the filter sweep.	CC 14 **Brightness** as 1 Mix	CC 15 **Brightness** as 1 Mix	CC 16 **Brightness** as 1 Mix	CC 17 **Brightness** as 1 Mix	CC 18 **Brightness** as 1 Mix	CC 19 **Brightness** as 1 Mix	CC 20 **Brightness** as 1 Mix
Row 2 Space	CC 21 **Space** 0 = dry ↔ a room.	CC 22 **Space** as 1 Mix	CC 23 **Space** as 1 Mix	CC 24 **Space** as 1 Mix	CC 25 **Space** as 1 Mix	CC 26 **Space** as 1 Mix	CC 27 **Space** as 1 Mix	CC 28 **Space** as 1 Mix
Row 3 Length	CC 29 **Length** 0 = short stab ↔ hits ring four times longer.	CC 30 **Length** as 1 Mix	CC 31 **Length** as 1 Mix	CC 32 **Length** as 1 Mix	CC 33 **Length** as 1 Mix	CC 34 **Length** as 1 Mix	CC 35 **Length** as 1 Mix	CC 36 **Length** as 1 Mix
Fader Level	CC 5 **Level** the layer mix (shift knobs: piano → Rhodes, B3 → M1, vibraphone → marimba).	CC 6 **Level** like column 1, without echo, played: hits on the off-beat 8ths hard, on the beat medium, the 16ths in between soft.	CC 7 **Level** drawbar organ, darker, soft attack.	CC 8 **Level** synth organ from two sines (drawbars 8' + 4'): the softest.	CC 9 **Level** like 4 plus the fifth above (drawbar 2 2/3'): rounder, a bit more organ.	CC 10 **Level** triangle wave, filtered: a soft synth organ.	CC 11 **Level** Korg M1 Organ 2, built from waves: hollow, with a short percussive tock (90s house). As loud as the B3.	CC 12 **Level** Hammond B3 built from sines (drawbars 888) with a slow Leslie swirl: warm, gospel.
Button 1 Change	CC 37 **Change** 7 patterns: chain → shifted chain → pairs → 3-3-2 → Kerri off-beat → Kerri syncope → Kerri riff (video).	CC 38 **Change** as 1 Mix	CC 39 **Change** as 1 Mix	CC 40 **Change** as 1 Mix	CC 41 **Change** as 1 Mix	CC 42 **Change** as 1 Mix	CC 43 **Change** as 1 Mix	CC 44 **Change** as 1 Mix
Button 2 Shift (hold)	CC 45 **Shift** press = on / off: the 3 knobs mix the sound (piano → Rhodes, B3 → M1, vibraphone → marimba); fader 1 = echo, fader 2 = touch.	CC 46 **Shift** as 1 Mix	CC 47 **Shift** as 1 Mix	CC 48 **Shift** as 1 Mix	CC 49 **Shift** as 1 Mix	CC 50 **Shift** as 1 Mix	CC 51 **Shift** as 1 Mix	CC 52 **Shift** as 1 Mix

Mode 2 — Sound + global

	1 Grand	2 Rhodes	3 Organ	4 Vibraphone	5 Harmony	6 Drums	7 Bass	8
Row 1	CC 61 —	CC 62 —	CC 63 —	CC 64 —	CC 65 —	CC 66 **Swing** 50 % straight ↔ 70 %; 55–58 % = house.	CC 67 —	CC 68 —
Row 2	CC 69 —	CC 70 —	CC 71 —	CC 72 —	CC 73 —	CC 74 —	CC 75 —	CC 76 —
Row 3	CC 77 **M1** 0 = plain grand ↔ the 90s house piano (detuned, e-piano octave, a little grit).	CC 78 **Phaser** 0 = plain ↔ slow, deep phaser swirl.	CC 79 **M1** 0 = B3 ↔ M1, blended at equal loudness.	CC 80 **Marimba** 0 = vibraphone ↔ woody marimba, blended at equal loudness.	CC 81 —	CC 82 —	CC 83 —	CC 84 —
Fader Level	CC 53 **Grand** layer level: dry grand piano.	CC 54 **Rhodes** layer level: warm electric piano.	CC 55 **Organ** layer level: B3 and M1 organ (columns 8 and 7).	CC 56 **Vibraphone** layer level: soft, jazzy mallets.	CC 57 —	CC 58 **Drums** 909 kick, off-beat hat, clap, shaker.	CC 59 **Bass** off-beat bass on the chord root.	CC 60 —
Buttons 1	CC 85 —	CC 86 —	CC 87 —	CC 88 —	CC 89 **Harmony** one chord (Am9) ↔ System (Am9 – Gm9 – Am9 – Dm9), next 4 bars.	CC 90 —	CC 91 —	CC 92 —
Buttons 2	CC 93 —	CC 94 —	CC 95 —	CC 96 —	CC 97 —	CC 98 **Drums out** keys and bass alone while held.	CC 99 —	CC 100 —

Guide

Changing the sound

Three levels, from quick to deep. 1. Brightness (row 1 in Mode 16): the house filter sweep, the most used move of all. Length (row 3): a short, dry stab ↔ ringing chords. 2. The layer mix (Mode 2 faders 1-4): grand + organ = the thick 90s piano, Rhodes + vibraphone = soft and deep. 3. Each layer's character (Mode 2 knob 3): grand → M1 piano, Rhodes → phaser, organ → drawbar, vibraphone → marimba.

Why off the kick

Stab rhythms that avoid the kick and sit on the off-16ths pull against the beat; hits on the kick double it and sound like a band. Two hits and 3-3-2 do start on the one: that is their weight.

Constancy

Every pattern repeats unchanged (one or two bars long). Change comes from you: filter, length, layers, another pattern.

Harmony

All chords in Kerri Chandler's shape: the 7th at the bottom, the 9 instead of the root, moved as a block. 1 one chord (Am9), 2 “My System” (Am9 – Gm9 – Am9 – Dm9), the chord changes pushed two 16ths early. Pattern 7 (Kerri riff) plays the video's own chords: use it with harmony 1.