Launch Control XL 3 — Track 011 — continuum (two controllers)

One set on one continuum: ambient → ambient house → house → groove techno. Every column stays the same instrument all the way; the set position only changes its parameters.

Set position: hold Chapter (Jonas, column 8, button 1) and turn Fog. Released without turning = next chapter. The position glides, a whole sweep takes at least 25 seconds.

Every row means the same everywhere: row 1 = brightness, row 2 = space, row 3 = character, fader = level, button 1 = next pattern (at the next bar), button 2 = a moment while held.

Start with all faders down. Nothing sounds until Jonas' master fader (column 8) is up.

Knob | Fader | Button | global (all modes) | unused

Jojo — Foundation (beat + bass)

	1 Kick	2 Rumble / Breath	3 Sub	4 Bass	5 Clap	6 Hats / Shaker	7 Perc / Toms	8 Ride
Row 1 Brightness	CC 13 **Brightness** dull thump ↔ clicky attack. The range opens towards house.	CC 14 **Brightness** dark ↔ airy hiss (and more of the rumble's body).	CC 15 **Brightness** pure sine ↔ a warm triangle on top (audible on small speakers).	CC 16 **Brightness** round and dark ↔ buzzing, squelchy.	CC 17 **Brightness** soft ↔ sharp crack.	CC 18 **Brightness** soft hiss ↔ crisp and sharp.	CC 19 **Brightness** woody ↔ metallic.	CC 20 **Brightness** dark wash ↔ bright sizzle.
Row 2 Space	CC 21 **Space** dry and close ↔ far away (reverb).	CC 22 **Space** close ↔ a long dark cloud.	CC 23 **Space** dry ↔ a little room.	CC 24 **Space** dry ↔ a little room.	CC 25 **Space** dry ↔ far away (reverb + echo).	CC 26 **Space** dry ↔ far away (reverb + echo).	CC 27 **Space** dry ↔ far away (reverb + echo).	CC 28 **Space** dry ↔ far away (reverb + echo).
Row 3 Character	CC 29 **Punch** 0 = the position's basic kick ↔ harder: bigger pitch drop, faster attack, more click.	CC 30 **Motion** the position's breathing ↔ deeper breaths, the noise wanders left and right, the rumble echoes.	CC 31 **Length** the position's length ↔ short, bouncing notes.	CC 32 **Groove** the line as it is ↔ extra 16th notes rolling in between.	CC 33 **Ghost notes** plain ↔ a quiet rim before beat 3 ↔ + small double taps.	CC 34 **Hats ↔ Shaker** 0 = metallic hat ↔ middle = both ↔ 1 = grainy shaker (same rhythm).	CC 35 **Density / Toms** the pattern ↔ + fingertip ghost notes ↔ + low toms at the end of the bar.	CC 36 **Swing** straight ↔ swung, lazy (the in-between 16ths come late).
Fader Level	CC 5 **Level** 0 = gone. Ambient: heartbeat · house, techno: four on the floor. Always on A.	CC 6 **Level** ambient: sea waves · house: noise pumping with the kick · techno: rumble between the kicks.	CC 7 **Level** sub on the chord root, follows the chapter.	CC 8 **Level** bass on the chord, follows the chapter.	CC 9 **Level** ambient: rim click · house, techno: clap on 2 and 4. Also the level of Tension's snare roll.	CC 10 **Level** ambient: clock ticks · house: off-beat hat · techno: off-beat + 16ths. Keeps playing in the break.	CC 11 **Level** ambient: wood clicks · house: congas, rim figure · techno: bongos. Keeps playing in the break.	CC 12 **Level** ambient: a cymbal swell · house, techno: ride on the off-beats. Keeps playing in the break.
Button 1 Change	CC 37 **Change** basic → pickup before the 1 → a gap every 4th bar.	CC 38 **Change** basic → denser → slow waves everywhere.	CC 39 **Change** basic → off-beat → one long note per bar.	CC 40 **Change** basic → off-beat → melodic.	CC 41 **Change** basic → pickup → with rim figure.	CC 42 **Change** basic → + 16ths → driving.	CC 43 **Change** basic → livelier → sparse.	CC 44 **Change** basic → 8ths → 16ths.
Button 2 Moment	CC 45 **Drop** kick, rumble and sub pause while held.	CC 46 **Riser** a noise sweep rises over 2 bars while held.	CC 47 **Slide** every note bends up into its pitch while held.	CC 48 **Octave** one octave up while held.	CC 49 **Roll** snare roll, growing over the bar, while held.	CC 50 **Open** every hit rings long while held (shaker: a long “shhh”).	CC 51 **Fill** a tom run down over the bar while held.	CC 52 **Double** double time while held.

Jonas — Colour (chords + melodies) · column 8 = global

	1 Pad	2 Chords	3 Arp	4 Lead	5 Voice	6 Bells	7 Air / FX	8 Global
Row 1 Brightness	CC 13 **Brightness** muffled ↔ open and airy.	CC 14 **Brightness** warm ↔ bright, barking.	CC 15 **Brightness** soft plucks ↔ sharp, sparkling.	CC 16 **Brightness** soft and round ↔ biting.	CC 17 **Brightness** hushed ↔ clear.	CC 18 **Brightness** soft glow ↔ ringing, bright.	CC 19 **Brightness** dark whoosh ↔ bright hiss.	CC 20 **Fog** 0 = clear, up = every filter pulled down to ~6 %. While Chapter is held: the set position.
Row 2 Space	CC 21 **Space** dry and close ↔ far away in a big room (reverb + echo).	CC 22 **Space** dry ↔ the echoes repeat far into the room.	CC 23 **Space** a little room ↔ far away (reverb + echo).	CC 24 **Space** a little room ↔ far away (reverb + echo).	CC 25 **Space** dry ↔ far away.	CC 26 **Space** dry ↔ far away (reverb + echo).	CC 27 **Space** some room ↔ far away (reverb + echo).	CC 28 **Room** 0 = each sound's own room (row 2), up = everything drowns in reverb.
Row 3 Character	CC 29 **Motion** the position's motion ↔ the pad sweeps slowly (phaser).	CC 30 **Length** the position's length ↔ short, choppy stabs.	CC 31 **Range** some notes left out ↔ every note, some an octave up.	CC 32 **Glide** the position's slide ↔ notes slide further into their pitch.	CC 33 **Voices** the position's voices ↔ + a third ↔ + a fifth above.	CC 34 **Density** the position's few notes ↔ a busy pattern.	CC 35 **Amount** only the breathing air ↔ chord tones pulse along ↔ + a shimmer an octave up.	CC 36 **Tension** build-up: echo grows, filters open, from the middle a snare roll (clap fader). 0 = release.
Fader Level	CC 5 **Level** the chapter's chords as a long pad.	CC 6 **Level** chord hits on the chapter's chords.	CC 7 **Level** arp on the chord.	CC 8 **Level** lead on the chord.	CC 9 **Level** ambient: choir · house: vocal chops · techno: vowel blips.	CC 10 **Level** glockenspiel on the chord.	CC 11 **Level** ambient: wind · house, techno: a slow breathing whoosh.	CC 12 **Master Level** volume of everything, both controllers. 0 = silence.
Button 1 Change	CC 37 **Change** voicing: warm → open → wide.	CC 38 **Change** basic → busier → other rhythm.	CC 39 **Change** basic → second shape → third shape.	CC 40 **Change** basic → second line → third line.	CC 41 **Change** basic → second phrase → third phrase.	CC 42 **Change** next of 3 random patterns.	CC 43 **Change** one breath per 2 bars → per 4 bars → every bar.	CC 44 **Chapter / Set** tap = next chapter. Hold + turn Fog = set position.
Button 2 Moment	CC 45 **Freeze** holds the current chord while held, for everybody.	CC 46 **Stab** a chord on every off-beat while held.	CC 47 **Octave** one octave up while held.	CC 48 **Echo throw** long echo on the lead while held.	CC 49 **Choir** all three voices while held.	CC 50 **Run** runs over the chord, filling in while held.	CC 51 **Rise** chord tones climb an octave while held.	CC 52 **Break / Drop** 1st: beat out. 2nd: all back on the one.

Guide

The continuum

Position 0 is ambient (soft heartbeat, sea, rim click on 3, clock ticks, wood clicks), a third is ambient house, two thirds house, the end groove techno. Nothing is swapped on the way: the heartbeat's second thump fades while beats 2 and 4 grow, the sub slides from the 1 behind the kick, the ticks open into an off-beat hat.

The tempo follows: 120 in the ambient half (felt half time), 128 in house, 140 in techno.

Moving through the set

Jonas holds Chapter and turns Fog: the position follows slowly (a whole sweep takes at least 25 seconds), so even a fast turn becomes a transition. Fog keeps its own value while the button is held.

Every position sounds good

All knobs at 0 is the basic sound of the position: a soft thump in ambient, a firm kick in house, a hard one in techno. Turning up adds, it does not repair.