

River Test Report

Summary								
Serial Number	BDDCTC015254							
Configuration Name	DTU_FCT_RX_RY2							
River EOL Doc Version	T0_DTU_V2.1							
Date	24-06-2026_16-37-39							
Operator	Admin							
DUT	1							
Cycle time	538.04							
Overall Results	Pass							
Results								
Cycle time 538.04								
Power Lines Impedance check	Config DAQ(1)						1.54	
Power Lines Impedance check	Read RES TP19-TP3	5.00	151.85	Inf	Pass	Kohm	7.02	
Power Lines Impedance check	Config DAQ(3)						1.54	
Power Lines Impedance check	Read_RES_TP2-TP3	5.00	40.77	Inf	Pass	Kohm	6.92	
Power Lines Impedance check	Config DAQ(5)						1.54	
Power Lines Impedance check	Read_RES_TP7-TP9	3.00	93.59	Inf	Pass	Kohm	6.92	
Power Lines Impedance check	Config DAQ(7)						1.54	
Power Lines Impedance check	Read_RES_TP12-TP3	3.00	4.17	Inf	Pass	Kohm	6.92	
J9 impedance check	Config DAQ(11)						1.54	
J9 impedance check	Read_RES_TP48-TP41	117.00	121.81	123.00	Pass	ohm	6.78	
Power up	Set_14_PS1						1.54	
Power up	Set_14V_ps_to 3A						1.54	
Power up	Turn ON +14V & GND Relays						1.53	
Power up	Turn_on_14VPS						0.74	
Power up	Config DAQ(18)						1.54	
Power up	Read_VOL_TP66-TP3	2.45	2.71	2.80	Pass	V	6.71	
Voltage Measurements	Config DAQ(21)						1.54	
Voltage Measurements	Read_VOL_TP02-TP03	4.90	5.09	5.20	Pass	V	7.03	
Voltage Measurements	Config DAQ(19)						1.54	
Voltage Measurements	Read_VOL_TP19-TP3	13.90	13.99	14.10	Pass	V	8.13	
Voltage Measurements	Config_DAQ(22)						1.54	

Voltage Measurements	Read_VOL_TP7-TP9	3.70	3.83	3.90	Pass	V	8.39
Voltage Measurements	Config DAQ(23)						1.54
Voltage Measurements	Read_VOL_TP12-TP13	2.90	3.07	3.10	Pass	V	8.42
MCU Software Flash	Flash Software		PASS		Pass		6.39
MCU Software Flash	Power_CYCLE(1)						1.53
MCU Software Flash	Off_14V(1)						1.54
MCU Software Flash	On_Power_cycle(1)						1.53
MCU Software Flash	On_14V(1)						5.54
S.No_write and read	Write_Barcode						2.64
S.No_write and read	Read_barcode_STATUS		62 1		Pass		5.54
S.No_write and read	Power14Voff(1)						2.54
S.No_write and read	Poweron14V(1)						2.54
S.No_write and read	Send_Request_Barcode						1.54
S.No_write and read	Read_barcode_written		BDDCTC015254		Pass		6.77
S.No_write and read	Write_RX_RY_check						2.54
Pre-Flash Neoway	SET_USB_RELAY						1.54
Neoway Flashing	Set Boot Mode						5.54
Neoway Flashing	Set_To_Boot_mode						5.54
Neoway Flashing	Set_USB_relay_on						1.53
Neoway Flashing	Flash Software(1)		success		Pass		23.20
Neoway Flashing	Reset_Boot_Mode						10.54
Post Neoway Flash	Read_boot_mode_status		6F		Pass		10.54
Post Neoway Flash	Read_boot_state_again		6F 0		Pass		10.54
Post Neoway Flash	On_power						1.53
Post Neoway Flash	OFF_14V_supply						1.54
Post Neoway Flash	ON_14V_again(1)						10.54
Check N58 Flash	Send_N58_Check_msg						10.54
Check N58 Flash	Send_again_n58_flash_msg						10.54
Check N58 Flash	Resend_N58_Rest msg						2.54
Check N58 Flash	Read-check_ssl		20492		Pass		0.74
SSL Certification	Connect USB relays						1.53
SSL Certification	Read_Set_SSL		OKAY		Pass		20.04
SSL Certification	Power_off_ssl						1.54

SSL Certification	Power_on_SSL						2.54
SSL Certification	Send_msg_22x10						20.54
SSL Certification	Send _22x10 again						20.54
SSL Certification	Read_SSL_DeviceID		20492		Pass		25.54
SSL Certification							20.54
Firmware Version	Get_FW_Ver_Info						1.54
Firmware Version	Read_FW_VER		0 0 76		Pass		1.54
Hardware Version	Read_HW_VER		3 0		Pass		1.54
Active Current Check	Send_0x4401_active current						1.54
Active Current Check	Read_active_current	0.00	39.00	200.00	Pass	mA	3.53
Active Current Check	Set_12V_ps						2.04
Active Current Check	Set_current_to_3A						1.04
Active Current Check	On_12V_Power						0.64
FCT Initialization	Read_FCT_Initialize ack		1		Pass		5.54
FCT Initialization	Send GPS command						1.54
Highbeam Indicator Check	Turn ON HB_IND						1.53
Highbeam Indicator Check	Config DAQ(27)						1.54
Highbeam Indicator Check	Read Vol_TP52	5.00	5.15	Inf	Pass	V	6.57
Highbeam Indicator Check	Read_ON_HB		1		Pass		2.54
Highbeam Indicator Check	Turn OFF HB_IND						1.53
Highbeam Indicator Check	Config DAQ(28)						1.54
Highbeam Indicator Check	Read_VOL_TP52(1)	0.00	0.00	0.10	Pass	V	6.81
Highbeam Indicator Check	Read_OFF_HB		0		Pass		1.54
Left Indicator Check	Turn ON L_IND						1.53
Left Indicator Check	Config DAQ(29)						1.54
Left Indicator Check	Read Vol_TP50	5.00	5.15	Inf	Pass	V	6.60
Left Indicator Check	Read_ON_L		1		Pass		1.54
Left Indicator Check	Turn OFF L_IND						1.53
Left Indicator Check	Config DAQ(30)						1.54
Left Indicator Check	Read_VOL_TP50(1)	0.00	0.00	0.10	Pass	V	6.81
Left Indicator Check	Read_OFF_L		0		Pass		1.54
Right Indicator Check	Turn ON R_IND						1.53
Right Indicator Check	Config DAQ(31)						1.54

Right Indicator Check	Read_VOL_TP51	5.00	5.15	Inf	Pass	V	6.60
Right Indicator Check	Read_ON_R		1		Pass		1.54
Right Indicator Check	Turn OFF R_IND						1.53
Right Indicator Check	Config DAQ(32)						1.54
Right Indicator Check	Read Vol_TP51	0.00	0.00	0.10	Pass	V	6.81
Right Indicator Check	Read_OFF_R		0		Pass		1.04
Tactile Switch Check	Turn ON SW1						1.53
Tactile Switch Check	Read_ON_SW1		1		Pass		1.54
Tactile Switch Check	Turn OFF SW1						1.53
Tactile Switch Check	Turn ON SW2						1.53
Tactile Switch Check	Read_ON_SW2		1		Pass		1.54
Tactile Switch Check	Turn OFF SW2						1.53
GPS_Test	GPS_CMD(1)						60.54
GPS_Test	Read_GPS		12.814,77.669		Pass		1.54
FCT Termination	Uninit FCT						1.54
FCT Termination	Turn OFF +14V						1.53
FCT Termination	Off14V						1.54
FCT Termination	off12V						1.54