Aurora X2 Smart Thermostat User Manual

1. In the box

Aurora X2 thermostat, wall plate, trim plate, 4 screws and anchors, wire labels, C-wire adapter, quick start card.

2. Before you install

Turn off power to your heating and cooling system at the breaker before removing your old thermostat. The Aurora X2 works with most 24 V systems: gas, oil and electric furnaces, heat pumps with auxiliary heat, and boilers. It is not compatible with 120 V or 240 V line-voltage systems such as electric baseboard heaters.

A common wire (C-wire) is strongly recommended. If your system has no C-wire, install the included C-wire adapter at the furnace control board; see section 4.

3. Wiring

Terminal	Typical wire colour	Function
R / Rh	Red	24 V power
C	Blue or black	Common (return path for power)
W1	White	Heat stage 1
Y1	Yellow	Cooling stage 1 / compressor
G	Green	Fan
O/B	Orange or dark blue	Heat pump reversing valve

Insert each wire into the terminal that matches the label you put on it when removing the old thermostat. Wire colours are conventions only; always follow the labels rather than the colours.

4. Installing the C-wire adapter

Connect the adapter to the R, C, W and Y terminals on the furnace control board as shown on the adapter label, then connect the existing thermostat wires to the adapter. The adapter lets the Aurora X2 draw steady power without needing a new cable.

5. Connecting to the Aurora app

Download the Aurora Home app, create an account and tap Add device. Hold the Menu button on the thermostat for 3 seconds until the screen shows a pairing code, then enter the code in the app. The thermostat supports 2.4 GHz Wi-Fi networks only.

6. Schedules and Eco mode

The default schedule keeps 21 °C from 06:30 to 22:00 and 17 °C overnight. You can create up to 6 temperature periods per day in the app. Eco mode lowers the heating setpoint by 3 °C (or raises the cooling setpoint by 3 °C) while everyone is away, using phone geofencing. Households in the pilot programme saved on average 14% on heating costs with Eco mode enabled.

7. Error codes

Code	Meaning	What to do
E1	Temperature sensor fault	Restart the thermostat. If it persists, contact support.
E2	Wi-Fi connection lost	Check your router, then re-pair from the app.
E3	Wiring mismatch detected	Turn off power and check wires against the labels.
E4	Low or unstable power (below 18 V)	Check that the C-wire is connected at both ends, or install the C-wire adapter.
E5	Heat pump lockout	Wait 5 minutes; the compressor protection delay will clear.

8. Factory reset

To restore factory settings, hold the Menu and Down buttons together for 10 seconds until the screen shows RESET, then release. All schedules, Wi-Fi credentials and the link to your account are erased. You will need to pair the thermostat again.

9. Warranty and support

The Aurora X2 has a 3-year limited warranty from the date of purchase covering manufacturing defects. Damage caused by incorrect wiring or line-voltage connection is not covered. Support is available by chat in the app, seven days a week.

10. Specifications

Display: 3.5-inch colour touchscreen. Sensors: temperature (accuracy ±0.3 °C), humidity, occupancy. Power: 24 V AC, 2 W. Connectivity: Wi-Fi 2.4 GHz, Bluetooth LE. Dimensions: 92 × 92 × 24 mm.