Preliminary

Hamspot Commander

User Guide

Version 0.6.6

10 October 2026

Hamspot

This guide tells you how to run Hamspot Commander, tune a radio from the window, save a station file, and keep a portable copy on an Ubuntu live USB. It describes the program that ships in release 0.6.6. It does not describe a later build.

Ham Radio Deluxe is a trademark of its owner. This project does not copy that program's icons, pictures, or manual text. The chapter order of this guide follows the same kind of operator manual: what the program is, how to start it, how the face works, then how to configure it.

The program is licensed under the GNU General Public License, version 3 or any later version. See the `LICENSE` file in the source tree.

Table of Contents

1. Introduction 6
- 1.1 What Hamspot Commander is 6
- 1.2 What this release does not do 6
- 1.3 This guide 6
- 1.4 Computer 6
- 1.5 Programs the radio face expects 7
- 1.6 Radios 7
- 1.7 Where the release file is 7

2. Getting started 8
- 2.1 Two ways to run it 8
- 2.2 What you see first 8
- 2.3 Full screen and a second window 8
- 2.4 Favorite 8
- 2.5 If the radio does not answer 8

3. The window 10
- 3.1 Top bar 10
- 3.2 Pages 10
- 3.3 Status line 10
- 3.4 Tune, from top to bottom 10

4. Tuning 11
- 4.1 The digits 11
- 4.2 Typed frequency 11
- 4.3 The fine scale 11
- 4.4 VFO buttons 11
- 4.5 Mode, sub mode, and the receiver 12
- 4.6 Band chips and Band + / Band - 12
- 4.7 The bandspread 12
- 4.8 The control row 12
- 4.9 Transmit and the band plan 13
- 4.10 Where tuning stops 13

5. Band plans 14
- 5.1 The file you start with 14
- 5.2 Plan page 14

5.3 A bad file 14
6. Channels 15
6.1 A memory file, not the radio 15
6.2 Load, save, add, recall 15
6.3 The strip above the list 15
7. Meters and levels 16
7.1 Meters 16
7.2 Levels 16
8. The station file 17
8.1 One JSON document 17
8.2 Opening a file 17
8.3 What you must save yourself 17
9. CAT control and GQRX 18
9.1 The CAT Control frame 18
9.2 Add a Hamlib radio 18
9.3 Add a GQRX receiver 18
9.4 Which radio Tune uses 19
10. Audio 20
10.1 One card per radio 20
10.2 The Audio frame 20
10.3 What is kept 20
10.4 Nodes this program does not create 20
11. A persistent Ubuntu live USB 22
11.1 What you are installing 22
11.2 Make the stick 22
11.3 Confirm the boot is persistent 22
11.4 Copy the zip onto the stick 23
11.5 Unzip into the home directory 23
11.6 Install the packages the folder does not contain 23
11.7 Device permissions 24
11.8 Start Commander 24
11.9 Reboot and see that it stuck 24
11.10 What this chapter does not do 25
12. An installed copy 26
12.1 When to use the installer 26
12.2 Install 26

12.3 Remove 26
13. Appendix 28
13.1 Portable folder 28
13.2 Station file, short form 28
13.3 Frequency entry 28
13.4 Dark controls 28
13.5 Process boundaries 29
13.6 Further reading in the source tree 29

1. Introduction

1.1 What Hamspot Commander is

Hamspot Commander is a station face for a radio you can reach with Hamlib, and for a GQRX receiver the program starts itself. You use it to read the frequency, change the VFO, set the mode, key the transmitter when the radio allows it, and keep a band plan and a local channel file.

The window is a dark set of grouped frames: a top bar, a row of page tabs, the page, and a status line. The pages are Tune, Plan, Channels, Meters, Levels, and Config.

Radio traffic uses Hamlib's `rigctld` text protocol. Commander does not link the Hamlib library. A GQRX row uses the short rigctl commands on the same kind of client. Commander starts those programs. It does not attach to a `rigctld` or a GQRX that some other program already started, and it stops only the processes it started.

1.2 What this release does not do

Logbook, digital-mode decoding, satellite tracking, and rotator control are not in this release. There is no DX cluster, no ADIF import, and no contest logger.

The Channels page is a file on this computer. It is not the memory bank inside the radio. The buttons `A > Mem` and `Mem > A` use one frequency held in the window, not that file and not the radio's memories.

Favorite is kept until you close the window. It is not written into the station file.

Some buttons on the Tune page stay dark on every radio. Section 13.4 lists them. A button that the connected radio cannot perform also stays dark, even when a different radio would light it.

1.3 This guide

Each chapter starts with what you are looking at, then the steps. A note is something you can skip and still operate. An important note is something that will lose a setting or key the radio if you miss it.

Button names are printed as they appear on the window, for example `Add hamlib` and `Band +`.

1.4 Computer

Release 0.6.6 of the portable build is a 64-bit Linux program. The install script in the source tree accepts only Ubuntu 26.04. The portable folder can be copied onto another Ubuntu machine of the same kind. It still needs the packages in the next section. Those packages are not inside the zip.

You need a graphical session. The window uses the desktop's display. Audio uses the session's PipeWire socket. Do not point the launcher at a different runtime directory. The start script leaves that socket alone on purpose.

A serial radio needs the user in the `dialout` group. A USB device node that Ubuntu assigns to `plugdev` needs that group as well. Membership is on the machine, not inside the portable folder. After a group change, log out and back in before you open the port.

1.5 Programs the radio face expects

Program	Package on Ubuntu	What it is for
`rigctld`	`libhamlib-utils`	Hamlib radios, including the built-in dummy
`gqrx`	`gqrx-sdr`	A GQRX row on the Config page
`pw-loopback`, `pw-dump`	`pipewire-bin`	The receive and transmit audio cards
`helvum`	`helvum`	The Helvum button on the Audio frame
`dsd-fme`	built from lwvmobile/dsd-fme	Digital voice, including P25, on an RX pipe
`sox`, `socat`	`sox`, `socat`	Resample dsd-fme's 8 kHz voice to the RX pipe's 48 kHz stream

PipeWire itself is part of the Ubuntu desktop session. Commander does not start it.

The source-tree installer also installs `rustc`, `cargo`, `pkg-config`, and `libgtk-3-dev` so it can compile the window. It installs `build-essential`, `cmake`, `git`, `libcodec2-dev`, `libncurses-dev`, `libpulse-dev`, `librtlsdr-dev`, `libsndfile1-dev`, and `libusb-1.0-0-dev`, then builds `mbelib` and `dsd-fme` into `~/.local/bin`. It does not install GNU Radio or the Ubuntu `dsdcc` package. The portable zip is already compiled and does not include `dsd-fme`. A live USB does not need the compiler.

1.6 Radios

A Hamlib row stores a model number, a device path, a serial speed, a CI-V address, a PTT type, a PTT device, and any extra Hamlib `-C` options. The model list is the list `rigctld -l` prints on that machine. The closed model button shows the model number and the radio name, for example `3073 Icom IC-7300`. The saved value is the number.

An empty device is valid. Model `1` is Hamlib's dummy radio. The first time that dummy answers, the window sets VFO A to 14.153608 MHz USB, VFO B to 146.520 MHz FM, and VFO C to 446.000 MHz FM, then selects VFO A again. A later reconnect of the same dummy does not write those frequencies again.

The dummy receives from 150 kHz through 1.5 GHz. The window will not tune it outside that span.

GQRX is a receiver on this face. Its caps are one VFO, no transmit, no RIT, and no split. The face treats its receive range as 0 Hz through 6 GHz. A new GQRX row has no input device, so GQRX opens its I/O device chooser and Commander leaves that window up.

1.7 Where the release file is

The portable zip for this guide is attached to the GitHub release:

https://github.com/hamspot/hamspot-commander/releases/tag/v0.6.6

The file name is `hamspot-commander-0.6.6-portable-linux-x86_64.zip`. Unzipping it produces one folder, `HamSpotCommander`. Chapter 11 is the procedure for a USB stick.

2. Getting started

2.1 Two ways to run it

Use the portable folder when the computer is an Ubuntu live USB, or when you want the station files to travel with the program. Chapter 11 is that path.

Use `scripts/install.sh` from a source checkout when Ubuntu 26.04 is installed on the machine and you want a binary under your home directory. Chapter 12 is that path.

Both end at the same window. They put the station files in different places.

2.2 What you see first

The window opens on the Tune page. If the station file has no radio list, Commander starts one Hamlib row named Dummy, model 1, with no serial device. The status line names the link. The right side of that line shows the last command you sent. Polls that the window sends on its own are not printed there.

Press `Demo` on the top bar to leave the live radio and use a small radio inside the process. Demo does not start `rigctld`. Press `Demo` again to return to the selected radio.

The in-process demo receives the ten HF segments from 160 m through 10 m, including 60 m from 5.250 MHz to 5.450 MHz. It will not tune 6 m, 2 m, or 70 cm. It starts with VFO A at 14.153608 MHz USB and VFO B at 7.074 MHz LSB, and it transmits on VFO A until you select `TX sub`.

2.3 Full screen and a second window

`Full screen` on the top bar switches the window. Press it again to leave full screen.

The desktop file has an action named New Window. That starts another process. Two processes do not share one radio port. They can share the same saved window folder, so the last one to exit writes the band-plan folder remembered for the file dialog.

2.4 Favorite

1 Press `Favorite` on the top bar.
2 Press `Save current` while a radio is online. The window stores the frequency, mode, and passband.
3 Press `Recall` to send them again, if the radio can set the frequency.

Close the Favorite window with its title-bar control. Nothing is written to disk. The next launch starts with "Nothing saved."

2.5 If the radio does not answer

Read the Status column on the Config page before you change frequency.

`starting` means the program has been launched and the port is not open yet.

`device missing` means a Hamlib row names a serial device that is not on the machine. Commander waits. Plug the cable in. It does not need a restart if the device appears.

`choose I/O device` means a GQRX row is up and its remote-control port is not accepting yet. Use the GQRX window to pick a device. Commander does not kill that window on a timer.

`retrying` means a Hamlib process exited. Commander starts it again about two seconds later.

A frequency the radio refuses does not move the readout. The typed number is ignored and the digits stay where the radio is.

3. The window

3.1 Top bar

The top bar holds `Demo`, `Favorite`, and `Full screen`.

3.2 Pages

The tab row is `Tune`, `Plan`, `Channels`, `Meters`, `Levels`, and `Config`. The wheel over the frequency display is handled by Tune. The band scales sit outside the scroll area so the wheel is not stolen by the list.

3.3 Status line

The left side is the link and the band label for the frequency on the readout. The right side is the last operator command, in a monospace face. Background reads are omitted, so a quiet radio leaves the last command you actually sent.

3.4 Tune, from top to bottom

The Tune page is four bands of controls.

The frequency frame holds the current VFO, a column of VFO buttons, and the paired VFO when the radio has one. Under the digits is a fine scale. The next row is `ALT`, `BSP`, `LOAD`, the band chips for the zone that contains the frequency, then `Mode`, `Sub`, and `Receiver` at the right.

Under that frame is the control row: `ATU`, `Band -`, `Band +`, and the rest of the keys in section 4.8.

`BSP` shows or hides the bandspread. When it is on, one line is drawn for each zone in the loaded plan. A zone the radio cannot receive is left out.

4. Tuning

4.1 The digits

The readout always shows four megahertz digits, then a kilohertz group, then a hertz group. 14.153608 MHz is `0014.153.608`. 146.520 MHz is `0146.520.000`. A frequency at or above 10000 MHz prints in full.

The left readout is the current VFO. Its label is the Hamlib token, written with a space: `VFO A`, `Sub`, `Main A`. The S-meter sits on this readout. Hamlib reports one strength, so the other readout has no second S-meter.

The right readout is the paired VFO: VFO A with VFO B, Main with Sub, and the A and B forms of those names. A VFO with no pair in the radio's list has no right readout. The right digits tune the split frequency.

Click a digit to select that place and add one to it. One notch of the mouse wheel on a digit adds or subtracts one of that digit and does not change which digit is selected. A notch anywhere else on that VFO cluster, including the typed frequency, the mode text, the meter, and the gaps, steps the selected digit. One physical notch is one step. The line under the digits reads `step` and the size, such as `100 Hz` or `1 kHz`.

4.2 Typed frequency

Click the text under the digits, type a frequency, and press Enter.

Three groups work: `0014.153.608` or `14.153.608`. Two groups are megahertz, so `14.153608` is the same frequency. A whole number is hertz.

The radio must be able to receive that frequency. A number outside the receive ranges is ignored.

4.3 The fine scale

The scale marked Fine sits under the two readouts. A drag on it tunes the current VFO inside the window it opened on. It does not jump to another band.

4.4 VFO buttons

These sit between the two readouts. A button lights only when the radio reports that it can do the operation.

Button	Action
`A <> B`	Exchange the VFOs (Hamlib `XCHG`)
`A > B`	Copy A to B (Hamlib `CPY`)
`A > Mem`	Store the current frequency in the window
`Mem > A`	Tune back to that one stored frequency
`TX main`	Split off. Transmit on the current VFO
`TX sub`	Split on. Transmit on VFO B
`VFO A`, `VFO B`	Select that VFO
`R-6kHz`, `R-3kHz`, `R-15kHz`	Set the RIT offset
`R-Auto`	Clear RIT

`ALT` on the band row sends the same exchange as `A <> B` when the radio lists `XCHG`.

RIT is an offset. It is not a second VFO frequency. The current readout shows `RIT` and the offset in hertz when it is not zero.

VFO select on this face is A and B. A dummy radio can hold 70 cm on VFO C from the first park, and this row does not offer a VFO C button.

4.5 Mode, sub mode, and the receiver

`Mode` lists the modes the radio reported. Choosing one sends that mode and keeps the current passband.

`Sub` does the same for the paired VFO, when the radio can set split and it listed modes.

`Receiver` is `RX` or `Off`. It is enabled when the radio can be powered from CAT. Off is not a substitute for disconnecting the cable.

4.6 Band chips and Band + / Band -

The chips are the bands in the current zone that intersect the radio's receive ranges. A radio that stops at 30 MHz does not show a chip for a 500 MHz allocation. Click a chip to tune the remembered frequency for that band, or its home frequency if you have not visited it in this session.

`Band +` and `Band -` step to the next band the radio can receive, in frequency order, across every zone. There is no Hamlib band-up command. The window sends a frequency set. A band outside the receive ranges is skipped.

On the dummy, receive starts at 150 kHz, so 2200 m is not a step and 630 m is.

The chips follow the radio frequency. The Plan page does not follow, so its zone tab stays where you left it.

4.7 The bandspread

Turn `BSP` on. Each zone in the plan is one horizontal line, highest zone first. Low frequency is on the left. Sub-bands share the line with a small pad between them. A press in the pad or on the zone name does nothing.

Colors on a ham plan are the segment use: CW is amber, digital is blue, voice is green, and mixed is gray. On the shortwave example the line is painted by service name.

Left-click or left-drag a segment to tune the main VFO and set the main mode from that segment. CW segments ask for CW. Digital segments ask for RTTY, or another mode in that family if the radio has no RTTY. Voice and mixed segments ask for USB, unless the band's stored mode is already legal on that segment. A CW band mode does not stick when you click a voice segment.

Right-click or right-drag sets the split frequency and the split mode. It does not move the main VFO. Right-click is ignored when the radio cannot set split, or when the frequency is outside the receive ranges.

`LOAD` on this row opens a JSON file dialog titled "Load band plan". It does not save. Saving a plan is on the Plan page.

4.8 The control row

A control is dark when the radio is offline, when Hamlib did not list that function, or when the button has no command in this release.

Button	Sent when the radio lists it
`ATU`	Tuner
`Band -`, `Band +`	A frequency on the next receive band
`NR`	Noise reduction on or off
`Pre 1`, `Pre 2`	Preamp at 10 dB or 20 dB
`Ant 1`, `Ant 2`	Antenna 1 or 2
`Bk-in`	Semi break-in
`Fast`	Fast AGC
`Proc`	Speech processor
`Lock`	Dial lock
`Notch`	Automatic notch
`MOX`	Push-to-talk
`Moni`	Monitor

These stay dark on every radio in this release: `Dimmer`, `NR sub`, `CW Spot`, `Keyer`, `Nar`, `Ant Rx`, `Chan +`, `Chan -`, `QMR`, `BC`, `PWR`, `QMS`, `Contour`, `Scan`, and `Scan Dn`.

4.9 Transmit and the band plan

> *Important.* `MOX` *can key the transmitter. The band-plan check below runs first, and a refusal does not key. A mode the plan allows is sent to the radio.*

`MOX` checks the loaded plan before it keys. CW is allowed on every segment use. Voice is refused on a CW segment and on a digital segment. Digital is refused on a CW segment and on a voice segment. Mixed refuses nothing. A mode the plan does not classify is not blocked.

The check uses the frequency and mode on the current VFO. Receive tuning is still the radio's receive ranges. The plan does not stop you from listening.

The refusal is a note on the page. The transmitter is not keyed.

4.10 Where tuning stops

The window rejects a negative frequency, and it rejects a frequency that is not a finite number. Tuning stays inside the receive ranges Hamlib printed under `RX ranges #1`. Transmit ranges are not used as the tune limit. An empty receive list closes tuning.

A step that would leave the current receive segment stops at the edge. It does not jump the gap.

5. Band plans

5.1 The file you start with

Startup loads `bsp/default.json` from beside the program. In the portable tree that directory is `HamSpotCommander/bsp`. The file is a version-1 JSON plan: zones, and bands inside the zones. Each band has edges, a home frequency, a home mode, and segments tagged `cw`, `digital`, `voice`, or `mixed`.

`bsp/arrl.json` is an example of the ARRL voluntary plan, one zone per named allocation. It is not the file the window loads at startup. `bsp/shortwave.json` is an example listening map (broadcast, aero, marine, time, and the rest). It is not the startup plan, and it does not apply the amateur mode limits from the ham plan.

License class and calling-frequency spots are not segments.

5.2 Plan page

The zone row starts with `LOAD`, `Save`, and `ADD`, then the zone names.

`LOAD` opens "Load band plan". `Save` opens "Save band plan". Both dialogs filter for JSON. The dialog starts in the `bsp` folder beside the program unless you have already picked a folder. That folder is remembered with the window.

An empty plan has no standalone Save. `ADD` appends a zone named New, or New 2, and so on, with one band around the current VFO. If the VFO cannot seed a band, the new band is 14.200 MHz USB. The chip text is `new`.

Right-click a zone name to rename it or to delete that zone and its bands. A blank name is ignored. Delete selects the previous zone. Nothing is written to disk until you Save.

The list under the dial is one row per band: slot, home in megahertz, and name. Click a row to select that band and tune its home, inside the receive ranges.

The editor on the right has Name, Home, Low, High, and Mode. It does not edit the individual segments inside the band. A click on the dial inside a band sets that band's home. A click in a gap does not widen the band.

The Plan page lists every band in the file. The Tune page hides bands the radio cannot receive.

5.3 A bad file

A plan that does not parse is refused. The plan already in memory stays, and the page shows the error. Saving writes pretty JSON and refuses an invalid plan.

Overlapping bands are an error. Bands that only touch at an edge are valid. The edge belongs to the band that starts there.

6. Channels

6.1 A memory file, not the radio

The Channels page stores named frequencies on disk. A file is version 1: zones of channels, and each channel is a name, a frequency in hertz, and a mode. The page starts with one empty zone named Memories.

This does not read or write the memories in the radio.

6.2 Load, save, add, recall

The buttons are `Load` and `Save`. The dialogs are titled "Load channels" and "Save channels". A new save suggests `channels.json` when no file is open yet.

The list shows slot, megahertz, and name. Click a row to recall it. Recall tunes only inside the receive ranges, and it sends the mode when the radio can set mode.

The editor has Name, Frequency, Mode, `Add`, and `Delete`. `Add` uses the current VFO frequency and mode. `Delete` removes the selected channel.

A file with unknown fields, a missing channel list, a band-plan document, or a frequency that is not a finite number above zero is refused. The previous memories stay.

6.3 The strip above the list

The strip is the loaded band plan, drawn across the span of the channels in the selected zone, padded on each side. It is decoration and a place to look. Loading a channel file does not change the band plan. If the plan has no segment in that window, the built-in ham plan is used for the colors. A window outside both stays unmarked.

Channel zones and band-plan zones are different lists. They are not matched by name.

7. Meters and levels

7.1 Meters

The Meters page shows the S-meter for the current VFO, then ALC, SWR, and PWR.

S-meter numbers use Hamlib's strength in dB relative to S9. S9 is about 0 dB. Above that the label is `S9` plus the dB. Below that the label steps by about 6 dB per S-unit down to S0.

SWR is the number Hamlib reports. The bar treats 1.0 as empty and 5.0 as full. The alarm `High SWR` lights when that number is 3.0 or higher.

PWR uses `RFPOWER_METER` when the radio has it, otherwise `RFPOWER`. The numeric label is the value times 100, rounded.

ALC, SWR, and PWR read zero or 1.0 when the radio has not reported that level.

`Roofing` is a label when the radio reports a roofing value.

`Busy`, `Mic Eq`, and `PLL unlock` are drawn and stay off. They do not follow the radio in this release.

Meters are not stored in the station file.

7.2 Levels

The Levels page is also the set of sliders you are configuring. A slider is live only when the radio lists that level and gives it a range. Otherwise the label ends in a dash and the slider does not move.

Control	Hamlib level	Notes
AF gain (main)	`AF`	
RF gain (main)	`RF`	
AGC (main)	`AGC`	A drop-down of the names the radio listed
RF power	`RFPOWER`	
AF gain (sub)	none	Fixed. It never sends a command
RF gain (sub)	none	Fixed. It never sends a command
AGC (sub): Auto Fast	none	Dark
Noise reduction	`NR`	The level, not the NR button
IF shift	`IF`	Shown in hertz
Filter width	passband	50 Hz through 16000 Hz, sent with the mode
Contour: 20 Hz	none	Dark
Mic gain	`MICGAIN`	
VOX delay	`VOXDELAY`	Milliseconds when the range allows it
VOX gain	`VOXGAIN`	

Levels that the radio lists are written into the station file. PTT is not.

8. The station file

8.1 One JSON document

The Config page `Load` and `Save` buttons store one version-1 JSON file. The dialog remembers the folder. The label next to the buttons is `No file` until you save or load.

The file holds the band plan, the plan's file name, the channel file, the Tune face (frequency, mode, split, RIT, and the VFO selection the face can store), the settable levels, the radio list, and the audio graph. Unknown fields fail the load and leave the running face unchanged.

`Save` does not write the `bsp` directory by itself except as described in the next section, and it does not send CAT until you open a file onto a radio that is already online.

8.2 Opening a file

Opening a config replaces the plan, the channels, and the Tune fields in memory. It does not reconnect. If the radio is already online, the window then sends frequency, mode, passband, split, RIT, and the listed levels. A frequency the radio refuses does not block the rest. PTT is not keyed.

The plan name in the file must be a single `.json` file name, with no slash and no parent directory. If `bsp/<that name>` is missing beside the program, the embedded plan is written there. An existing file is left alone, even when its bytes differ. If the folder is missing, the face still loads and a note says the plan was not written.

The channel path is cleared on open, so a later Channels `Save` does not overwrite the channel file you had open before.

8.3 What you must save yourself

Favorite, the one-slot `A > Mem` frequency, the meter readings, and PTT are not in the file.

PipeWire changes are written only when a station file is already open. The Audio frame says "Open a station file to keep PipeWire changes." when none is open. Commander does not restore a wire that another program moved. The live graph is the source of truth, and the open file is updated to match it.

9. CAT control and GQRX

9.1 The CAT Control frame

Config shows a table: Name, Driver, Device, Listen, and Status. Click a row to make it the Tune radio. Other rows stay running. Each of them keeps a light frequency poll about every two seconds. The selected row is the one the Tune page drives.

Listen is `127.0.0.1` and a port. Ports are chosen from 4532 upward, the first free port.

`Add hamlib` opens the Hamlib radio window. `Add GQRX` opens the GQRX window. `Edit` opens the selected row. `Remove` stops that row and the process group Commander started for it. Closing the Commander window stops every process group it started.

Under the buttons, USB ports lists `/dev/serial/by-id` when those links exist, otherwise `/dev/ttyUSB*` and `/dev/ttyACM*`. The label `none` means no port was found. The list updates when a device appears or disappears.

9.2 Add a Hamlib radio

1 Press `Add hamlib`.
2 Type a Name.
3 Pick a model in the list, or type the model number in Model. The list is `rigctld -l` in fixed columns.
4 Pick a Device from the USB ports, choose `none`, or type a path.
5 Set Serial speed, CI-V, PTT type, and PTT device to what that radio's Hamlib model expects. Leave a field blank when the model does not use it.
6 Extra `-C` is passed through as Hamlib configuration. The program does not add `-o`.
7 Press `Save`.

The port is assigned when the row starts. The window shows `Listen 127.0.0.1:` and the port, or `assigning` before that.

A missing device node waits in `device missing`. It is not a failed save.

9.3 Add a GQRX receiver

1 Press `Add GQRX`.
2 Type a Name. The note under the name says Commander starts this GQRX and stops it on exit.
3 A new row has no input device. The window says so. GQRX will open its I/O chooser.
4 Press `Save`.

Commander writes a GQRX config for that name and starts `gqrx` on it. Remote control is turned on, bound to 127.0.0.1, and the port is the one in the Listen column. Status stays `choose I/O device` until that port accepts a connection.

Pick the device in the GQRX chooser and let GQRX finish starting. When the port has been up, a later exit folds the device you chose back into the station row. `crashed` is stored false so the next start does not open GQRX's crash guard.

If you remove the row, or close Commander, before the port has ever accepted a connection, the chooser is not copied back. A device GQRX may have written only because the window was closing is not stored.

An older station row with no GQRX settings adopts a config file that is already on disk for that name. It does not copy your personal `~/.config/gqrx/default.conf`.

GQRX rows do not ask for a model, a serial port, CI-V, or PTT.

Do not point a new row at a config whose `crashed` flag is true and whose input device is a radio that is not on the network. That is the GQRX crash guard, and the chooser will not appear until `crashed` is false and the dead device line is gone. A new row from `Add GQRX` already meets that condition.

9.4 Which radio Tune uses

Select the row. The Tune page follows that row after the port is up. Opening a station file does not by itself reconnect. The face settings in the file are sent when that row's session is published.

Demo leaves the selected radio running and shows the in-process radio instead. Press Demo again to return.

10. Audio

10.1 One card per radio

Each CAT row gets two PipeWire loopbacks while Commander is running:

1 Receive is a sink named `hamspot_<id>_rx`. The radio plays into it. The description is the make, the model, the connection id, and `RX`.

1 Transmit is a source named `hamspot_<id>_tx`. The radio captures it. The description ends in `TX`.

`<id>` is the connection id in the Audio frame, not the text you typed in Name.

GQRX is started with that sink and that source as its Pulse sink and source. Hamlib does not play audio by itself. The loopbacks are still created so you can wire a speaker and a microphone.

The defaults are the computer's default playback device and default capture device.

10.2 The Audio frame

The frame is on the Config page under CAT Control. Each row shows the connection id, the make, and the model, then a playback drop-down on the RX line and a capture drop-down on the TX line.

If Helvum is on `PATH`, the Helvum button starts it. The button stays visible and is dark when `helvum` is not an executable on `PATH`. Commander does not quit when you close Helvum.

The line under the drop-downs says: "Drag a wire from a microphone to the radio, or from the radio to a speaker."

The picture is three columns. Microphones and other capture devices are on one side, the radio in the center, and speakers and other playback devices on the other. Drag only between a device and a radio. System devices use the desktop's icons. The radio, the speaker, and the microphone use the drawings shipped with Commander.

A wire you drop is the same change as picking that device in the drop-down.

`Other hamspot devices` lists `hamspot_` nodes that are not the RX or TX card of a current row.

10.3 What is kept

With a station file open, devices and wires whose names start with `hamspot_` are written into the file after the graph settles. Commander does not fight a wire you move in Helvum. It records the move.

Deleting a radio card that Commander has already seen turns that row's RX or TX flag off. Commander does not immediately create the card again.

The loopbacks exist only while Commander is running. Helvum does not show `Hamlib Dummy 1 RX` after you quit.

10.4 Nodes this program does not create

Do not add null sinks named Radio-Playback, Radio-Mic, Radio-EQ-In, or Radio-EQ-Out. Those are not Commander cards. A real sound card and the `hamspot_<id>_rx` and `hamspot_<id>_tx` nodes are the graph this window uses.

11. A persistent Ubuntu live USB

11.1 What you are installing

The zip is a folder, not an Ubuntu package and not a new squashfs. Unzip it and run `hamspot-commander.sh`. The script finds its own directory, so the folder can move. Config, window state, and the GQRX files Commander writes stay inside that folder.

The read-only live image does not contain Commander, `gqrx`, or `rigctld`. A normal live boot forgets every file you unzip into the home directory and every package you install. Persistence is the part that keeps them.

You do two different writes:

1 Put `HamSpotCommander` on a Linux filesystem that the persistent session keeps.
2 Install `gqrx-sdr`, `libhamlib-utils`, `pipewire-bin`, and `helvum` with apt while that same persistent session is running, and add your user to `dialout` and `plugdev`.

The next boot has to be the persistent boot entry. A plain "Try Ubuntu" entry starts a clean image and will not show the folder or the packages.

11.2 Make the stick

Use a USB drive you can erase. Ubuntu 26.04 desktop is several gigabytes, and the persistence area has to hold package installs on top of that. A 32 GB stick is a practical minimum. Larger is more comfortable once GQRX and Hamlib are installed.

On a working Ubuntu machine, create the stick with mkusb and choose its persistent-live operation. That is the Ubuntu community tool that adds a writable overlay. The desktop Startup Disk Creator writes a live USB and does not add this overlay.

mkusb will ask you to confirm the target drive. Confirm the device name with `lsblk` before you accept.

> *Important. mkusb erases the drive you select. A wrong disk is gone. Read the device name in the prompt and match it to* `lsblk` *before you accept.*

Current mkusb labels the overlay partition `writable`. Older mkusb layouts label it `casper-rw`. Either label is the overlay. mkusb also creates a separate data partition, often named `usbdata`, that you can open from another computer. Use `usbdata` to carry the zip. Do not run the program from that partition when it is NTFS or FAT. The binary needs a Linux filesystem so it stays executable.

After mkusb finishes, boot the persistent menu entry, not the plain live entry.

11.3 Confirm the boot is persistent

Open a terminal on the live session and run:

```
findmnt -T /
lsblk -o NAME,LABEL,SIZE,FSTYPE,MOUNTPOINT
```

`findmnt` should show an overlay on `/`. `lsblk` should show a partition labeled `writable` or `casper-rw`. If `/` is only the read-only image, stop. Packages and an unzip into the home directory will disappear at shutdown. Boot the persistent entry, or recreate the stick with mkusb's persistent-live operation.

The live user is the one the Ubuntu image logs in as. Commands below use that user's home directory.

11.4 Copy the zip onto the stick

From any computer, copy `hamspot-commander-0.6.6-portable-linux-x86_64.zip` onto the `usbdata` partition, or download the release onto the live session after you have confirmed persistence.

The release page is chapter 1.7.

11.5 Unzip into the home directory

On the persistent live session:

```
ZIP=/media/$USER/usbdata/hamspot-commander-0.6.6-portable-linux-x86_64.zip
mkdir -p "$HOME/Applications"
unzip "$ZIP" -d "$HOME/Applications"
```

Change `ZIP` if you downloaded the archive somewhere else. The archive already contains the folder `HamSpotCommander`, so the tree is:

```
$HOME/Applications/HamSpotCommander/hamspot-commander.sh
$HOME/Applications/HamSpotCommander/bin/commander
$HOME/Applications/HamSpotCommander/bsp/
$HOME/Applications/HamSpotCommander/config/
$HOME/Applications/HamSpotCommander/data/
```

`config`, `data`, `cache`, and `state` are created by the launcher if a copy omitted them. Band plans are in `bsp` next to `bin`.

Check that the binary is executable:

```
test -x "$HOME/Applications/HamSpotCommander/bin/commander" && echo OK
```

If that does not print OK, the unzip landed on a filesystem that dropped the executable bit. Unzip it again onto `$HOME/Applications`, which is on the overlay.

11.6 Install the packages the folder does not contain

Still on the persistent session:

```
sudo apt-get update
sudo apt-get install gqrx-sdr libhamlib-utils pipewire-bin helvum
```

Confirm the four programs:

```
command -v rigctld
command -v gqrx
command -v pw-loopback
command -v helvum
```

Each line should print a path.

These packages land on the overlay. They are still there after a reboot only when you boot the persistent entry again. They are not copied into the read-only squashfs by this procedure, and they are not inside the zip.

11.7 Device permissions

A live user is not always in `dialout` and `plugdev`. Without `dialout`, a serial radio port will not open. Without `plugdev`, some USB device nodes will not open.

```
sudo usermod -aG dialout,plugdev "$USER"
```

Log out and back in, or reboot and choose the persistent entry again. Group membership is read at login. Check it:

```
id
```

The line should include `dialout` and `plugdev`.

Ubuntu's default rules already cover `/dev/ttyUSB*`, `/dev/ttyACM*`, and `/dev/serial/by-id` for members of `dialout`. You do not add a separate udev file for this program.

11.8 Start Commander

```
"$HOME/Applications/HamSpotCommander/hamspot-commander.sh"
```

The script sets the config, data, cache, and state directories to folders inside `HamSpotCommander`, then runs `bin/commander`. Station files you save from the Config page default to that config directory if you navigate there. GQRX files Commander writes for a portable launch go under `HamSpotCommander/config`, because that directory is the config home.

The desktop file in the folder is named Hamspot Commander. Its launch line uses the desktop file's own location, so it still works after you move the folder. If the file manager will not start a desktop file, use the shell command above. That command is the one this guide relies on.

PipeWire stays on the session socket. Do not export a private runtime directory before you start the script.

11.9 Reboot and see that it stuck

1 Shut down.
2 Boot the same stick and choose the persistent entry again.
3 Run `findmnt -T /` and confirm the overlay.
4 Run the start command in section 11.8.
5 Open Config and confirm the radio rows you saved are the rows in the station file.

A station file you saved inside `HamSpotCommander/config` is part of the folder. Copy the whole `HamSpotCommander` folder if you want that station on another machine. The zip from the release page is a fresh tree and does not contain your station.

If you boot the non-persistent entry, the home directory is empty again and apt will not list the packages you installed. The zip you left on `usbdata` is still there, because that partition is not the overlay. You would have to install the packages again.

11.10 What this chapter does not do

It does not rebuild the Ubuntu squashfs. The live image stays the image you downloaded. Persistence holds your changes beside it. That is the layout the portable folder was built for: no home directory is baked into the launcher.

Rebuilding the ISO so that Commander and the four packages are inside the read-only image is a separate remaster. This release does not ship that ISO. If you later remaster, keep the `HamSpotCommander` folder as a normal directory and leave its config path relative. Do not replace `hamspot-commander.sh` with a script that points at `/home/user`.

12. An installed copy

12.1 When to use the installer

Use this chapter when Ubuntu 26.04 is installed on the computer, you have a source checkout, and you want `commander` on your account. The installer refuses any other distribution. It reads `/etc/os-release` and stops if the id is not `ubuntu` or the version is not `26.04`.

The portable zip in chapter 11 does not use this script.

12.2 Install

From the source tree:

```
scripts/install.sh
```

The script asks for sudo without a password prompt. On a machine where sudo requires a password in the terminal, run it from a terminal that can authenticate, or arrange passwordless sudo for the duration of the install. If sudo cannot run, the script stops before it changes packages.

It installs the packages in section 1.5, including the compiler, then builds the release binary and `dsd-fme`. It copies:

Installed path	What it is
`~/.local/bin/commander`	The window
`~/.local/bin/dsd-fme`	The digital voice decoder
`~/.local/share/applications/hamspotcommander.desktop`	The desktop entry
`~/.local/share/icons/hicolor/128x128/apps/hamspot-commander.png`	The icon
`~/.local/share/hamspot-commander/installed.manifest`	What this install added

The desktop name is Hamspot Commander. The executable line points at `~/.local/bin/commander`.

You are added to `dialout` or `plugdev` only if you are not already a member. The manifest records `added_dialout=yes` or `added_plugdev=yes` only in that case. Log out and back in if a group was added.

The script does not start Commander or GQRX.

12.3 Remove

```
scripts/uninstall.sh
```

Removal deletes the binary, the desktop file, and the icon recorded in the manifest, when those paths are under your home directory. It also deletes the `dsd-fme` and `mbelib` files listed in the manifest. It removes you from `dialout` or `plugdev` only if the manifest says this install added you. It does not remove apt packages. GQRX, Hamlib, PipeWire, and the compiler stay installed. The decoder source cache under `~/.cache/hamspot-commander` stays as well.

A second install leaves `added_dialout` and `added_plugdev` as they were, so a later uninstall does not drop a group you already belonged to.

Station files you saved, and anything under `HamSpotCommander`, are not part of the manifest. Uninstall does not delete them.

13. Appendix

13.1 Portable folder

Path inside `HamSpotCommander`	Role
`hamspot-commander.sh`	Sets the four data directories, then execs the binary
`hamspotcommander.desktop`	Desktop entry that follows the folder
`hamspot-commander.png`	Icon used by the relocatable desktop file
`bin/commander`	The window
`bsp/*.json`	Band plans. Startup uses `default.json`
`config/`	Station files and GQRX INI for a portable launch
`data/`	Window state
`cache/`, `state/`	The other two relocated directories
`share/applications/`	A second desktop file, for the app id search path
`share/icons/hicolor/128x128/apps/`	The same icon on that search path

The installed copy in chapter 12 does not use this layout. Its binary is `~/.local/bin/commander`, and its window state defaults to `~/.local/share/hamspotcommander`.

13.2 Station file, short form

Version must be 1. A file with a field this release does not know is rejected.

Radios and the GQRX object may be absent. An older file still loads. An empty radio list starts the Dummy row.

The plan is stored in the file, and `bsp_name` says which file name under `bsp/` to write only when that file is not already there.

13.3 Frequency entry

You type	Meaning
`0014.153.608`	14153608 Hz
`14.153608`	14.153608 MHz
`14153608`	14153608 Hz

Press Enter in the text under the digits. The wheel and the digit clicks do not use this parser.

13.4 Dark controls

Dark on every radio, on the Tune control row: `Dimmer`, `NR sub`, `CW Spot`, `Keyer`, `Nar`, `Ant Rx`, `Chan +`, `Chan -`, `QMR`, `BC`, `PWR`, `QMS`, `Contour`, `Scan`, `Scan Dn`.

Dark on the Levels page: `AF gain (sub)`, `RF gain (sub)`, `AGC (sub): Auto Fast`, and `Contour: 20 Hz`.

Drawn on Meters and not wired to the radio: `Busy`, `Mic Eq`, and `PLL unlock`. `High SWR` does follow the SWR number.

Any other control is dark when this radio's Hamlib dump does not list it. That is expected. The dummy lists more operations than a typical GQRX row, and GQRX lists no PTT.

13.5 Process boundaries

Commander starts `rigctld`, `gqrx`, and `pw-loopback`. It stops those process groups on Remove and on exit. It does not stop a GQRX you started from the application menu, and it will not drive a `rigctld` you started in a terminal.

The first free TCP port at or above 4532 on 127.0.0.1 is the listen port. Nothing in this release listens on another address.

13.6 Further reading in the source tree

`README.md` is the short project readme. `docs/AudioGraph.md` names the PipeWire nodes for a Hamlib dummy wired to a USB sound device. This user guide is the operator manual. Where the readme still speaks of an older screen layout, trust the window and this guide.