Command set for VDT/S
(Firmware version 2.07.1, 14.11.2017)

Command from PC	Response from device	Description
ST	ST 00	Get measurement method
HVS	HVS: xxxx	Get firmware version
GI	GI: xx…	Get PCB id
VINCPROG	VINCPROG	
VINCRESET	VINCRESET	
VS xx…	xx…	Send data to Vinculum
VINCEXT	VINCEXT	Set Vinculum extended
VINCPORT	VINCPORT: xx	Get Vinculum port
VINCVERS	VINCVERS: xx…	Get Vinculum version
VINCDIR	VINCDIR: xx…	Get Vinculum directory
VINCQD	VINCQD: xx xx xx…	Get Vinculum QD
HSNR	HSNR: xxxxxx	Get serial number
SSNR xxxxxx	SSNR xxxxxx	Set serial number
EP	EPROM x.xx.x	Get firmware version
EPSONDER	EPSONDER xxx	Get firmware special version
EPDATUM	EPDATUM dd.mm.yy	Get firmware date
HUPDDAT	HUPDDAT dd.mm.yy	Get update date
HVAC	HVAC: xx…	Get ADC average value
VNULL	VNULL	Get VNULL
LICFREExxxx	OK	License Manager
HPERIODS	HPERIODS: x	Get periods
HFULLDAYS	HFULLDAYS: x	Get full days
SPERIODS x	SPERIODS: x	Write Periods
SFULLDAYS x	SFULLDAYS: x	Write full days
LICINIT	LICINIT	Initialize license management
GCOD	GCOD: xxxxxx	Get COD
PRINTTEST	text	Print test message