
9/25/2023

2.5.5 Configure initial switch setting



Answers:

24 Ethernet ports

2 Gigabit ports

0 - 4 and 5 - 15

show starting-configuration

The startup-config is not present because the running-configuration is not copied into the NVRAM yet (write or copy running-config startup-config command isn't done yet)

We get enable secret 5 \$1\$mERr\$ILwq/b7kc.7X/ejA4Aosn0

The secret password is different because it's encrypted instead of plaintext
They will be in encrypted form because we enabled the service password-encryption
The banner is displayed in user mode during bootup or remote login
The shortest version is w in exec mode w stands for write
Show starting-config shows the contents of NVRAM
All changes are recorded during write