Supervyse OPF IPMI Command Support List

Revision 1.4

02/2025

Copyright (c) 2025, All Rights Reserved. Insyde Software.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form, or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Insyde Software Corp.

Disclaimer

Insyde Software provides this document and the programs "as is" without warranty of any kind, either expressed or implied, including, but not limited to, the implied warranties of merchantability or fitness for a particular purpose.

This document could contain technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in future revisions of this document. Insyde Software is under no obligation to notify any person of the changes.

The following trademarks are used in this document:

Insyde and InsydeH2O are registered trademarks or trademarks of Insyde Software. All other trademarks or trade names are property of their respective holders.

Contents

1 Network Function Codes 5
2 Label and Description 6
3 IPMI Command Support List 7

Revision History

Revision Number	Date	Author	Reviewer	Summary
1.0	2020-03-31	Roy Kuo	Brad Chang	Initial version
1.1	2021-12-22	Roy Kuo	Brad Chang	RV version
1.2	2022-08-10	Roy Kuo	Brad Chang	update latest information
1.3	2025-01-24	Jeff Chen	Brad Chang	Release review
1.4	2025-02-14	Jeff Chen	Roy Kuo	Add label and description

1 Network Function Codes

NetFn Name	NetFn Value
Chassis	00h
Bridge	02h
S/E	04h
App	06h
Storage	0Ah
Transport	0Ch

2 Label And Description

Label	Description
M	Mandatory. Indicates that the command must be implemented to comply with the specification.
O	Optional. Indicates that the command is optional in the specification.
N	This command is not supported.
Y	This command is supported.

3 IPMI Command Support List

IPMI Commands	NetFn	CMD	IPMI 2.0	DCMI 1.5	NM 3.0	Supervyse OPF
IPMI Device "Global" Commands						
Get Device ID	App	01h	M	M		Y
Broadcast Get Device ID	App	01h	M			N
Cold Reset	App	02h	O			Y
Warm Reset	App	03h	O			N
Get Self Test Results	App	04h	M			Y
Manufacturing Test On	App	05h	O			Y
Set ACPI Power State	App	06h	O			Y
Get ACPI Power State	App	07h	O	M		Y
Get Device GUID	App	08h	O			Y
Get NetFn Support	App	09h	O			N
Get Command Support	App	0Ah	O			N
Get Command Sub-function Support	App	0Bh	O			N
Get Configurable Commands	App	0Ch	O			N
Get Configurable Command	App	0Dh	O			N

Sub-functions						
Set Command Enables	App	60h	O			N
Get Command Enables	App	61h	O			N
Set Command Sub-function Enables	App	62h	O			N
Get Command Sub-function Enables	App	63h	O			N
Get OEM NetFn IANA Support	App	64h	O			N
BMC Watchdog Timer Commands						
Reset Watchdog Timer	App	22h	M	M		Y
Set Watchdog Timer	App	24h	M	M		Y
Get Watchdog Timer	App	25h	M	M		Y
BMC Device and Messaging Commands						
Set BMC Global Enables	App	2Eh	M	O		Y
Get BMC Global Enables	App	2Fh	M	O		Y
Clear Message Flags	App	30h	M	O		Y
Get Message Flags	App	31h	M	O		Y

Enable Message Channel Receive	App	32h	O			Y
Get Message	App	33h	M	O		Y
Send Message	App	34h	M	O		Y
Read Event Message Buffer	App	35h	O			Y
Get BT Interface Capabilities	App	36h	M			Y
Get System GUID	App	37h	O	M		Y
Get Channel Authenticatio n Capabilities	App	38h	O	M		Y
Get Session Challenge	App	39h	O			N
Activate Session	App	3Ah	O			N
Set Session Privilege Level	App	3Bh	O	M		Y
Close Session	App	3Ch	O	M		Y
Get Session Info	App	3Dh	O	M		Y
Get AuthCode	App	3Fh	O			N
Set Channel Access	App	40h	O	M		Y
Get Channel Access	App	41h	O	M		Y
Get Channel Info	App	42h	O	M		Y

Set User Access	App	43h	O	M		Y
Get User Access	App	44h	O	M		Y
Set User Name	App	45h	O	M		Y
Get User Name	App	46h	O	M		Y
Set User Password	App	47h	O	M		Y
Activate Payload	App	48h	O	M		Y
Deactivate Payload	App	49h	O	M		Y
Get Payload Activation Status	App	4Ah	O	M		Y
Get Payload Instance Info	App	4Bh	O	M		Y
Set User Payload Access	App	4Ch	O	M		Y
Get User Payload Access	App	4Dh	O	M		Y
Get Channel Payload Support	App	4Eh	O	O		Y
Get Channel Payload Version	App	4Fh	O			Y
Get Channel OEM Payload Info	App	50h	O			N
Master Write-Read	App	52h	M			Y
Get Channel Cipher Suites	App	54h	O	M		Y

Suspend/Resume Payload Encryption	App	55h	O			N
Set Channel Security Keys	App	56h	O			N
Get System Interface Capabilities	App	57h	O			Y
Set System Info Parameters	App	58h	O			Y
Get System Info Parameters	App	59h	O			Y
Chassis Device Commands						
Get Chassis Capabilities	Chassis	00h	M	M		Y
Get Chassis Status	Chassis	01h	M	M		Y
Chassis Control	Chassis	02h	M	M	M	Y
Chassis Reset	Chassis	03h	O			N
Chassis Identify	Chassis	04h	O	M		Y
Set Chassis Capabilities	Chassis	05h	O			Y
Set Power Restore Policy	Chassis	06h	O			Y
Get System Restart Cause	Chassis	07h	O			Y
Set System Boot Options	Chassis	08h	O	O		Y
Get System Boot Options	Chassis	09h	O	O		Y

Set Front Panel Button Enables	Chassis	0Ah	O			Y
Set Power Cycle Interval	Chassis	0Bh	O			Y
Get POH Counter	Chassis	0Fh	O			Y
Event Commands						
Set Event Receiver	S/E	00h	M			Y
Get Event Receiver	S/E	01h	M			Y
Platform Event (a.k.a. "Event Message")	S/E	02h	M		M	Y
PEF and Alerting Commands						
Get PEF Capabilities	S/E	10h	M			Y
Arm PEF Postpone Timer	S/E	11h	M			Y
Set PEF Configuration Parameters	S/E	12h	M			Y
Get PEF Configuration Parameters	S/E	13h	M			Y
Set Last Processed Event ID	S/E	14h	M			Y
Get Last Processed Event ID	S/E	15h	M			Y
Alert Immediate	S/E	16h	O		M	Y

PET Acknowledge	S/E	17h	O			Y
Sensor Device Commands						
Get Device SDR Info	S/E	20h	O			Y
Get Device SDR	S/E	21h	O			Y
Reserve Device SDR Repository	S/E	22h	O			Y
Get Sensor Reading Factors	S/E	23h	O			Y
Set Sensor Hysteresis	S/E	24h	O			Y
Get Sensor Hysteresis	S/E	25h	O			Y
Set Sensor Threshold	S/E	26h	O			Y
Get Sensor Threshold	S/E	27h	O	M		Y
Set Sensor Event Enable	S/E	28h	O	O		Y
Get Sensor Event Enable	S/E	29h	O	O		Y
Re-arm Sensor Events	S/E	2Ah	O			Y
Get Sensor Event Status	S/E	2Bh	O			Y
Get Sensor Reading	S/E	2Dh	M	M		Y
Set Sensor Type	S/E	2Eh	O			N
Get Sensor Type	S/E	2Fh	O			N

Set Sensor Reading And Event Status	S/E	30h	O			Y
FRU Device Commands						
Get FRU Inventory Area Info	Storage	10h	M			Y
Read FRU Data	Storage	11h	M			Y
Write FRU Data	Storage	12h	M			Y
SDR Device Commands						
Get SDR Repository Info	Storage	20h	M	M		Y
Get SDR Repository Allocation Info	Storage	21h	O			Y
Reserve SDR Repository	Storage	22h	M	M		Y
Get SDR	Storage	23h	M	M		Y
Add SDR	Storage	24h	M			Y
Partial Add SDR	Storage	25h	M			Y
Delete SDR	Storage	26h	O			Y
Clear SDR Repository	Storage	27h	M			Y
Get SDR Repository Time	Storage	28h	O			Y
Set SDR Repository Time	Storage	29h	O			N
Enter SDR Repository Update Mode	Storage	2Ah	O			N

Exit SDR Repository Update Mode	Storage	2Bh	O			N
Run Initialization Agent	Storage	2Ch	O			Y
SEL Device Commands						
Get SEL Info	Storage	40h	M	M		Y
Get SEL Allocation Info	Storage	41h	O			Y
Reserve SEL	Storage	42h	O	M		Y
Get SEL Entry	Storage	43h	M	M		Y
Add SEL Entry	Storage	44h	M			Y
Partial Add SEL Entry	Storage	45h	M			Y
Delete SEL Entry	Storage	46h	O			N
Clear SEL	Storage	47h	M	M		Y
Get SEL Time	Storage	48h	M			Y
Set SEL Time	Storage	49h	M			Y
Get Auxiliary Log Status	Storage	5Ah	O			N
Set Auxiliary Log Status	Storage	5Bh	O			N
Get SEL Time UTC Offset	Storage	5Ch	O			Y
Set SEL Time UTC Offset	Storage	5Dh	O			Y
LAN Device Commands						
Set LAN Configuratio	Transport	01h	M	M		Y

n Parameters						
Get LAN Configuration Parameters	Transport	02h	M	M		Y
Suspend BMC ARPs	Transport	03h	O			Y
Get IP/UDP/RMCP Statistics	Transport	04h	O			N
Serial/Modem Device Commands						
Set Serial/Modem Configuration	Transport	10h	M			Y
Get Serial/Modem Configuration	Transport	11h	M			Y
Set Serial/Modem Mux	Transport	12h	O			N
Get TAP Response Codes	Transport	13h	O			N
Set PPP UDP Proxy Transmit Data	Transport	14h	O			N
Get PPP UDP Proxy Transmit Data	Transport	15h	O			N
Send PPP UDP Proxy Packet	Transport	16h	O			N
Get PPP UDP Proxy Receive Data	Transport	17h	O			N

Serial/Modem Connection Active	Transport	18h	M			N
Callback	Transport	19h	O			N
Set User Callback Options	Transport	1Ah	O			N
Get User Callback Options	Transport	1Bh	O			N
Set Serial Routing Mux	Transport	1Ch	O			N
SOL Activating	Transport	20h	O	M		N
Set SOL Configuration Parameters	Transport	21h	O	M		Y
Get SOL Configuration Parameters	Transport	22h	O	M		Y
Command Forwarding Commands						
Forwarded Command	Transport	30h	O			N
Set Forwarded Commands	Transport	31h	O			N
Get Forwarded Commands	Transport	32h	O			N
Enable Forwarded Commands	Transport	33h	O			N
Bridge Management Commands (ICMB)						
Get Bridge State	Bridge	00h	[ICMB]			N
Set Bridge State	Bridge	01h	[ICMB]			N

Get ICMB Address	Bridge	02h	[ICMB]			N
Set ICMB Address	Bridge	03h	[ICMB]			N
Set Bridge ProxyAddres s	Bridge	04h	[ICMB]			N
Get Bridge Statistics	Bridge	05h	[ICMB]			N
Get ICMB Capabilities	Bridge	06h	[ICMB]			N
Clear Bridge Statistics	Bridge	08h	[ICMB]			N
Get Bridge Proxy Address	Bridge	09h	[ICMB]			N
Get ICMB Connector Info	Bridge	0Ah	[ICMB]			N
Get ICMB Connection ID	Bridge	0Bh	[ICMB]			N
Send ICMB Connection ID	Bridge	0Ch	[ICMB]			N
Discovery Commands (ICMB)						
PrepareForDi scovery	Bridge	10h	[ICMB]			N
GetAddresse s	Bridge	11h	[ICMB]			N
SetDiscovere d	Bridge	12h	[ICMB]			N
GetChassisD eviceId	Bridge	13h	[ICMB]			N
SetChassisD eviceId	Bridge	14h	[ICMB]			N
Bridging Commands (ICMB)						

BridgeRequest	Bridge	20h	[ICMB]			N
BridgeMessage	Bridge	21h	[ICMB]			N
Event Commands (ICMB)						
GetEventCount	Bridge	30h	[ICMB]			N
SetEventDestination	Bridge	31h	[ICMB]			N
SetEventReceptionState	Bridge	32h	[ICMB]			N
SendICMBEventMessage	Bridge	33h	[ICMB]			N
GetEventDestination (optional)	Bridge	34h	[ICMB]			N
GetEventReceptionState (optional)	Bridge	35h	[ICMB]			N
OEM Commands for Bridge NetFn						
OEM Commands	Bridge	C0h-FEh	[ICMB]			N
Other Bridge Commands (ICMB)						
Error Report (optional)	Bridge	FFh	[ICMB]			N