Supervyse OPF Intel Redfish API User Guide

Revision 1.0

Sep. 2024

Copyright (c) 2024, All Rights Reserved. Insyde Software.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form, or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Insyde Software Corp.

Disclaimer

Insyde Software provides this document and the programs "as is" without warranty of any kind, either expressed or implied, including, but not limited to, the implied warranties of merchantability or fitness for a particular purpose. This document could contain technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in future revisions of this document. Insyde Software is under no obligation to notify any person of the changes.

The following trademarks are used in this document:

Insyde and InsydeH2O are registered trademarks or trademarks of Insyde Software. All other trademarks or trade names are property of their respective holders.

Revision History

Revision Number	Date	Author	Reviewer	Summary
1.0	2024-08-19	-	-	Initial version

目次

1 Introduction 7
1.1 Overview 7
1.2 Related Information 7
1.3 Terms 7
2 Schemas 8
2.1 Service Root 8
2.1.1 Description 8
2.1.2 Support Method and Privilege 8
2.1.3 Properties 8
2.1.3.1 Example 8
2.2 CertificateService 10
2.2.1 Description 10
2.2.2 Support Method and Privilege 10
2.2.3 Properties 10
2.2.4 Supported Actions 10
2.2.4.1 DownloadIntelASDCertFile (Only for G4 platforms) 10
2.3 CableCollection (Only for G4 platforms) 11
2.3.1 Support Method and Privilege 11
2.3.2 Properties 11
2.4 Cable (Only for G4 platforms) 11
2.4.1 Description 11
2.4.2 Support Method and Privilege 11
2.4.3 Properties 11
2.5 Chassis 12
2.5.1 Description 12
2.5.2 Support Method and Privilege 12
2.5.3 Properties 12
2.5.4 Updatable Properties 12
2.5.5 Supported Actions 12
2.5.5.1 Reset Chassis 12
2.5.5.1.1 Example payload 13
2.5.6 ActionInfo 13
2.5.6.1 ResetActionInfo 13
2.5.6.1.1 Support Method and Privilege 13
2.5.6.1.2 Properties 13
Example13
2.6 Power (Only for G3 platforms) 14
2.6.1 Description 14
2.6.2 Support Method and Privilege 14
2.6.3 Properties 14
2.6.3.1 Example 15
2.6.4 Updatable Properties 16
2.6.4.1 Example payload 16
2.7 Thermal (Only for G3 platforms) 17
2.7.1 Description 17
2.7.2 Support Method and Privilege 17
2.7.3 Properties 17
2.7.3.1 Example 18
2.8 ThermalSubsystem 20
2.8.1 Description 20
2.8.2 Support Method and Privilege 20
2.8.3 Properties 20
2.9 Manager 20

2.9.1 Description 20
2.9.2 Support Method and Privilege 21
2.9.3 Properties 21
2.9.3.1 Example 21
2.10 FanControllers 24
2.10.1 Description 24
2.10.2 Support Method and Privilege 24
2.10.3 Properties 25
2.10.3.1 Example 25
2.10.4 Updatable Properties 26
2.10.4.1 Example Payload 27
2.11 FanZones 28
2.11.1 Description 28
2.11.2 Support Method and Privilege 28
2.11.3 Properties 28
2.11.3.1 Example 28
2.11.4 Updatable Properties 29
2.11.4.1 Example Payload 29
2.12 PidControllers 30
2.12.1 Description 30
2.12.2 Support Method and Privilege 30
2.12.3 Properties 30
2.12.3.1 Example 31
2.12.4 Updatable Properties 32
2.12.4.1 Example Payload 32
2.13 StepwiseControllers 33
2.13.1 Description 33
2.13.2 Support Method and Privilege 33
2.13.3 Properties 33
2.13.3.1 Example 34
2.14 EthernetInterfaceCollection 35
2.14.1 Description 35
2.14.2 Support Method and Privilege 35
2.14.3 Properties 35
2.15 VlanNetworkInterfaceCollection (Only for G3 platforms) 35
2.15.1 Description 35
2.15.2 Support Method and Privilege 36
2.15.3 Properties 36
2.15.3.1 Example 36
2.15.4 Establish VLAN by POST 36
2.15.4.1 Example Payload 36
2.16 VlanNetworkInterface (Only for G3 platforms) 36
2.16.1 Description 36
2.16.2 Support Method and Privilege 37
2.16.3 Properties 37
2.16.4 Updatable Properties 37
2.16.4.1 Example Payload 37
2.16.5 Remove VLAN by DELETE 37
2.17 LogService 38
2.17.1 Description 38
2.17.2 Support Method and Privilege 38
2.17.3 Properties 38
2.17.3.1 Example 38
2.18 LogEntryCollection 39
2.18.1 Description 39
2.18.2 Support Method and Privilege 39
2.18.3 Properties 39

2.18.3.1 Example 39
2.19 LogEntry 40
2.19.1 Description 40
2.19.2 Support Method and Privilege 40
2.19.3 Properties 40
2.19.3.1 Example 41
2.20 HostInterface 41
2.20.1 Description 41
2.20.2 Support Method and Privilege 42
2.20.3 Properties 42
2.20.3.1 Example 42
2.20.4 Updatable Properties 44
2.20.4.1 Example Payload 44
2.21 ComputerSystem 44
2.21.1 Description 44
2.21.2 Support Method and Privilege 44
2.21.3 Properties 45
2.22 Memory 45
2.22.1 Description 45
2.22.2 Support Method and Privilege 46
2.22.3 Properties 46
2.23 Processor 46
2.23.1 Description 46
2.23.2 Support Method and Privilege 46
2.23.3 Properties 46
2.24 TelemetryService 47
2.24.1 Description 47
2.24.2 Support Method and Privilege 47
2.24.3 Properties 47
2.24.3.1 Example 47
2.24.4 Supported Actions 48
2.25 MetricReportCollection 48
2.25.1 Description 48
2.25.2 Support Method and Privilege 48
2.25.3 Properties 48
2.25.3.1 Example 49
2.25.4 Supported Actions 49
2.25.4.1 ClearTestMetricReport 49
2.26 MetricDefinitionsCollection 49
2.26.1 Description 49
2.26.2 Support Method and Privilege 49
2.26.3 Properties 49
2.26.3.1 Example 50
2.27 MetricDefinition 50
2.27.1 Description 50
2.27.2 Support Method and Privilege 50
2.27.3 Properties 50
2.27.4 Example 50
2.28 UpdateService 51
2.28.1 Description 51
2.28.2 Support Method and Privilege 51
2.28.3 Properties 51
2.28.3.1 Update Service Example 52
2.28.4 ActionInfo 54
2.28.5 Supported Actions 54
2.29 InsydeACDLogCollection 54

2.29.1 Description 54
2.29.2 Support Method and Privilege..... 54
2.29.3 Properties..... 54
2.29.3.1 Example.....54
2.30 InsydeACDLog 55
2.30.1 Description 55
2.30.2 Support Method and Privilege..... 55
2.30.3 Properties..... 55
2.30.3.1 Example.....55
2.31 Node Manager related schema 56
2.31.1 Description 56
2.31.2 Node Manager..... 57
2.31.2.1 Support Method and Privilege 57
2.31.2.2 Properties.....57
2.31.2.2.1 Example..... 57
2.31.2.3 Supported Action 58
2.31.2.3.1 ChangeState 58
Example payload 58
2.31.2.3.2 GetDiagnosticInfo 58
2.31.3 NmDomain Collection 58
2.31.3.1 Description 58
2.31.3.2 Support Method and Privilege 59
2.31.3.3 Properties.....59
2.31.3.3.1 Example..... 59
2.31.4 NmDomain 59
2.31.4.1 Support Method and Privilege 59
2.31.4.2 Properties.....60
2.31.4.2.1 Example..... 61
2.31.4.3 Updatable Properties 62
2.31.4.3.1 Example Payload..... 63
2.31.4.4 Supported Action 63
2.31.4.4.1 ChangeState 63
Example Payload 63
2.31.4.4.2 ResetStatistics..... 63
2.31.5 NmPolicy Collection 64
2.31.5.1 Description 64
2.31.5.2 Support Method and Privilege 64
2.31.5.3 Properties.....64
2.31.5.3.1 Example..... 64
2.31.5.4 Create a new policy by POST 64
2.31.5.4.1 Example payload..... 65
2.31.6 NmPolicy 66
2.31.6.1 Support Method and Privilege 66
2.31.6.2 Properties.....66
2.31.6.2.1 Example..... 67
2.31.6.3 Updateable Properties.....68
2.31.6.3.1 Example payload..... 68
2.31.6.4 Supported Action 69
2.31.6.4.1 ChangeState 69
Example payload 69
2.31.6.4.2 ResetStatistics..... 69
2.31.6.5 Remove Policy by DELETE 69
2.31.7 NmTrigger Collection 70
2.31.7.1 Description 70
2.31.7.2 Support Method and Privilege 70
2.31.7.3 Properties.....70
2.31.7.3.1 Example..... 70
2.31.8 NmTrigger 70
2.31.8.1 Support Method and Privilege 70

2.31.8.2 Properties 71
2.31.8.2.1 Example payload 71
2.31.9 NmThrottlingStatus 71
2.31.10 Support Method and Privilege 71
2.31.11 Properties 71
2.32 Cups Service 72
2.32.1 Description 72
2.32.2 Support Method and Privilege 72
2.32.3 Properties 72
2.32.4 Updateable Properties 73
2.33 CupsSensorsCollection 73
2.33.1 Description 73
2.33.2 Support Method and Privilege 73
2.33.3 Properties 73
2.33.3.1 Example 73

1 Introduction

This document is intended for, such as developers, users, and testers to understand the Redfish APIs supported by Insyde's OPF BMC firmware. If you are familiar with the Redfish protocol, you may like to start from sections 2 to directly focus on the implementation of OPF.

1.1 Overview

The purpose of this document is to introduce the Redfish API other than Command supported by Insyde's Intel OPF BMC firmware. It lists the available APIs with their URIs, the HTTP status codes, and also the supported methods and properties of each schema with brief descriptions.

1.2 Related Information

The following publications and sources of information are referred to by this document or may be useful to you:

- *Redfish Specification DSP0266, DMTF*
- *Redfish Resource and Schema Guide, DSP8010, DMTF, 2021.2*
- *Redfish Scalable Platforms Management API Specification, DMTF, 2019*
- *Common RAID Disk Data Format Specification, SNIA, 2009*
- *Platform Level Data Model for Platform Monitoring and Control Specification, DMTF, 2019*

1.3 Terms

The following terms are used throughout this document:

BMC

Baseboard Management Controller

IPMI

Intelligent Platform Management Interface

NIC

Network Interface Card

DCPMM

DC Persistent Memory Module

2 Schemas

2.1 Service Root

2.1.1 Description

This object represents the root Redfish service.
URI: https://{ip}/redfish/v1/

2.1.2 Support Method and Privilege

Table 1: Support Method and Privilege of Service Root

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET	V					

2.1.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx.

Table 2: Properties of Service Root

Property	Description
Cables	The link to a collection of cables. (Only for G4 platforms)
Links	Link Collection.
→ ManagerProvidingService	The link to the manager that is providing this Redfish service. (Only for G4 platforms)
Oem	Oem Extension Object.
→ Intel	Intel Oem Extension Object. (Only for G4 platforms)
→→ CupsService	This is a link to the CupsService. (Only for G4 platforms)
→ OpenBmc	OpenBmc Oem Extension Object. (Only for G3 platforms)
→→ CupsService	This is a link to the CupsService. (Only for G3 platforms)

2.1.3.1 Example

This example is the result of ServiceRoot schema's GET response.

```
{
    "@odata.id": "/redfish/v1",
    "@odata.type": "#ServiceRoot.v1_14_0.ServiceRoot",
    "AccountService": {
        "@odata.id": "/redfish/v1/AccountService"
    },
    "CertificateService": {
```

```
        "@odata.id": "/redfish/v1/CertificateService"
    },
    "Chassis": {
        "@odata.id": "/redfish/v1/Chassis"
    },
    "EventService": {
        "@odata.id": "/redfish/v1/EventService"
    },
    "Id": "RootService",
    "JsonSchemas": {
        "@odata.id": "/redfish/v1/JsonSchemas"
    },
    "Links": {
        "Sessions": {
            "@odata.id": "/redfish/v1/SessionService/Sessions"
        }
    },
    "Managers": {
        "@odata.id": "/redfish/v1/Managers"
    },
    "Name": "Root Service",
    "Oem": {
        "OpenBmc": {
            "@odata.type": "#OemServiceRoot.v1_0_0.OpenBmc",
            "CupsService": {
                "@odata.id": "/redfish/v1/CupsService"
            }
        }
    },
    "ProtocolFeaturesSupported": {
        "DeepOperations": {
            "DeepPATCH": true,
            "DeepPOST": true,
            "MaxLevels": 1
        },
        "ExcerptQuery": true,
        "ExpandQuery": {
            "ExpandAll": false,
            "Levels": false,
            "Links": false,
            "MaxLevels": 1,
            "NoLinks": false
        },
        "FilterQuery": true,
        "OnlyMemberQuery": true,
        "SelectQuery": true
    },
    "RedfishVersion": "1.9.0",
    "Registries": {
        "@odata.id": "/redfish/v1/Registries"
    },
    "SessionService": {
        "@odata.id": "/redfish/v1/SessionService"
    },
    "StorageServices": {
        "@odata.id": "/redfish/v1/StorageServices"
    },
```

```
    "Systems": {
        "@odata.id": "/redfish/v1/Systems"
    },
    "Tasks": {
        "@odata.id": "/redfish/v1/TaskService"
    },
    "TelemetryService": {
        "@odata.id": "/redfish/v1/TelemetryService"
    },
    "UUID": "0f94a050-31e4-585b-817b-f8dea670354d",
    "UpdateService": {
        "@odata.id": "/redfish/v1/UpdateService"
    }
}
```


2.2 CertificateService

2.2.1 Description

The CertificateService schema defines a Certificate Service which represents the actions available to manage certificates and links to where certificates are installed.
URI: https://{ip}/redfish/v1/CertificateService

2.2.2 Support Method and Privilege

Table 3: Support Method and Privilege of CertificateService

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
POST			V	V		

2.2.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx.

2.2.4 Supported Actions

2.2.4.1 DownloadIntelASDCertFile (Only for G4 platforms)

Description: This action is used to download intel ASD certificate file.
URI: https://{ip}/redfish/v1/CertificateService/Actions/Oem/InsydeOEMExtensions.DownloadIntelASDCertFile

Table 4: Payload Properties of DownloadIntelASDCertFile

Property	Description
Password	

2.3 CableCollection (Only for G4 platforms)

The Cable schema contains properties that describe a cable connecting endpoints of a chassis, port, or any other cable-compatible endpoint.
URI: https://{ip}/redfish/v1/Cables

2.3.1 Support Method and Privilege

Table 5: Support Method and Privilege of CableCollection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.3.2 Properties

Refer to Supervyse OPF Redfish API User Guide.docx#Resource Collection Section.

2.4 Cable (Only for G4 platforms)

2.4.1 Description

The Cable schema contains properties that describe a cable connecting endpoints of a chassis, port, or any other cable-compatible endpoint.
URI: https://{ip}/redfish/v1/Cables/<CableId>

2.4.2 Support Method and Privilege

Table 6: Support Method and Privilege of Cable

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.4.3 Properties

Table 7: Properties of Cable

Property	Description
CableType	The type of this cable.
LengthMeters	The length of the cable in meters.
Status	*Refer to Supervyse OPF Redfish API User Guide.docx#Status Object*

2.5 Chassis

2.5.1 Description

The Chassis schema represents the physical components of a system. This resource represents the sheet-metal confined spaces and logical zones such as racks, enclosures, chassis and all other containers. Subsystems (like sensors) that operate outside of a system's data plane (meaning the resources are not accessible to software running on the system) are linked either directly or indirectly through this resource.
URI: https://{ip}/redfish/v1/Chassis/<ChassisID>

2.5.2 Support Method and Privilege

Table 8: Support Method and Privilege of Chassis

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
PATCH				V		
POST				V		

2.5.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

Table 9: Properties of Chassis

Property	Description
Actions	The available actions for this Resource.
Power	The link to the power properties, or power supplies, power policies, and sensors, for this chassis. (Only for G3 platforms)
Thermal	The link to the thermal properties, such as fans, cooling, and sensors, for this chassis. (Only for G3 platforms)

2.5.4 Updatable Properties

Refer to Supervyse OPF Redfish API User Guide.docx

2.5.5 Supported Actions

2.5.5.1 Reset Chassis

Description: This action is used to reset the chassis
URI: https://{ip}/redfish/v1/Chassis/<ChassisID>/Actions/Chassis.Reset

Table 10: Payload Properties of Reset Chassis

Property	Allowed Value	Description

ResetType	PowerCycle	Power cycle the unit.

2.5.5.1.1 Example payload

```
{
    "ResetType": "PowerCycle"
}
```

2.5.6 ActionInfo

2.5.6.1 ResetActionInfo

Descriptions: Deliver allowable values of ResetType.
URI: https://{ip}/redfish/v1/Chassis/<ChassisID>/ResetActionInfo/

2.5.6.1.1 Support Method and Privilege

Table 11: Support Method and Privilege of ResetActionInfo

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.5.6.1.2 Properties

Table 12: Properties of ResetActionInfo

Property	Description
Parameters	An array of object.
→AllowableValues	The current allowable values for ResetType, including "PowerCycle".
→DataType	The data type of value of ResetType.
→Name	ResetType.
→Required	Determine if argument ResetType was required when doing action.

Example

This example is the result of a GET response.

```
{
    "@odata.context": "/redfish/v1/$metadata#ActionInfo.ActionInfo",
    "@odata.id": "/redfish/v1/Chassis/Onyx_Baseboard/ResetActionInfo",
    "@odata.type": "#ActionInfo.v1_2_0.ActionInfo",
    "Id": "ResetActionInfo",
    "Name": "Reset Action Info",
    "Parameters": [
        {
            "AllowableValues": [
                "PowerCycle"
            ],
            "DataType": "String",
```

```
            "Name": "ResetType",
            "Required": true
        }
    ]
}
```

2.6 Power (Only for G3 platforms)

2.6.1 Description

This is the schema definition for the Power Metrics. It represents the properties for Power Consumption and Power Limiting.
URI: https://{ip}/redfish/v1/Chassis/<ChassisID>/Power

2.6.2 Support Method and Privilege

Table 13: Support Method and Privilege of Power

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
PATCH			V			

2.6.3 Properties

Table 14: Properties of Power

Property	Description
PowerControl	This is the definition for power control function (power reading/limiting)
→ MemberId	This is the identifier for the member within the collection.
→ Oem	(Only for G4 platforms)
→→ OpenBmc	(Only for G4 platforms)
→→→ PowerLimitStorage	(Only for G4 platforms)
→ PowerAllocatedWatts	The total amount of power that has been allocated or budgeted to chassis. (Only for G4 platforms)
→ PowerCapacityWatts	The total amount of power that can be allocated to the chassis. This value can be either the power supply capacity or the power budget that an upstream chassis assigns to this chassis.
→ PowerConsumedWatts	This property shall represent the actual power that the chassis consumes, inwatts
→ PowerLimit	The power limit status and configuration information for this chassis.
→→ CorrectionInMs	The time required for the limiting process to reduce power consumption to below the limit. (Only for G4 platforms)

→→LimitException	The action that is taken if the power cannot be maintained below the LimitInWatts.
→→LimitInWatts	The Power limit in watts. Set to 0 to disable power capping.
→ PowerMetrics	The power readings for this chassis. (Only for G4 platforms)
→→ AverageConsumedWatts	The average power level over the measurement window over the last IntervalInMin minutes. (Only for G4 platforms)
→→ IntervalInMin	The time interval, or window, over which the power metrics are measured. (Only for G4 platforms)
→→ MaxConsumedWatts	The highest power consumption level, in watt units, that has occurred over the measurement window within the last IntervalInMin minutes. (Only for G4 platforms)
→→ MinConsumedWatts	The lowest power consumption level, in watt units, over the measurement window that occurred within the last IntervalInMin minutes. (Only for G4 platforms)
→ PowerRequestedWatts	The potential power, in watt units, that the chassis requests, which might be higher than the current level being consumed because the requested power includes a budget that the chassis wants for future use. (Only for G4 platforms)
→ RelatedItem	An array of links to resources or objects associated with this power limit. (Only for G4 platforms)
Redundancy	Redundancy information for the power subsystem of this system or device. This will be displayed if supported.
→MemberId	This is the identifier for the member within the collection
→MinNumNeeded	This is the minumum number of members needed for this group to be redundant.
→Mode	This is the redundancy mode of the group.
→RedundancySet	Contains any ids that represent components of this redundancy set.
→Status	*Refer to Supervyse OPF Redfish API User Guide.docx#Status Object*
Voltages	This is the definition for voltage sensors. This will be displayed if supported.
→MaxReadingRange	Maximum value for Reading.
→MemberId	This is the identifier for the member within the collection.
→MinReadingRange	Minimum value for Reading.
→ReadingVolts	The present reading of the voltage sensor.
→Status	*Refer to Supervyse OPF Redfish API User Guide.docx#Status Object*

2.6.3.1 Example

This example is the result of Power schema's GET response.

```
{
    "@odata.id": "/redfish/v1/Chassis/AC_Modular_Baseboard/Power",
    "@odata.type": "#Power.v1_7_1.Power",
    "Id": "Power",
```

```
    "Name": "Power",
    "PowerControl": [
        {
            "@odata.id": "/redfish/v1/Chassis/AC_Modular_Baseboard/Power#/PowerControl/0",
            "@odata.type": "#Power.v1_7_1.PowerControl",
            "MemberId": "0",
            "Name": "Chassis Power Control",
            "PowerCapacityWatts": null,
            "PowerConsumedWatts": 0.0,
            "PowerLimit": {
                "LimitException": "NoAction",
                "LimitInWatts": null
            }
        }
    ],
    "Redundancy": [],
    "Voltages": [
        {
            "@odata.id": "/redfish/v1/Chassis/AC_Modular_Baseboard/Power#/Voltages/0",
            "@odata.type": "#Power.v1_7_1.Voltage",
            "MaxReadingRange": 300.0,
            "MemberId": "0",
            "MinReadingRange": 0.0,
            "Name": "PSU1 Input Voltage",
            "ReadingVolts": 105.0,
            "Status": {
                "Health": "OK",
                "State": "Enabled"
            }
        }
    ]
}
```


2.6.4 Updatable Properties

Table 15: Updatable Properties of Power

Property	Allowed value	Description
PowerControl	Array	
→PowerLimit	Object	
→→LimitInWatts	Unsigned Integer(32)	0 - 4294967295

2.6.4.1 Example payload


```
{
    "PowerControl": [
        {
            "PowerLimit": {
                "LimitInWatts": 500
            }
        }
    ]
}
```

2.7 Thermal (Only for G3 platforms)

2.7.1 Description

This is the schema definition for the Thermal properties. It represents the properties for Temperature and Cooling.
URI: https://{ip}/redfish/v1/Chassis/<ChassisID>/Thermal

2.7.2 Support Method and Privilege

Table 16: Support Method and Privilege of Thermal

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.7.3 Properties

The property or object will be displayed if the Chassis support.

Table 17: Properties of Thermal

Property	Description
Fans	This is the definition for fans. This will be displayed if sensors of this type existed.
→LowerThresholdCritical	Below normal range but not yet fatal.
→LowerThresholdNonCritical	Below normal range.
→MaxReadingRange	Maximum value for Reading.
→MemberId	This is the identifier for the member within the collection.
→MinReadingRange	Minimum value for Reading.
→Reading	Current fan speed.
→ReadingUnits	The units in which the fan reading and thresholds are measured.
→Status	*Refer to Supervyse OPF Redfish API User Guide.docx#Status Object*
Redundancy	Redundancy information for the power subsystem of this system or device. This will be displayed if supported.
→ MinNumNeeded	This is the minumum number of members needed for this group to be redundant.
→ Mode	This is the redundancy mode of the group.
→ RedundancySet	Contains any ids that represent components of this redundancy set.
→Status	*Refer to Supervyse OPF Redfish API User Guide.docx#Status Object*
Temperatures	This property shall specify a valid odata or Redfish property. This will be displayed if sensors of this type existed.

→LowerThresholdCritical	Below normal range but not yet fatal.
→LowerThresholdNonCritical	Below normal range.
→MaxReadingRange	Maximum value for Reading.
→MemberId	This is the identifier for the member within the collection.
→MinReadingRange	Minimum value for Reading.
→ PhysicalContext	The area or device to which this temperature measurement applies.
→ReadingCelsius	The value of this property shall be the current value of the temperature sensor's reading
→Status	*Refer to Supervyse OPF Redfish API User Guide.docx#Status Object*
→UpperThresholdCritical	Above normal range but not yet fatal.
→UpperThresholdNonCritical	Above normal range.

2.7.3.1 Example

This example is the result of Thermal schema's GET response.


```
{
  "@odata.id": "/redfish/v1/Chassis/AC_Baseboard/Thermal",
  "@odata.type": "#Thermal.v1_7_1.Thermal",
  "Fans": [],
  "Id": "Thermal",
  "Name": "Thermal",
  "Redundancy": [],
  "Temperatures": [
    {
      "@odata.id": "/redfish/v1/Chassis/AC_Baseboard/Thermal#/Temperatures/0",
      "@odata.type": "#Thermal.v1_7_1.Temperature",
      "LowerThresholdCritical": 0.0,
      "LowerThresholdNonCritical": 5.0,
      "MaxReadingRangeTemp": 127.0,
      "MemberId": "BMC_Temp",
      "MinReadingRangeTemp": -128.0,
      "Name": "BMC Temp",
      "PhysicalContext": "SystemBoard",
      "ReadingCelsius": 50.0,
      "Status": {
        "Health": "OK",
        "State": "Enabled"
      },
      "UpperThresholdCritical": 115.0,
      "UpperThresholdNonCritical": 110.0
    },
    {
      "@odata.id": "/redfish/v1/Chassis/AC_Baseboard/Thermal#/Temperatures/1",
      "@odata.type": "#Thermal.v1_7_1.Temperature",
      "LowerThresholdCritical": 0.0,
      "LowerThresholdNonCritical": 5.0,
      "MaxReadingRangeTemp": 255.0,
```

```
      "MemberId": "CPU1_PVCCD_VR_Temp",
      "MinReadingRangeTemp": 0.0,
      "Name": "CPU1 PVCCD VR Temp",
      "PhysicalContext": "CPU",
      "ReadingCelsius": null,
      "Status": {
        "Health": "OK",
        "State": "Enabled"
      },
      "UpperThresholdCritical": 115.0,
      "UpperThresholdNonCritical": 110.0
    },
    {
      "@odata.id": "/redfish/v1/Chassis/AC_Baseboard/Thermal#/Temperatures/2",
      "@odata.type": "#Thermal.v1_7_1.Temperature",
      "LowerThresholdCritical": 0.0,
      "LowerThresholdNonCritical": 5.0,
      "MaxReadingRangeTemp": 255.0,
      "MemberId": "CPU1_PVCCFA_EHV_FIVRA_VR_Temp",
      "MinReadingRangeTemp": 0.0,
      "Name": "CPU1 PVCCFA EHV FIVRA VR Temp",
      "PhysicalContext": "CPU",
      "ReadingCelsius": null,
      "Status": {
        "Health": "OK",
        "State": "Enabled"
      },
      "UpperThresholdCritical": 115.0,
      "UpperThresholdNonCritical": 110.0
    },
    {
      "@odata.id": "/redfish/v1/Chassis/AC_Baseboard/Thermal#/Temperatures/3",
      "@odata.type": "#Thermal.v1_7_1.Temperature",
      "LowerThresholdCritical": 0.0,
      "LowerThresholdNonCritical": 5.0,
      "MaxReadingRangeTemp": 127.0,
      "MemberId": "CPU1_South_VR_Temp",
      "MinReadingRangeTemp": -128.0,
      "Name": "CPU1 South VR Temp",
      "PhysicalContext": "CPU",
      "ReadingCelsius": 49.937,
      "Status": {
        "Health": "OK",
        "State": "Enabled"
      },
      "UpperThresholdCritical": 115.0,
      "UpperThresholdNonCritical": 110.0
    }
  ]
}
```

2.8 ThermalSubsystem

2.8.1 Description

This ThermalSubsystem schema contains the definition for the thermal subsystem of a chassis.
URI: https://{ip}/redfish/v1/Chassis/<ChassisId>/ThermalSubsystem

2.8.2 Support Method and Privilege

Table 18: Support Method and Privilege of ThermalSubsystem

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.8.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

Table 19: Properties of ThermalSubsystem

Property	Description
FanRedundancy	The redundancy information for the devices in a redundancy group. (Only for G4 platforms)
→ MaxSupportedInGroup	The maximum number of devices supported in this redundancy group. (Only for G4 platforms)
→ MinNeededInGroup	The minimum number of devices needed for this group to be redundant. (Only for G4 platforms)
→ RedundancyGroup	The links to the devices included in this redundancy group. (Only for G4 platforms)
→ RedundancyType	The redundancy mode of the group. (Only for G4 platforms)
→ Status	*Refer to Supervyse OPF Redfish API User Guide.docx#StatusObject* (Only for G4 platforms)

2.9 Manager

2.9.1 Description

This is the schema definition for a Manager. Examples of managers are BMCs, Enclosure Managers, Management Controllers and other subsystems assigned manageability functions.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>

Default ManagerID is "bmc".

2.9.2 Support Method and Privilege

Table 20: Support Method and Privilege of Manager

	NoAuth	Login	Configure Manager	Configure Components	Configure Users	Configure Self
GET		V				
PATCH			V			
POST			V			

2.9.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

Table 21: Properties of Manager

Property	**Description**
Oem	Oem Extension Object.
→ OpenBmc	OpenBmc Oem Extension Object
→→ Fan	Oem extension object for Fan.
→→→ FanControllers	Container for OpenBmc fan controllers. Refs to FanControllers.
→→→ FanZones	Container for OpenBmc fan zones. Refs to FanZones.
→→→ PidControllers	Container for OpenBmc pid controllers. Refs to PidControllers.
→→→ Profile	Current thermal profile.
→→→ Profile@Redfish.AllowableValues	This term indicates to the client that the service supports the values for Profile.
→→→ StepwiseControllers	Container for OpenBmc Stepwise controllers. Refs to StepwiseControllers.
→→ NodeManager	This is a link to the NodeManager.

2.9.3.1 Example

This examples is the result of Manager schema's GET response.

```
{
    "@odata.id": "/redfish/v1/Managers/bmc",
    "@odata.type": "#Manager.v1_15_0.Manager",
    "Actions": {
        "#Manager.Reset": {
            "@Redfish.ActionInfo": "/redfish/v1/Managers/bmc/ResetActionInfo",
            "target": "/redfish/v1/Managers/bmc/Actions/Manager.Reset"
        },
        "#Manager.ResetToDefaults": {
            "ResetType@Redfish.AllowableValues": [
                "ResetAll"
            ],
```

```
            "target": "/redfish/v1/Managers/bmc/Actions/Manager.ResetToDefaults"
        },
        "Oem": {
            "#InsydeOEMExtensions.VMInstance": {
                "target": "/redfish/v1/Managers/bmc/Actions/Oem/InsydeOEMExtensions.VMInstance"
            }
        }
    },
    "CommandShell": {
        "ConnectTypesSupported": [
            "SSH",
            "IPMI"
        ],
        "MaxConcurrentSessions": 4,
        "ServiceEnabled": true
    },
    "DateTime": "2024-05-28T09:39:55+00:00",
    "DateTimeLocalOffset": "+00:00",
    "Description": "Baseboard Management Controller",
    "EthernetInterfaces": {
        "@odata.id": "/redfish/v1/Managers/bmc/EthernetInterfaces"
    },
    "FirmwareVersion": "35.24.15.1217",
    "GraphicalConsole": {
        "ConnectTypesSupported": [
            "KVMIP"
        ],
        "MaxConcurrentSessions": 4,
        "ServiceEnabled": true
    },
    "HostInterfaces": {
        "@odata.id": "/redfish/v1/Managers/bmc/HostInterfaces"
    },
    "Id": "bmc",
    "LastResetTime": "2024-05-27T02:52:52+00:00",
    "Links": {
        "ActiveSoftwareImage": {
            "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/bmc_active"
        },
        "ManagerForChassis": [
            {
                "@odata.id": "/redfish/v1/Chassis/AC_Baseboard"
            }
        ],
        "ManagerForChassis@odata.count": 1,
        "ManagerForServers": [
            {
                "@odata.id": "/redfish/v1/Systems/system"
            }
        ],
        "ManagerForServers@odata.count": 1,
        "ManagerInChassis": {
            "@odata.id": "/redfish/v1/Chassis/AC_Baseboard"
        },
        "SoftwareImages": [
            {
                "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory/bmc_active"
```

```
            }
        ],
        "SoftwareImages@odata.count": 1
    },
    "LogServices": {
        "@odata.id": "/redfish/v1/Managers/bmc/LogServices"
    },
    "ManagerType": "BMC",
    "Model": "OpenBmc",
    "Name": "OpenBmc Manager",
    "NetworkProtocol": {
        "@odata.id": "/redfish/v1/Managers/bmc/NetworkProtocol"
    },
    "Oem": {
        "@odata.id": "/redfish/v1/Managers/bmc#/Oem",
        "@odata.type": "#OemManager.Oem",
        "IPAccessControl": {
            "IPv4AccessControl": {
                "@odata.id": "/redfish/v1/Managers/bmc/Oem/Insyde/IPv4AccessCollection"
            },
            "IPv6AccessControl": {
                "@odata.id": "/redfish/v1/Managers/bmc/Oem/Insyde/IPv6AccessCollection"
            }
        },
        "OpenBmc": {
            "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc",
            "@odata.type": "#OemManager.OpenBmc",
            "Certificates": {
                "@odata.id": "/redfish/v1/Managers/bmc/Truststore/Certificates"
            },
            "Fan": {
                "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan",
                "@odata.type": "#OemManager.Fan",
                "FanControllers": {
                    ...
                    ...
                    ...
                },
                "FanZones": {
                    ...
                    ...
                    ...
                },
                "PidControllers": {
                    ...
                    ...
                    ...
                },
                "Profile": "Performance",
                "Profile@Redfish.AllowableValues": [
                    "Acoustic",
                    "Performance"
                ],
                "StepwiseControllers": {
                    ...
                    ...
                    ...
```

```
                }
            },
            "NodeManager": {
                "@odata.id": "/redfish/v1/Managers/bmc/NodeManager"
            },
            "SyslogService": {
                "@odata.id": "/redfish/v1/Managers/bmc/SyslogService"
            }
        }
    },
    "PowerState": "On",
    "SerialConsole": {
        "ConnectTypesSupported": [
            "IPMI",
            "SSH"
        ],
        "MaxConcurrentSessions": 15,
        "ServiceEnabled": true
    },
    "ServiceEntryPointUUID": "0f94a050-31e4-585b-817b-f8dea670354d",
    "Status": {
        "Health": "Warning",
        "HealthRollup": "Critical",
        "State": "Enabled"
    },
    "UUID": "ee78c158-a7a8-417a-aaa6-8bc466fea1c5",
    "VirtualMedia": {
        "@odata.id": "/redfish/v1/Managers/bmc/VirtualMedia"
    }
}
```


2.10 FanControllers

2.10.1 Description

Container for OpenBmc fan controllers.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>#/Oem/OpenBmc/Fan/FanControllers

2.10.2 Support Method and Privilege

Table 22: Support Method and Privilege of FanControllers

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
PATCH			V			

2.10.3 Properties

Table 23: Properties of FanControllers

Property	Description
FanController	Configuration data for Fan Controllers.
→ FFGainCoefficient	Feed forward gain coefficient for the PID.
→ FFOffCoefficient	Feed forward offset coefficient for the PID.
→ ICoefficient	Integral Coefficient for the PID.
→ ILimitMax	Integral limit maximum for the PID.
→ ILimitMin	Integral limit minimum for the PID.
→ Inputs	Input sensors to the PID controller.
→ NegativeHysteresis	Negative hysteresis for the controller.
→ OutLimitMax	Output limit maximum for the pwm.
→ OutLimitMin	Output limit minimum for the pwm.
→ Outputs	Output sensors to the PID controller.
→ PCoefficient	Polynomial coefficient for the PID.
→ PositiveHysteresis	Positive hysteresis for the controller.
→ SlewNeg	Negative slew rate for the PID.
→ SlewPos	Positive slew rate for the PID.
→ Zones	Contains the Zones that this PID contributes to.

2.10.3.1 Example

This examples is the result of FanControllers schema's GET response.


```
{
    "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanControllers",
    "@odata.type": "#OemManager.FanControllers",
    "Fan_1": {
        "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanControllers/Fan_1",
        "@odata.type": "#OemManager.FanController",
        "FFGainCoefficient": 1.0,
        "FFOffCoefficient": 0.0,
        "ICoefficient": 0.0,
        "ILimitMax": 0.0,
        "ILimitMin": 0.0,
        "Inputs": [
            "Fan 1"
        ],
        "NegativeHysteresis": 0.0,
        "OutLimitMax": 100.0,
```

```
        "OutLimitMin": 30.0,
        "Outputs": [
            "Pwm 1"
        ],
        "PCoefficient": 0.0,
        "PositiveHysteresis": 0.0,
        "SlewNeg": 0.0,
        "SlewPos": 0.0,
        "Zones": [
            {
                "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/Left"
            }
        ]
    },
    "Fan_10": {
            ...
            ...
            ...
    },
    "PSU1_Fan_2": {
        "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanControllers/PSU1_Fan_2",
        "@odata.type": "#OemManager.FanController",
        "FFGainCoefficient": 1.0,
        "FFOffCoefficient": 0.0,
        "ICoefficient": 0.0,
        "ILimitMax": 0.0,
        "ILimitMin": 0.0,
        "Inputs": [
            "PSU1 Fan Speed 2"
        ],
        "NegativeHysteresis": 2.0,
        "OutLimitMax": 100.0,
        "OutLimitMin": 30.0,
        "Outputs": [
            "Pwm PSU1 Fan 2"
        ],
        "PCoefficient": 0.0,
        "PositiveHysteresis": 0.0,
        "SlewNeg": 0.0,
        "SlewPos": 0.0,
        "Zones": [
            {
                "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/PSU"
            }
        ]
    }
}
```


2.10.4 Updatable Properties

Table 24: Updatable Properties of FanControllers

Property	Allowed value
FanController	OBJECT

→ FFGainCoefficient	Number
→ FFOffCoefficient	Number
→ ICoefficient	Number
→ ILimitMax	Number
→ ILimitMin	Number
→ Inputs	Array
→ NegativeHysteresis	Number
→ OutLimitMax	Number
→ OutLimitMin	Number
→ Outputs	Array
→ PCoefficient	Number
→ PositiveHysteresis	Number
→ SlewNeg	Number
→ SlewPos	Number
→ Zones	OBJECT
→ @odata.id	Valid url of the FanZone

2.10.4.1 Example Payload


```
{
    "Oem": {
        "OpenBmc": {
            "Fan": {
                "FanControllers": {
                    "Fan_1": {
                        "FFGainCoefficient": 1.0,
                        "FFOffCoefficient": 0.0,
                        "ICoefficient": 0.0,
                        "ILimitMax": 0.0,
                        "ILimitMin": 0.0,
                        "Inputs": [
                            "Fan 1"
                        ],
                        "NegativeHysteresis": 0.0,
                        "OutLimitMax": 100.0,
                        "OutLimitMin": 30.0,
                        "Outputs": [
                            "Pwm 1"
                        ],
                        "PCoefficient": 0.0,
                        "PositiveHysteresis": 0.0,
                        "SlewNeg": 0.0,
```

```
                        "SlewPos": 0.0,
                        "Zones": [
                            {
                                "@odata.id":
"/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/Left"
                            }
                        ]
                    }
                }
            }
        }
    }
}
```

2.11 FanZones

2.11.1 Description

Container for OpenBmc fan zones.
URI: https://{ip}/redfish/v1/Managers/#/Oem/OpenBmc/Fan/FanZones

2.11.2 Support Method and Privilege

Table 25: Support Method and Privilege of FanZones

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
PATCH			V			

2.11.3 Properties

Table 26: Properties of FanZones

Property	Description
FanZone	Configuration data for Fan Controllers.
→ Chassis	The Chassis that enables this Zone.
→ FailSafePercent	If the sensors are in fail-safe mode, this is the percentage to use.
→ MinThermalOutput	Minimum thermal RPM that can be set in this Zone.

2.11.3.1 Example

This examples is the result of FanZones schema's GET response.

```
{
    "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones",
    "@odata.type": "#OemManager.FanZones",
    "Left": {
        "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/Left",
```

```
        "@odata.type": "#OemManager.FanZone",
        "Chassis": {
            "@odata.id": "/redfish/v1/Chassis/AC_Baseboard"
        },
        "FailSafePercent": 100.0,
        "MinThermalOutput": 30.0
    },
    "PSU": {
        "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/PSU",
        "@odata.type": "#OemManager.FanZone",
        "Chassis": {
            "@odata.id": "/redfish/v1/Chassis/AC_Baseboard"
        },
        "FailSafePercent": 100.0,
        "MinThermalOutput": 30.0
    },
    "Right": {
        "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/Right",
        "@odata.type": "#OemManager.FanZone",
        "Chassis": {
            "@odata.id": "/redfish/v1/Chassis/AC_Baseboard"
        },
        "FailSafePercent": 100.0,
        "MinThermalOutput": 30.0
    }
}
```


2.11.4 Updatable Properties

Table 27: Updatable Properties of FanZones

Property	Allowed value
FanZone	OBJECT
→ FailSafePercent	Number
→ MinThermalOutput	Number

2.11.4.1 Example Payload


```
{
    "Oem": {
        "OpenBmc": {
            "Fan": {
                "FanZones": {
                    "Left": {
                        "FailSafePercent": 100.0,
                        "MinThermalOutput": 30.0
                    }
                }
            }
        }
    }
}
```

2.12 PidControllers

2.12.1 Description

Container for OpenBmc pid controllers.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>#/Oem/OpenBmc/Fan/FanControllers

2.12.2 Support Method and Privilege

Table 28: Support Method and Privilege of PidControllers

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
PATCH			V			

2.12.3 Properties

Table 29: Properties of PidController

Property	Description
PidController	Configuration data for Fan Controllers.
→ FFGainCoefficient	Feed forward gain coefficient for the PID.
→ FFOffCoefficient	Feed forward offset coefficient for the PID.
→ ICoefficient	Integral Coefficient for the PID.
→ ILimitMax	Integral limit maximum for the PID.
→ ILimitMin	Integral limit minimum for the PID.
→ Inputs	Input sensors to the PID controller.
→ NegativeHysteresis	Negative hysteresis for the controller.
→ OutLimitMax	Output limit maximum for the pwm.
→ OutLimitMin	Output limit minimum for the pwm.
→ PCoefficient	Polynomial coefficient for the PID.
→ PositiveHysteresis	Positive hysteresis for the controller.
→ SetPoint	Setpoint for the PID.
→ SetPointOffset	Threshold to take value from and apply to setpoint. Valid threshold names are supported.
→ SlewNeg	Negative slew rate for the PID.
→ SlewPos	Positive slew rate for the PID.

→ Zones	Contains the Zones that this PID contributes to.

2.12.3.1 Example

This examples is the result of PidControllers schema's GET response.


```
{
    "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/PidControllers",
    "@odata.type": "#OemManager.PidControllers",
    "BMC_Temp": {
        "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/PidControllers/BMC_Temp",
        "@odata.type": "#OemManager.PidController",
        "FFGainCoefficient": 0.0,
        "FFOffCoefficient": 0.0,
        "ICoefficient": -1.0,
        "ILimitMax": 100.0,
        "ILimitMin": 30.0,
        "Inputs": [
            "BMC Temp"
        ],
        "NegativeHysteresis": 5.0,
        "OutLimitMax": 100.0,
        "OutLimitMin": 30.0,
        "PCoefficient": -0.15,
        "PositiveHysteresis": 0.0,
        "SetPoint": 80.0,
        "SlewNeg": -1.0,
        "SlewPos": 0.0,
        "Zones": [
            {
                "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/Left"
            }
        ]
    },
    "CPU1_DIMM_ABC": {
        ...
        ...
        ...
    },
    "Right_Rear_Board": {
        "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/PidControllers/Right_Rear_Board",
        "@odata.type": "#OemManager.PidController",
        "FFGainCoefficient": 0.0,
        "FFOffCoefficient": 0.0,
        "ICoefficient": -1.0,
        "ILimitMax": 100.0,
        "ILimitMin": 30.0,
        "Inputs": [
            "Right Rear Board"
        ],
        "NegativeHysteresis": 5.0,
        "OutLimitMax": 100.0,
        "OutLimitMin": 30.0,
        "PCoefficient": -0.15,
        "PositiveHysteresis": 0.0,
        "SetPoint": 60.0,
        "SlewNeg": -1.0,
```

```
        "SlewPos": 0.0,
        "Zones": [
            {
                "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/Left"
            }
        ]
    }
}
```

2.12.4 Updatable Properties

Table 30: Updatable Properties of PidControllers

Property	Allowed value
PidController	OBJECT
→ FFGainCoefficient	Number
→ FFOffCoefficient	Number
→ ICoefficient	Number
→ ILimitMax	Number
→ ILimitMin	Number
→ Inputs	Array
→ NegativeHysteresis	Number
→ OutLimitMax	Number
→ OutLimitMin	Number
→ Outputs	Array
→ PCoefficient	Number
→ PositiveHysteresis	Number
→ SlewNeg	Number
→ SlewPos	Number
→ Zones	OBJECT
→ @odata.id	Valid url of the FanZone

2.12.4.1 Example Payload

```
{
    "Oem": {
        "OpenBmc": {
            "Fan": {
                "PidControllers": {
                    "Right_Rear_Board": {
```

```
                        "FFGainCoefficient": 0.0,
                        "FFOffCoefficient": 0.0,
                        "ICoefficient": -1.0,
                        "ILimitMax": 100.0,
                        "ILimitMin": 30.0,
                        "Inputs": [
                            "Right Rear Board"
                        ],
                        "NegativeHysteresis": 5.0,
                        "OutLimitMax": 100.0,
                        "OutLimitMin": 30.0,
                        "PCoefficient": -0.15,
                        "PositiveHysteresis": 0.0,
                        "SetPoint": 60.0,
                        "SlewNeg": -1.0,
                        "SlewPos": 0.0,
                        "Zones": [
                            {
                                "@odata.id":
"/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/Left"
                            }
                        ]
                    }
                }
            }
        }
    }
}
```


2.13 StepwiseControllers

2.13.1 Description

Container for OpenBmc fan controllers.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>#/Oem/OpenBmc/Fan/FanControllers

2.13.2 Support Method and Privilege

Table 31: Support Method and Privilege of StepwiseControllers

	NoAuth	Login	ConfigureManager	ConfigureComponents	ConfigureUsers	ConfigureSelf
GET		V				

2.13.3 Properties

Table 32: Properties of StepwiseControllers

Property	Description
StepwiseController	Configuration data for Stepwise Controllers.
→ Inputs	Input sensors to the Stepwise controller.

→ NegativeHysteresis	Negative Hysteresis for the stepwise controller.
→ PositiveHysteresis	Positive Hysteresis for the stepwise controller.
→ Steps	Temperature vs RPM steps for the stepwise controller.
→→ Output	Fan speed setting for step.
→→ Target	Input sensor reading for step.
→ Zones	Contains the Zones that this controller contributes to.

2.13.3.1 Example

This examples is the result of StepwiseControllers schema's GET response.


```
{
    "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/StepwiseControllers",
    "@odata.type": "#OemManager.StepwiseControllers",
    "Front_Panel_LCC": {
        "@odata.id":
"/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/StepwiseControllers/Front_Panel_LCC",
        "@odata.type": "#OemManager.StepwiseController",
        "Direction": "Floor",
        "Inputs": [
            "Front Panel Temp"
        ],
        "NegativeHysteresis": 2.0,
        "PositiveHysteresis": 0.0,
        "Steps": [
            {
                "Output": 50.0,
                "Target": 20.0
            },
            {
                "Output": 60.0,
                "Target": 30.0
            }
        ],
        "Zones": [
            {
                "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/Left"
            },
            {
                "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/Right"
            }
        ]
    },
    "PSU1_LCC": {
        "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/StepwiseControllers/PSU1_LCC",
        "@odata.type": "#OemManager.StepwiseController",
        "Direction": "Floor",
        "Inputs": [
            "PSU1 Temperature"
        ],
        "NegativeHysteresis": 2.0,
        "PositiveHysteresis": 0.0,
```

```
        "Steps": [
            {
                "Output": 40.0,
                "Target": 30.0
            },
            {
                "Output": 100.0,
                "Target": 65.0
            }
        ],
        "Zones": [
            {
                "@odata.id": "/redfish/v1/Managers/bmc#/Oem/OpenBmc/Fan/FanZones/PSU"
            }
        ]
    }
}
```


2.14 EthernetInterfaceCollection

2.14.1 Description

A Collection of EthernetInterface resource instances.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/EthernetInterfaces

URI: https://{ip}/redfish/v1/Systems/<SystemID>/EthernetInterfaces

2.14.2 Support Method and Privilege

Table 33: Support Method and Privilege of EthernetInterfaceCollection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.14.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

2.15 VlanNetworkInterfaceCollection (Only for G3 platforms)

2.15.1 Description

A Collection of VLanNetworkInterface resource instances.
URI: https://{ip}/redfish/v1/Managers/{ManagerId}/EthernetInterfaces/{EthernetInterfaceId}/VLANs

2.15.2 Support Method and Privilege

Table 34: Support Method and Privilege of VlanNetworkInterfaceCollection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
POST				V		

2.15.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx#*Resource Collection Section*.

2.15.3.1 Example

This example is the result of Manager schema's GET response.

```
{
  "@odata.id": "/redfish/v1/Managers/bmc/EthernetInterfaces/eth0/VLANs",
  "@odata.type": "#VLanNetworkInterfaceCollection.VLanNetworkInterfaceCollection",
  "Members": [],
  "Members@odata.count": 0,
  "Name": "VLAN Network Interface Collection"
}
```

2.15.4 Establish VLAN by POST

URI: https://{ip}/redfish/v1/Managers/{ManagerId}/EthernetInterfaces/{EthernetInterfaceId}/VLANs/

Table 35: Payload Properties of Establish VLAN by POST

Property	Required	Allowed Value
VLANId	Yes	1~255
VLANEnable	Yes	True

2.15.4.1 Example Payload

```
{
    "VLANId": 1,
    "VLANEnable": true
}
```

2.16 VlanNetworkInterface (Only for G3 platforms)

2.16.1 Description

The VLanNetworkInterface schema describes a VLAN network instance that is available on a manager, system, or other device.

URI:
https://{ip}/redfish/v1/Managers/{ManagerId}/EthernetInterfaces/{EthernetInterfaceId}/VLANs/{VLanNetworkInterfaceId}

P.S Only for G3 platforms

2.16.2 Support Method and Privilege

Table 36: Support Method and Privilege of VlanNetworkInterface

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
PATCH				V		
DELETE				V		

2.16.3 Properties

Table 37: Properties of VlanNetworkInterface

Property	Description
VLANEnable	An indication of whether this VLAN is enabled for this VLAN network interface.
VLANId	The ID for this VLAN.

2.16.4 Updatable Properties

Table 38: Updatable Properties of VlanNetworkInterface

Property	Allowed value	Description
VLANEnable	BOOLEAN	An indication of whether this VLAN is enabled for this VLAN network interface.
VLANId	1~255	The ID for this VLAN.

2.16.4.1 Example Payload

```
{
    "VLANId": 1,
    "VLANEnable": true
}
```

2.16.5 Remove VLAN by DELETE

Description: VLAN are removed with a Delete operation.

URI:
https://{ip}/redfish/v1/Managers/{ManagerId}/EthernetInterfaces/{EthernetInterfaceId}/VLANs/{VLanNetworkInterfaceId}

2.17 LogService

2.17.1 Description

This resource represents the log service for the resource or service to which it is associated.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/LogServices/<LogType>

URI: https://{ip}/redfish/v1/Systems/<SystemID>/LogServices/<LogType>

- Journal: /redfish/v1/Managers/bmc/LogServices/Journal
- Crashdump: /redfish/v1/Systems/system/LogService/Crashdump
- acpi: /redfish/v1/Systems/system/LogServices/acpi

Refer to Supervyse OPF Redfish API User Guide.docx

2.17.2 Support Method and Privilege

Table 39: Support Method and Privilege of LogService

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.17.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

2.17.3.1 Example

These examples are the result of LogService schema's GET response.
This is "/redfish/v1/Managers/bmc/LogServices/Journal" example:

```
{
    "@odata.id": "/redfish/v1/Managers/bmc/LogServices/Journal",
    "@odata.type": "#LogService.v1_3_0.LogService",
    "DateTime": "2024-08-19T08:09:22+00:00",
    "DateTimeLocalOffset": "+00:00",
    "Description": "BMC Journal Log Service",
    "Entries": {
        "@odata.id": "/redfish/v1/Managers/bmc/LogServices/Journal/Entries"
    },
    "Id": "Journal",
    "Name": "Open BMC Journal Log Service",
    "OverWritePolicy": "WrapsWhenFull"
}
```

2.18 LogEntryCollection

2.18.1 Description

A Collection of LogEntry resource instances.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/LogServices/<LogTYPE>/Entries

URI: https://{ip}/redfish/v1/Systems/<SystemID>/LogServices/<LogTYPE>/Entries

- Journal: /redfish/v1/Managers/bmc/LogServices/Journal/Entries
- Crashdump: /redfish/v1/Systems/system/LogService/Crashdump/Entries
- acpi: /redfish/v1/Systems/system/LogServices/acpi/Entries

Refer to Supervyse OPF Redfish API User Guide.docx

2.18.2 Support Method and Privilege

Table 40: Support Method and Privilege of LogEntryCollection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.18.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

2.18.3.1 Example

These examples are the result of LogEntryCollection schema's GET response.


```
{
    "@odata.id": "/redfish/v1/Managers/bmc/LogServices/Journal/Entries",
    "@odata.type": "#LogEntryCollection.LogEntryCollection",
    "Description": "Collection of BMC Journal Entries",
    "Members": [
        {
            "@odata.id": "/redfish/v1/Managers/bmc/LogServices/Journal/Entries/1724048543225997",
            "@odata.type": "#LogEntry.v1_12_0.LogEntry",
            "Created": "2024-08-19T06:22:23+00:00",
            "EntryType": "Oem",
            "Id": "1724048543225997",
            "Message": "power-control: POH timer started",
            "Name": "BMC Journal Entry",
            "OemRecordFormat": "BMC Journal Entry",
            "Severity": "OK"
        },
        {
            "@odata.id": "/redfish/v1/Managers/bmc/LogServices/Journal/Entries/1724048543356548",
            "@odata.type": "#LogEntry.v1_12_0.LogEntry",
            "Created": "2024-08-19T06:22:23+00:00",
            "EntryType": "Oem",
            "Id": "1724048543356548",
```

```
            "Message": "ipmid: No sensor name found in entity manager",
            "Name": "BMC Journal Entry",
            "OemRecordFormat": "BMC Journal Entry",
            "Severity": "OK"
        }
    ],
    "Members@odata.count": 2,
    "Name": "Open BMC Journal Entries"
}
```


2.19 LogEntry

2.19.1 Description

This resource defines the record format for a log.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/LogServices/<LogTYPE>/Entries/<EntryId>

URI: https://{ip}/redfish/v1/Systems/<SystemID>/LogServices/<LogTYPE>/Entries/<EntryId>

- Journal: /redfish/v1/Managers/bmc/LogServices/Journal/Entries/<EntryId>
- Crashdump: /redfish/v1/Systems/system/LogService/Crashdump/Entries/<EntryId>
- acpi: /redfish/v1/Systems/system/LogServices/acpi/Entries/<EntryId>

Refer to Supervyse OPF Redfish API User Guide.docx

2.19.2 Support Method and Privilege

Table 41: Support Method and Privilege of LogEntryCollection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.19.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

Table 42: Properties of LogEntry for BMC Journal

Property	Description
Created	The time the log entry was created.
EntryType	This is the type of log entry.
MessageId	The MessageId of the log entry.
Message	The message of the log entry.
MessageArgs	The arguments for the message of the log entry.

OemRecordFormat	The OEM-specific format of the entry. If the entry type is Oem , this property contains more information about the record format from the OEM.
Severity	This is the severity of the log entry.

Table 43: Properties of LogEntryCollection for Others log

Property	Description
AdditionalDataSizeBytes	The size of the additional data for the log entry.
AdditionalDataURI	The URI at which to access the additional data for the log entry.
Created	The time the log entry was created.
DiagnosticDataType	The type of diagnostic data.
EntryType	This is the type of log entry.
Message	The message of the log entry.
MessageArgs	The arguments for the message of the log entry.
MessageId	The MessageId of the log entry.
OEMDiagnosticDataType	The OEM-defined type of diagnostic data.
Resolution	Used to provide suggestions on how to resolve the situation that caused the log entry.

2.19.3.1 Example

These examples are the result of LogEntry schema's GET response.

This is "/redfish/v1/Managers/bmc/LogServices/Journal/Entries/1724048543225997" example:

```
{
    "@odata.id": "/redfish/v1/Managers/bmc/LogServices/Journal/Entries/1724048543225997",
    "@odata.type": "#LogEntry.v1_12_0.LogEntry",
    "Created": "2024-08-19T06:22:23+00:00",
    "EntryType": "Oem",
    "Id": "1724048543225997",
    "Message": "power-control: POH timer started",
    "Name": "BMC Journal Entry",
    "OemRecordFormat": "BMC Journal Entry",
    "Severity": "OK"
}
```

2.20 HostInterface

2.20.1 Description

The properties associated with a single, Host Interface.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/HostInterfaces/<HostInterfaceId>

2.20.2 Support Method and Privilege

Table 44: Support Method and Privilege of HostInterface

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
PATCH			V			

2.20.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

Table 45: Properties of HostInterface

Property	Description
FirmwareAuthEnabled	An indication of whether this firmware authentication is enabled for this interface.
FirmwareAuthRoleId	The Role used for firmware authentication on this interface.
KernelAuthEnabled	An indication of whether this kernel authentication is enabled for this interface.
KernelAuthRoleId	The Role used for kernel authentication on this interface.
Links	The links to other resources that are related to this resource.
→ FirmwareAuthRole	The link to the Redfish role that has firmware authentication privileges on this host interface.
→ KernelAuthRole	The link to the Redfish role defining privileges for this host interface when using kernel authentication.

2.20.3.1 Example

This examples is the result of HostInterfaces schema's GET response.


```
{
    "@odata.context": "/redfish/v1/$metadata#HostInterface.HostInterface",
    "@odata.id": "/redfish/v1/Managers/bmc/HostInterfaces/1",
    "@odata.type": "#HostInterface.v1_3_0.HostInterface",
    "Id": "1",
    "Description": "The properties associated with a Host Interface.",
    "Name": "Host Interface",
    "InterfaceEnabled": false,
    "AuthenticationModes": [
        "AuthNone",
        "BasicAuth",
        "RedfishSessionAuth"
    ],
    "ExternallyAccessible": false,
    "HostInterfaceType": "NetworkHostInterface",
    "KernelAuthRoleId": "NoAccess",
    "KernelAuthEnabled": false,
    "FirmwareAuthRoleId": "NoAccess",
    "FirmwareAuthEnabled": false,
    "HostEthernetInterfaces": {
```

```
        "@odata.id": "/redfish/v1/Systems/system/EthernetInterfaces"
    },
    "Links": {
        "ComputerSystems@odata.count": 1,
        "ComputerSystems": [
            {
                "@odata.id": "/redfish/v1/Systems/system"
            }
        ],
        "KernelAuthRole": {
            "@odata.id": "/redfish/v1/AccountService/Roles/NoAccess"
        },
        "FirmwareAuthRole": {
            "@odata.id": "/redfish/v1/AccountService/Roles/NoAccess"
        }
    },
    "Oem": {
        "InsydeUpdateTag": {
            "BIOSFEATUREVER": "",
            "BMCFEATUREVER": "2.0",
            "BIOSSetup": "empty",
            "SMBIOS": "empty",
            "PCIE": "empty",
            "SATA": "empty",
            "PCIECRC": "",
            "SATACRC": "",
            "AEP": "",
            "SecureBootEnable": "",
            "SecureBootAction": "",
            "SecureBootDatabasePKAction": "",
            "SecureBootDatabaseKEKAction": "",
            "SecureBootDatabaseDBAction": "",
            "SecureBootDatabaseDBXAction": "",
            "SecureBootFileExist": "NonExist",
            "HttpsCertificateTag": "",
            "ResetBiosToDefaultsPending": "",
            "BIOSRegistries": "empty",
            "BOOTOption": "empty",
            "BOOTOrder": "empty",
            "NetworkAdapter": "empty",
            "OSDeployment": "empty",
            "@odata.type": "#InsydeOEMExtensions.UpdateTag"
        },
        "PendingAction": {
            "@odata.type": "#InsydeOEMExtensions.PendingAction",
            "ActionID_16": {
                "ActionID": 16,
                "ActionName": "AddHttpsBootCertificate",
                "Description": "The Parameter index property is 1 base.",
                "Done": false,
                "Parameter": []
            },
            "ActionID_17": {
                "ActionID": 17,
                "ActionName": "ReplaceHttpsBootCertificate",
                "Description": "The Parameter index property is 1 base.",
                "Done": false,
```

```
                "Parameter": []
            },
            "ActionID_18": {
                "ActionID": 18,
                "ActionName": "DeleteHttpsBootCertificate",
                "Description": "The Parameter index property is 1 base.",
                "Done": false,
                "Parameter": []
            }
        }
    },
    "@odata.etag": "b5214ac8cd57dad26209ee28fa582609"
}
```


2.20.4 Updatable Properties

Table 46: Updatable Properties of HostInterface

Property	Allowed value
FirmwareAuthEnabled	BOOLEAN
FirmwareAuthRoleId	"Administrator", "Operator", "ReadOnly", "Callback", "NoAccess"
KernelAuthEnabled	BOOLEAN
KernelAuthRoleId	"Administrator", "Operator", "ReadOnly", "Callback", "NoAccess"

2.20.4.1 Example Payload


```
{
    "KernelAuthRoleId": "Administrator",
    "KernelAuthEnabled": true,
    "FirmwareAuthRoleId": "Administrator",
    "FirmwareAuthEnabled": true
}
```


2.21 ComputerSystem

2.21.1 Description

This object represents the root Redfish service.
URI: https://{ip}/redfish/v1/Systems/<SystemID>

Default SystemID is “system”.

2.21.2 Support Method and Privilege

Table 47: Support Method and Privilege of ComputerSystem

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

POST				V		
PATCH				V		

2.21.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

Table 48: Properties of ComputerSystem

Property	**Description**
Boot	Information about the boot settings for this system.
→ AutomaticRetryConfig	The configuration of how the system retries booting automatically. (Only for G4 platforms)
→ AutomaticRetryConfig@Redfish.AllowableValues	The allowable values of BootSourceOverrideMode. It contains "Disabled" and "RetryAttempts". (Only for G4 platforms)
BootProgress	This object describes the last boot progress state.
→ LastStateTime	The date and time when the last boot state was updated. (Only for G4 platforms)
EthernetInterfaces	The link to the collection of Ethernet interfaces associated with this system.
FabricAdapters	The link to the collection of fabric adapters associated with this system. (Only for G4 platforms)
ManufacturingMode	An indication of whether the system is in manufacturing mode. Manufacturing mode is a special boot mode, not normally available to end users, that modifies features and settings for use while the system is being manufactured and tested. (Only for G4 platforms)
Oem	Oem extension object.
→ InsydeACDLog	Oem extension object for ACDLog.
→→ ACDLog	This is a reference to a ACDLog.
PowerMode	The power mode setting of the computer system.
UUID	The UUID for this system. (Only for G4 platforms)

2.22 Memory

2.22.1 Description

This is the schema definition of the Memory and its configuration.
URI: https://{ip}/redfish/v1/Systems/<SystemID>/Memory/<MemoryID>

2.22.2 Support Method and Privilege

Table 49: Support Method and Privilege of Memory

	NoAuth	Login	ConfigureManager	ConfigureComponents	ConfigureUsers	ConfigureSelf
GET		V				

2.22.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

Table 50: Properties of Memory

Property	Description
CacheSizeMiB	Total size of the cache portion memory in MiB. (Only for G4 platforms) (Only for Cache Memory)
ErrorCorrection	Error correction scheme supported for this memory device. (Only for G4 platforms) (Only for Cache Memory)

2.23 Processor

2.23.1 Description

This is the schema definition for the Processor resource. It represents the properties of a processor attached to a System
URI: https://{ip}/redfish/v1/Systems/<SystemID>/Processors/<ProcessorId>

URI: https://{ip}/redfish/v1/Systems/<SystemID>/Processors/<ProcessorId>/SubProcessors/<CoreID>

URI:
https://{ip}/redfish/v1/Systems/<SystemID>/Processors/<ProcessorId>/SubProcessors/<CoreID>/SubProcessors/<ThreadID>

Notice that Core and Threads will have limited properties as all the Main processors properties(like TotalCores, TotalThreads, and TotalEnabledCores) are not applicable for Cores & Threads.

2.23.2 Support Method and Privilege

Table 51: Support Method and Privilege of Processor

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.23.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

Table 52: Properties of Processor

Property	Description
AppliedOperatingConfig	The link to the operating configuration that is applied to this processor. (Only for G4 platforms)
BaseSpeedPriorityState	The state of the base frequency settings of the operation configuration applied to this processor. (Only for G4 platforms)
HighSpeedCoreIDs	The list of core identifiers corresponding to the cores that have been configured with the higher clock speed from the operating configuration applied to this processor. (Only for G4 platforms)
OperatingConfigs	The link to the collection of operating configurations that can be applied to this processor. (Only for G4 platforms)

2.24 TelemetryService

2.24.1 Description

The TelemetryService schema describes a Telemetry Service. The Telemetry Service is used to for collecting and reporting metric data within the Redfish Service.
URI: https://{ip}/redfish/v1/TelemetryService

2.24.2 Support Method and Privilege

Table 53: Support Method and Privilege of TelemetryService

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
POST			V			

2.24.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

Table 54: Properties of TelemetryService

Property	Description
MetricDefinitions	The link to the collection of metric definitions.
SupportedCollectionFunctions	An operation to perform over the sample. (Only for G4 platforms)

2.24.3.1 Example

This example is the result of TelemetryService schema's GET response.

```
{
    "@odata.id": "/redfish/v1/TelemetryService",
    "@odata.type": "#TelemetryService.v1_3_1.TelemetryService",
```

```
    "Actions": {
        "#TelemetryService.SubmitTestMetricReport": {
            "target":
"/redfish/v1/TelemetryService/Actions/TelemetryService.SubmitTestMetricReport"
        }
    },
    "Id": "TelemetryService",
    "MaxReports": 10,
    "MetricDefinitions": {
        "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions"
    },
    "MetricReportDefinitions": {
        "@odata.id": "/redfish/v1/TelemetryService/MetricReportDefinitions"
    },
    "MetricReports": {
        "@odata.id": "/redfish/v1/TelemetryService/MetricReports"
    },
    "MinCollectionInterval": "PT1.000S",
    "Name": "Telemetry Service",
    "Status": {
        "State": "Enabled"
    },
    "Triggers": {
        "@odata.id": "/redfish/v1/TelemetryService/Triggers"
    }
}
```


2.24.4 Supported Actions

Refer to Supervyse OPF Redfish API User Guide.docx

2.25 MetricReportCollection

2.25.1 Description

A Collection of MetricReport resource instances.
URI: https://{ip}/redfish/v1/TelemetryService/MetricReports

2.25.2 Support Method and Privilege

Table 55: Support Method and Privilege of MetricReportCollection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
POST			V			

2.25.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx

2.25.3.1 Example

This example is the result of MetricReportCollection schema's GET response.

```
{
    "@odata.id": "/redfish/v1/TelemetryService/MetricReports",
    "@odata.type": "#MetricReportCollection.MetricReportCollection",
    "Actions": {
        "Oem": {
            "InsydeOEMExtensions.ClearTestMetricReport": {
                "target":
"/redfish/v1/TelemetryService/MetricReports/Actions/Oem/InsydeOEMExtensions.ClearTestMetricReport"
            }
        }
    },
    "Members": [],
    "Members@odata.count": 0,
    "Name": "Metric Report Collection"
}
```

2.25.4 Supported Actions

2.25.4.1 ClearTestMetricReport

Description: This action is used to clear all TestMetricReport.
Example URI to clear all TestMetricReport:

https://{ip}/redfish/v1/TelemetryService/MetricReports/Actions/Oem/InsydeOEMExtensions.ClearTestMetricReport

Table 56: Payload Properties of ClearTestMetricReport

Property	Description
N/A	N/A

2.26 MetricDefinitionsCollection

2.26.1 Description

The collection of MetricDefinitions resource instances.
URI: https://{ip}/redfish/v1/TelemetryService/MetricDefinitions

2.26.2 Support Method and Privilege

Table 57: Support Method and Privilege of MetricDefinitionsCollection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.26.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx #Resource Collection Section.

2.26.3.1 Example

This example is the result of MetricDefinitions schema's GET response.

```
{
    "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions",
    "@odata.type": "#MetricDefinitionCollection.MetricDefinitionCollection",
    "Members": [
        {
            "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions/A_P12V_PSU_SCALED"
        }
    ],
    "Members@odata.count": 1,
    "Name": "Metric Definition Collection"
}
```

2.27 MetricDefinition

2.27.1 Description

The MetricDefinition schema describes the metadata information for a metric.
/redfish/v1/TelemetryService/MetricDefinitions/

2.27.2 Support Method and Privilege

Table 58: Support Method and Privilege of MetricDefinition

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.27.3 Properties

Table 59: Properties of MetricDefinition

Property	Description
IsLinear	An indication of whether the metric values are linear versus nonlinear.
MaxReadingRange	The value shall indicate the highest possible value for a related MetricValue.
MetricDataType	This property shall specify the data-type of the metric.
MetricProperties	The list of URIs with wildcards and property identifiers that this metric definition defines.
MetricType	This property shall specify the type of metric.
MinReadingRange	This property shall contain the lowest possible value for the metric reading.
Units	This property shall specify the units of the metric.

2.27.4 Example

```
{
```

```
    "@odata.id": "/redfish/v1/TelemetryService/MetricDefinitions/A_P12V_PSU_SCALED",
    "@odata.type": "#MetricDefinition.v1_3_0.MetricDefinition",
    "Id": "A_P12V_PSU_SCALED",
    "IsLinear": true,
    "MaxReadingRange": 15.903308522393404,
    "MetricDataType": "Decimal",
    "MetricProperties": [
        "/redfish/v1/Chassis/AC_Baseboard/Sensors/A_P12V_PSU_SCALED/Reading"
    ],
    "MetricType": "Gauge",
    "MinReadingRange": 0.0,
    "Name": "A_P12V_PSU_SCALED",
    "Units": "V"
}
```


2.28 UpdateService

2.28.1 Description

This is the schema definition for the Update Service. It represents the properties for the service itself and has links to collections of firmware and software inventory.
URI: https://{ip}/redfish/v1/UpdateService

2.28.2 Support Method and Privilege

Table 60: Support Method and Privilege of UpdateService

	NoAuth	Login	ConfigureManager	ConfigureComponents	ConfigureUsers	ConfigureSelf
GET		V				
PATCH				V		
POST				V		

2.28.3 Properties

Table 61: Properties of UpdateService

Property	Description
MultipartHttpPushUri	The URI used to perform a Redfish Specification-defined multipart HTTP or HTTPS push update to the update service. (Only for G4 platforms)
Oem	Oem Extension Object.
→ ApplyOptions	An indication by boolean value whether to update firmware configuration along with firmware image update.
→→ ClearConfig	This indicates whether to update firmware configuration or not.

→ OpenBmc	(Only for G4 platforms)
→→ PFRInformation	(Only for G4 platforms)
→→→ ACMCheckpoint	(Only for G4 platforms)
→→→ BIOSActiveVersion	(Only for G4 platforms)
→→→ BIOSCheckpoint	(Only for G4 platforms)
→→→ BIOSRecoveryVersion	(Only for G4 platforms)
→→→ BIOSUpdateIntent	(Only for G4 platforms)
→→→ BMCActiveVersion	(Only for G4 platforms)
→→→ BMCCheckpoint	(Only for G4 platforms)
→→→ BMCRecoveryVersion	(Only for G4 platforms)
→→→ BMCUpdateIntent	(Only for G4 platforms)
→→→ CPLDRoTReleaseVersion	(Only for G4 platforms)
→→→ CPLDRoTSVN	(Only for G4 platforms)
→→→ CPLDRoTStaticIdentifier	(Only for G4 platforms)
→→→ LastPanicReason	(Only for G4 platforms)
→→→ LastRecoveryReason	(Only for G4 platforms)
→→→ MajorErrorCode	(Only for G4 platforms)
→→→ MinorErrorCode	(Only for G4 platforms)
→→→ PanicEventCount	(Only for G4 platforms)
→→→ PlatformState	(Only for G4 platforms)
→→→ RecoveryCount	(Only for G4 platforms)
→→→ UFMCommandTrigger	(Only for G4 platforms)
→→→ UFMCommandTrigger	(Only for G4 platforms)
→→→ UFMProvisioningCommand	(Only for G4 platforms)
→→→ UFMProvisioningStatus	(Only for G4 platforms)
→→→ UFMReadFIFO	(Only for G4 platforms)
→→→ UFMWriteFIFO	(Only for G4 platforms)

2.28.3.1 Update Service Example

This example is the result of UpdateService schema's GET response.

```
{
    "@odata.id": "/redfish/v1/UpdateService",
    "@odata.type": "#UpdateService.v1_11_0.UpdateService",
    "Actions": {
        "#UpdateService.SimpleUpdate": {
            "TransferProtocol@Redfish.AllowableValues": [
                "TFTP",
                "HTTPS"
            ],
            "target": "/redfish/v1/UpdateService/Actions/UpdateService.SimpleUpdate"
        },
        "Oem": {
            "#InsydeOEMExtensions.v1_0_0.OSdeployment": {
                "@Redfish.ActionInfo":
"/redfish/v1/UpdateService/Oem/Insyde/OSdeploymentActionInfo",
                "target": "/redfish/v1/UpdateService/Actions/Oem/InsydeOEMExtensions.OSdeployment"
            },
            "#InsydeOEMExtensions.v1_0_0.PushUpdate": {
                "target": "/redfish/v1/UpdateService/Actions/Oem/InsydeOEMExtensions.PushUpdate"
            }
        }
    },
    "Description": "Service for Software Update",
    "FirmwareInventory": {
        "@odata.id": "/redfish/v1/UpdateService/FirmwareInventory"
    },
    "HttpPushUri": "/redfish/v1/UpdateService",
    "HttpPushUriOptions": {
        "HttpPushUriApplyTime": {
            "ApplyTime": "Immediate"
        }
    },
    "HttpPushUriTargets": [],
    "HttpPushUriTargetsBusy": false,
    "Id": "UpdateService",
    "MaxImageSizeBytes": 157286400,
    "Name": "Update Service",
    "Oem": {
        "ApplyOptions": {
            "@odata.type": "#OemUpdateService.ApplyOptions",
            "ClearConfig": false
        },
        "InsydeOSDeployment": {
            "@odata.type": "#InsydeOEMExtensions.v1_0_0.OSDeployment",
            "DevPortNum": -1,
            "OSDeployment": false,
            "OSDeploymentID": "00000000-0000-0000-0000-000000000000",
            "VMSlot": ""
        },
        "InsydePushUpdate": {
            "@odata.type": "#InsydeOEMExtensions.v1_0_0.PushUpdate",
            "RestoreDefault": false
        }
    },
    "ServiceEnabled": true
}
```

2.28.4 ActionInfo

Refer to Supervyse OPF Redfish API User Guide.docx

2.28.5 Supported Actions

Refer to Supervyse OPF Redfish API User Guide.docx

2.29 InsydeACDLogCollection

2.29.1 Description

A Collection of Insyde ACD Log resource instances.
URI: https://{ip}/redfish/v1/Systems/<SystemID>/Oem/Insyde/ACDLog

2.29.2 Support Method and Privilege

Table 62: Support Method and Privilege of InsydeACDLogCollection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.29.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx #Resource Collection Section.

2.29.3.1 Example

This example is the result of InsydeACDLogCollection schema's GET response.


```
{
    "@odata.id": "/redfish/v1/Systems/system/Oem/Insyde/ACDLog",
    "@odata.type": "#InsydeACDLogCollection.InsydeACDLogCollection",
    "Name": "InsydeACDLogCollection",
    "Description": "A Collection of InsydeACDLog resource instances.",
    "Members@odata.count": 2,
    "Members": [
        {
            "@odata.id": "/redfish/v1/Systems/system/Oem/Insyde/ACDLog/ondemand_20221028_143040"
        },
        {
            "@odata.id": "/redfish/v1/Systems/system/Oem/Insyde/ACDLog/ondemand_20210108_033636"
        }
    ]
}
```

2.30 InsydeACDLog

2.30.1 Description

This schema contains crash dump messages.
URI: https://{ip}/redfishv1/Systems/<SystemID>/Oem/Insyde/ACDLog/<AcdLogId>

2.30.2 Support Method and Privilege

Table 63: Support Method and Privilege of InsydeACDLog

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.30.3 Properties

Table 64: Properties of InsydeACDLog

Property	Description
ACDAnalyzedLog	The ACD analyzed log content.
ACDRawLog	The ACD Raw Log content.

2.30.3.1 Example

This example is the result of InsydeACDLog schema's GET response.


```
{
    "@odata.context": "/redfish/v1/$metadata#InsydeACDLog.InsydeACDLog",
    "@odata.type": "#InsydeACDLog.v1_0_0.InsydeACDLog",
    "@odata.id": "/redfish/v1/Systems/system/Oem/Insyde/ACDLog/ondemand_20210108_033636",
    "Id": "ondemand_20210108_033636",
    "Name": "ondemand_20210108_033636",
    "Description": "The InsydeACDLog schema contains properties related to ACD log.",
    "ACDAnalyzedLog": {
        "MCA": {
            "socket0": [],
            "socket1": []
        },
        "TOR": {
            "socket0": [],
            "socket1": []
        },
        "_total_time": "0.983s",
        "summary": {
            "socket0": [
                {
                    "Errors_Per_Socket": "PCU_CR_MCA_ERR_SRC_LOG = N/A, FirstIERR = 0x0, FirstMCERR
= 0x0"
                }
            ],
            "socket1": [
```

```
                {
                    "Errors_Per_Socket": "PCU_CR_MCA_ERR_SRC_LOG = N/A, FirstIERR = 0x0, FirstMCERR
= 0x0"
                }
            ]
        }
    },
    "ACDRawLog": {
        "crash_data": {
            "METADATA": {
                "cpu0": {
                    "peci_id": "0x30",
                .
                .
                .
                },
                "me_fw_ver": "04.04.03.192",
            .
            .
            .
            },
            "PROCESSORS": {
                "_version": "0x2301a001",
                "cpu0": {
                    "uncore": {
                        "_version": "0x801a026",
                        "B00_D00_F0_0x0": "0x8086",
                  .
                  .
                  .
                  "_time": "25.12s"
                    },
                    "TOR": {
                        "status": "N/A",
                        "_version": "0x901a001",
                        "_time": "0.00s"
                    }
                .
                .
                .
                }
            }
        }
    },
    "@odata.etag": "d8168fe958b2f3212eecd154aa7f31a8"
}
```


2.31 Node Manager related schema

2.31.1 Description

This section can be seen if the SPS offload feature is supported.

2.31.2 Node Manager

The Node Manager schema describes metrics and control properties for Node Manager application.
URI: https://{ip}/redfish/v1/Managers/<ManagerId>/NodeManager
URI: https://{ip}/redfish/v1/Managers/<ManagerId>/Oem/Intel/NodeManager (Only for G4 platforms)

2.31.2.1 Support Method and Privilege

Table 65: Support Method and Privilege of Node Manager

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
POST			V			

2.31.2.2 Properties

Table 66: Properties of Node Manager

Property	Description
Actions	The available actions for this Resource.
Domains	The Domain schema contains properties related to monitoring and control of the given power capping domain.
Policies	Policies created for this domain.
ThrottlingStatus	The link to the throttling status reported by this manager. (Only for G4 platforms)
Triggers	Policies created for this domain.
NmVersion	Application version running on this manager.
MaxNumberOfPolicies	Maximal number of policies supported by this manager.
Status	*Refer to Supervyse OPF Redfish API User Guide.docx#Status Object*

2.31.2.2.1 Example

```
{
    "@odata.id": "/redfish/v1/Managers/bmc/NodeManager",
    "@odata.type": "#NodeManager.v1_0_0.NodeManager",
    "Id": "NodeManager",
    "Name": "Node Manager",
    "Domains": {
        "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Domains"
    },
    "Policies": {
        "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Policies"
    },
    "Triggers": {
        "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers"
    },
    "Status": {
```

```
        "State": "Enabled",
        "Health": "Warning"
    },
    "NmVersion": "1.0",
    "MaxNumberOfPolicies": 64,
    "Actions": {
        "#NodeManager.ChangeState": {
            "target": "/redfish/v1/Managers/bmc/NodeManager/Actions/NodeManager.ChangeState",
            "State@Redfish.AllowableValues": [
                "Enabled",
                "Disabled"
            ]
        }
    },
    "@odata.etag": "5f24561684deda65410d0cc4951528f3"
}
```


2.31.2.3 Supported Action

2.31.2.3.1 ChangeState

URI: https://redfish/v1/Managers/<ManagerID>/NodeManager/Actions/NodeManager.ChangeState
URI: https://redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/ Actions/NodeManager.ChangeState (Only for G4 platforms)

Table 67: Payload Properties of ChangeState

Property	Allowed Value	Description
State	Enabled	Enable the domain.
	Disabled	Disable the domain.

Example payload


```
{
    "State": "Enabled"
}
```


2.31.2.3.2 GetDiagnosticInfo

URI: https://redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Actions/NodeManager.GetDiagnosticInfo (Only for G4 platforms)

Table 68: Payload Properties of GetDiagnosticInfo

Property	Allowed Value
N/A	N/A

2.31.3 NmDomain Collection

2.31.3.1 Description

The NM Domain collection schema contains a collection of node manager domain

URI: https://{ip}/redfish/v1/Managers/<ManagerID>/NodeManager/Domains
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Domains (Only for G4 platforms)

2.31.3.2 Support Method and Privilege

Table 69: Support Method and Privilege of NmDomain Collection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.31.3.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx #Resource Collection Section.

2.31.3.3.1 Example

```
{
    "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Domains",
    "@odata.type": "#NmDomainCollection.DomainCollection",
    "Name": "NM Domains Collection",
    "Members@odata.count": 5,
    "Members": [
        {
            "@odata.id": "/redfish/v1/Managers/BMC/NodeManager/Domains/DCTotalPlatformPower"
        },
        {
            "@odata.id": "/redfish/v1/Managers/BMC/NodeManager/Domains/MemorySubsystem"
        },
        {
            "@odata.id": "/redfish/v1/Managers/BMC/NodeManager/Domains/ACTotalPlatformPower"
        },
        {
            "@odata.id": "/redfish/v1/Managers/BMC/NodeManager/Domains/CPUSubsystem"
        },
        {
            "@odata.id": "/redfish/v1/Managers/BMC/NodeManager/Domains/PCIe"
        }
    ],
    "@odata.etag": "fc1764f75ccbf39a7f433924a93cc60e"
}
```

2.31.4 NmDomain

The NmDomain schema contains properties related to monitoring and control of the given domain.
URI : https://redfish/v1/Managers/<ManagerID>/NodeManager/Domains/<DomainID>
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Domains/<DomainID> (Only for G4 platforms)

2.31.4.1 Support Method and Privilege

Table 70: Support Method and Privilege of NmDomain

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf

GET		V				
POST			V			
PATCH			V			

2.31.4.2 Properties

Table 71: Properties of NmDomain

Property	**Description**
Capabilities	The capabilities data information for this domain.
->Max	Maximal value of the controlled parameter for this domain. Value 0 means that either there are no constraints on the maximal value, or such constraints are unknown.
->MaxCorrectionTimeInMs	Maximal correction time of policies in this domain.
->MaxStatisticsReportingPeriod	Maximal statistic reporting period for calculating the average for policies in this domain. The value shall conform to the Duration format.
->Min	Minimal value of the controlled parameter for this domain. Value 0 means that either there are no constraints on the minimal value, or such constraints are unknown.
->MinCorrectionTimeInMs	Minimal correction time of policies in this domain.
->MinStatisticsReportingPeriod	Minimal statistic reporting period for calculating the average for policies in this domain. The value shall conform to the Duration format.
LimitBias	Limit Bias settings to apply to policies in a domain.
->AbsoluteLimitBias	Absolute Limit Bias value.
->RelativeLimitBias	Relative Limit Bias value.
ComponentCapabilities	The capabilities data information for components in this domain.
->Max	Maximal value of the controlled parameter for this domain.
->Min	Minimal value of the controlled parameter for this domain.
->Name	Name of component for which capabilites are presented.
Links	The links to other Resources that are related to this Resource.
->Policies	An array of links to policies created in this domain.
Statistics	Statistics collected for the domain.
->Average	Average value of collected statistics.
->AveragingInterval	Interval over which average value was calculated.
->Current	Current value of collected statistics.

->Max	Maximal value of collected statistics.
->MeasurementState	Flag stating if the measuremt is in progress.
->Min	Minimal value of collected statistics.
->Name	Statistic name.
Status	*Refer to Supervyse OPF Redfish API User Guide.docx#StatusObject*
SupportedTriggers	An array of links to triggers supported by this domain.

2.31.4.2.1 Example


```
{
    "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Domains/DCTotalPlatformPower",
    "@odata.type": "#NmDomain.v1_4_0.Domain",
    "Actions": {
        "#NmDomain.ChangeState": {
            "State@Redfish.AllowableValues": [
                "Enabled",
                "Disabled"
            ],
            "target":
"/redfish/v1/Managers/bmc/NodeManager/Domains/DCTotalPlatformPower/Actions/Domain.ChangeState"
        },
        "#NmDomain.ResetStatistics": {
            "target":
"/redfish/v1/Managers/bmc/NodeManager/Domains/DCTotalPlatformPower/Actions/Domain.ResetStatistics"
        }
    },
    "Capabilities": {
        "Max": 90000.0,
        "MaxCorrectionTimeInMs": 60000,
        "MaxStatisticsReportingPeriod": "PT1H",
        "Min": 0.0,
        "MinCorrectionTimeInMs": 1000,
        "MinStatisticsReportingPeriod": "PT1.000S"
    },
    "ComponentCapabilities": [
        {
            "Max": 90000.0,
            "Min": 0.0,
            "Name": "Domain"
        }
    ],
    "Id": "DCTotalPlatformPower",
    "LimitBias": {
        "AbsoluteLimitBias": 2.0,
        "RelativeLimitBias": 1.0
    },
    "Links": {
        "Policies": [
            {
                "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Policies/1"
            }
```

```
        ],
        "Policies@odata.count": 1
    },
    "Name": "DCTotalPlatformPower",
    "Statistics": [
        {
            "AveragingInterval": "PT53M14.000S",
            "Current": 0,
            "MeasurementState": false,
            "Name": "Energy accumulator"
        },
        {
            "Average": 0.0,
            "AveragingInterval": "PT52M48.000S",
            "Current": 0.0,
            "Max": 0.0,
            "MeasurementState": true,
            "Min": 0.0,
            "Name": "Power"
        },
        {
            "Average": null,
            "AveragingInterval": "PT",
            "Current": null,
            "Max": null,
            "MeasurementState": false,
            "Min": null,
            "Name": "Throttling"
        }
    ],
    "Status": {
        "State": "Disabled"
    },
    "SupportedTriggers": [
        {
            "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers/AlwaysOn"
        },
        {
            "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers/InletTemperature"
        },
        {
            "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers/CPUUtilization"
        },
        {
            "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers/HostReset"
        }
    ],
    "SupportedTriggers@odata.count": 4
}
```


2.31.4.3 Updatable Properties

Table 72: Updatable Properties of NmDomain

Property	Allowed Value	Description

Capabilities.Max	0-60000	Maximal value of the controlled parameter for this domain.
Capabilities.Min	0-60000	Minimal value of the controlled parameter for this domain.
LimitBias.AbsoluteLimitBias	0-60000	Absolute Limit Bias value.
LimitBias.RelativeLimitBias	0-60000	Relative Limit Bias value.

2.31.4.3.1 Example Payload

```
{
    "LimitBias": {
        "AbsoluteLimitBias": 1000,
        "RelativeLimitBias": 1000
    },
    "Capabilities": {
        "Max": 5000,
        "Min": 500
    }
}
```

2.31.4.4 Supported Action

2.31.4.4.1 ChangeState

URI: https://redfish/v1/Managers/<ManagerID>/NodeManager/Domains/<DomainID>/Actions/Domain.ChangeState
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Domains/<DomainID>/Actions/Domain.ChangeState (Only for G4 platforms)

Table 73: Payload Properties of ChangeState

Property	Allowed Value	Description
State	Enabled	Enable the domain.
	Disabled	Disable the domain.

Example Payload

```
{
    "State": "Enabled"
}
```

2.31.4.4.2 ResetStatistics

URI: https://redfish/v1/Managers/<ManagerID>/NodeManager/Domains/<DomainID>/Actions/Domain.ResetStatistics
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Domains/<DomainID>/Actions/Domain.ResetStatistics (Only for G4 platforms)

Table 74: Payload Properties of ResetStatistics

Property	Allowed Value	Description

N/A	N/A	N/A

2.31.5 NmPolicy Collection

2.31.5.1 Description

The NmPolicy Collection schema contains a collection of node manager policy.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/NodeManager/Policies
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Policies (Only for G4 platforms)

2.31.5.2 Support Method and Privilege

Table 75: Support Method and Privilege of NmPolicy Collection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
POST			V			

2.31.5.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx #Resource Collection Section.

2.31.5.3.1 Example

```
{
    "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Policies",
    "@odata.type": "#NmPolicyCollection.PolicyCollection",
    "Name": "NM Policies Collection",
    "Members@odata.count": 1,
    "Members": [
        {
            "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Policies/1"
        }
    ],
    "@odata.etag": "a22586a139a948ddc102fa03eee33fa1"
}
```

2.31.5.4 Create a new policy by POST

Table 76: Properties of Create a new policy by POST

Property	Allowed Value	Description
Id	0-300	
Domain	VALID DOMAIN	
CorrectionInMs	1000-60000	
Limit	0-32767	

StatisticsReportingPeriod	STRING	STRING which follow pattern "-?P(\\d+D)?(T(\\d+H)?(\\d+M)?(\\d+(.\\d+)?S)?)?". Notice that add 3 digit limit for each unit to prevent overflow calculation.
PolicyStorage	Persistent	Policy is stored in non-volatile memory.
	Volatile	Policy is only stored in volatile memory
PowerCorrectionType	Auto	Node Manager will automatically decide what power correction time will be used.
	NonAggressive	Use only efficient control knobs (without severely impacting performance).
	Aggressive	Use all available control knobs to meet policy limit.
LimitException	NoAction	Take no action when the limit is exceeded.
	HardPowerOff	Turn the power off immediately when the limit is exceeded.
	LogEventOnly	Log an event when the limit is exceeded, but take no further action.
	Oem	Take an OEM-defined action.
ComponentId	0-255	
Trigger.TriggerLimit	0-100	
Trigger.TriggerType	VALID TRIGGER	
Status.State	Enabled	
	Disabled	

2.31.5.4.1 Example payload

```
{
    "Id": "5",
    "Domain": "DCTotalPlatformPower",
    "CorrectionInMs": 6000,
    "Limit": 0,
    "PolicyStorage": "Volatile",
    "PowerCorrectionType": "Auto",
    "StatisticsReportingPeriod": "PT1S",
    "LimitException": "NoAction",
    "ComponentId": 5,
    "Trigger": {
        "TriggerLimit": 0,
        "TriggerType": "AlwaysOn"
    },
    "Status": {
        "State": "Enabled"
    }
}
```

2.31.6 NmPolicy

The NmPolicy schema contains properties related to monitoring and control of the given policy.
URI: https://{ip}/redfish/v1/Managers/<ManagerId>/NodeManager/Policies/<PolicyId>
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Policies/<PolicyId> (Only for G4 platforms)

2.31.6.1 Support Method and Privilege

Table 77: Support Method and Privilege of NmPolicy

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
POST			V			
PATCH			V			
DELETE			V			

2.31.6.2 Properties

Table 78: Properties of NmPolicy

Property	Description
ComponentId	Identifier of a domain's component this policy limit is to be applied to.
CorrectionInMs	Policy correction time in ms.
CorrectionType	Power correction type, which identifies what control knobs will the policy use to enforce the power capping.
Domain	The domain in which the policy was created.
Limit	Limit to be enforced if the policy is triggered.
LimitException	Exception action to take if the limit is violated.
PolicyStorage	Storage configuration of policy object.
PolicyType	Type of policy object.
Statistics	Statistics collected for the policy.
->Average	Average value of collected statistics.
->AveragingDuration	Duration over which average value was calculated.
->Current	Current value of collected statistics.
->Max	Maximal value of collected statistics.
->MeasurementState	Flag stating if the measuremt is in progress.
->Min	Minimal value of collected statistics.

->Name	Statistic name.
Status	*Refer to Supervyse OPF Redfish API User Guide.docx#Status Object*
StatisticsReportingPeriod	Statistics reporting period for this policy.
Trigger	The trigger for this policy.
TriggerLimit	Trigger limit after violation of which the Policy will become triggered.
TriggerType	Link to the trigger definition that this policy is using.

2.31.6.2.1 Example


```
{
    "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Policies/1",
    "@odata.type": "#NmPolicy.v1_2_0.Policy",
    "Actions": {
        "#NmPolicy.ChangeState": {
            "State@Redfish.AllowableValues": [
                "Enabled",
                "Disabled"
            ],
            "target": "/redfish/v1/Managers/bmc/NodeManager/Policies/1/Actions/Policy.ChangeState"
        },
        "#NmPolicy.ResetStatistics": {
            "target":
"/redfish/v1/Managers/bmc/NodeManager/Policies/1/Actions/Policy.ResetStatistics"
        }
    },
    "ComponentId": 5,
    "CorrectionInMs": 6000,
    "Domain": {
        "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Domains/DCTotalPlatformPower"
    },
    "Id": "1",
    "Limit": 0,
    "LimitException": "NoAction",
    "Name": "Policy1",
    "OemStatus": "Disabled",
    "PolicyStorage": "Volatile",
    "PowerCorrectionType": "Auto",
    "Statistics": [
        {
            "Average": 0.0,
            "AveragingInterval": "PT1.000S",
            "Current": 0.0,
            "Max": 0.0,
            "MeasurementState": true,
            "Min": 0.0,
            "Name": "Power"
        }
    ],
    "StatisticsReportingPeriod": "PT1.000S",
    "Status": {
        "State": "Disabled"
```

```
    },
    "SuspendPeriods": {},
    "Thresholds": {
        "ThresholdValue": []
    },
    "Trigger": {
        "TriggerLimit": 0,
        "TriggerType": {
            "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers/AlwaysOn"
        }
    }
}
```

2.31.6.3 Updateable Properties

Table 79: Updatable Properties of NmPolicy

Property	Allowed Value	Description
CorrectionInMs	1000-60000	
Limit	0-32767	
PolicyStorage	Persistent	Policy is stored in non-volatile memory.
	Volatile	Policy is only stored in volatile memory
PowerCorrectionType	Auto	Node Manager will automatically decide what power correction time will be used.
	NonAggressive	Use only efficient control knobs (without severely impacting performance).
	Aggressive	Use all available control knobs to meet policy limit.
LimitException	NoAction	Take no action when the limit is exceeded.
	HardPowerOff	Turn the power off immediately when the limit is exceeded.
	LogEventOnly	Log an event when the limit is exceeded, but take no further action.
	Oem	Take an OEM-defined action.
ComponentId	0-255	
StatisticsReportingPeriod	STRING	STRING which follow pattern "-?P(\\d+D)?(T(\\d+H)?(\\d+M)?(\\d+(.\\d+)?S)?)?". Notice that add 3 digit limit for each unit to prevent overflow calculation.
Trigger.TriggerLimit	0-100	
Trigger.TriggerType	VALID TRIGGER	

2.31.6.3.1 Example payload

```
{
    "CorrectionInMs": 8000,
```

```
    "PolicyStorage": "Volatile",
    "PowerCorrectionType": "Auto",
    "LimitException": "NoAction",
    "Trigger": {
        "TriggerLimit": 0,
        "TriggerType": "HostReset"
    },
    "StatisticsReportingPeriod": "PT10M",
    "ComponentId": 0
}
```

2.31.6.4 Supported Action

2.31.6.4.1 ChangeState

URI: https://redfish/v1/Managers/<ManagerId>/NodeManager/Policies/<PolicyId>/Actions/Policy.ChangeState
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Policies/<PolicyId>/Policy.ChangeState (Only for G4 platforms)

Table 80: Payload Properties of ChangeState

Property	Allowed Value	Description
State	Enabled	Enable the policy.
	Disabled	Disable the policy.

Example payload

```
{
    "State": "Enabled"
}
```

2.31.6.4.2 ResetStatistics

URI: https://redfish/v1/Managers/<ManagerId>/NodeManager/Policies/<PolicyId>/Actions/Policy.ResetStatistics
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Policies/<PolicyId>/Policy.ResetStatistics (Only for G4 platforms)

Table 81: Payload Properties of ResetStatistics

Property	Allowed Value	Description
N/A	N/A	N/A

2.31.6.5 Remove Policy by DELETE

Description: Polocy can be removed by Deleting the Policy resource.
URI: https://{ip}redfish/v1/Managers/<ManagerID>/NodeManager/Policies/<PolicyId>
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Policies/<PolicyId> (Only for G4 platforms)

2.31.7 NmTrigger Collection

2.31.7.1 Description

The NM triggers collection schema contains a collection of node manager triggers.
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/NodeManager/Triggers
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Triggers (Only for G4 platforms)

2.31.7.2 Support Method and Privilege

Table 82: Support Method and Privilege of NmTrigger Collection

	NoAuth	Login	Configure Manager	Configure Components	Configure Users	ConfigureSelf
GET		V				

2.31.7.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx #Resource Collection Section.

2.31.7.3.1 Example

```
{
    "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers",
    "@odata.type": "#NmTriggerCollection.TriggerCollection",
    "Name": "NM Triggers Collection",
    "Members@odata.count": 3,
    "Members": [
        {
            "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers/CPUUtilization"
        },
        {
            "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers/InletTemperature"
        },
        {
            "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers/HostReset"
        }
    ],
    "@odata.etag": "27c66e8ae4bc7248985f9ae624ddb505"
}
```

2.31.8 NmTrigger

Trigger information for policies in domain.
URI: https://{ip}/redfish/v1/Managers/<ManagerId>/NodeManager/Triggers/<TriggerId>
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/Triggers/<TriggerId> (Only for G4 platforms)

2.31.8.1 Support Method and Privilege

Table 83: Support Method and Privilege of NmTrigger

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf

GET		V				

2.31.8.2 Properties

Table 84: Properties of NmTrigger

Property	Description
Max	Max acceptable trigger limit value for the trigger.
Min	Min acceptable trigger limit value for the trigger.
Unit	Unit for trigger limit of the trigger.

2.31.8.2.1 Example payload

```
{
    "@odata.id": "/redfish/v1/Managers/bmc/NodeManager/Triggers/CPUUtilization",
    "@odata.type": "#NmTrigger.v1_0_0.Trigger",
    "Id": "CPUUtilization",
    "Description": "Trigger information for policies in domain.",
    "Min": 0,
    "Max": 100,
    "Unit": "Percentage",
    "Name": "C0 Residency",
    "@odata.etag": "ef5a73689006485daf58c6695a8a4b07"
}
```

2.31.9 NmThrottlingStatus

(Only for G4 platforms)
URI: https://{ip}/redfish/v1/Managers/<ManagerID>/Oem/Intel/NodeManager/ThrottlingStatus

2.31.10 Support Method and Privilege

Table 85: Support Method and Privilege of NmThrottlingStatus

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.31.11 Properties

Table 86: Properties of NmThrottlingStatus

Property	Description
Events	(Only for G4 platforms)

2.32 Cups Service

2.32.1 Description

The CupsService schema describes the root of the CUPS service.
URI: https://{ip}/redfish/v1/CupsService
URI: https://{ip}/redfish/v1/CupsService/Oem/Intel/CupsService (Only for G4 platforms)

2.32.2 Support Method and Privilege

Table 87: Support Method and Privilege of Cups Service

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				
PATCH				V		

2.32.3 Properties

Table 88: Properties of Cups Service

Property	Description
AveragingPeriod	Determines the averaging period for CUPS compute domains.
Interval	Configures the interval for CUPS monitoring loop.
LoadFactorConfiguration	Determines whether CUPS uses static or dynamic load factors.
Status	*Refer to Supervyse OPF Redfish API User Guide.docx#Status Object*
CupsSensors	This property must contain a link to the collection of CUPS sensors.

Example

```
{
    "@odata.id": "/redfish/v1/CupsService",
    "@odata.type": "#CupsService.v1_0_0.CupsService",
    "AveragingPeriod": "PT3.000S",
    "CupsSensors": {
        "@odata.id": "/redfish/v1/CupsService/Sensors"
    },
    "Id": "CupsService",
    "Interval": "PT1.000S",
    "LoadFactorConfiguration": "Dynamic",
    "Name": "Cups Service",
    "Status": {
        "State": "Enabled"
    }
}
```

2.32.4 Updateable Properties

Table 89: Updateable Properties of Cups Service

Property	Allowed Value
AveragingPeriod	
Interval	
LoadFactorConfiguration	
StaticLoadFactors	
→ CoreLoadFactor	
→ IioLoadFactor	
→ MemoryLoadFactor	

2.33 CupsSensorsCollection

2.33.1 Description

A Collection of CupsService resource instances.
URI: https://{ip}/redfish/v1/CupsService/Sensors
URI: https://{ip}/redfish/v1/CupsService/Oem/Intel/CupsService/Sensors (Only for G4 platforms)

2.33.2 Support Method and Privilege

Table 90: Support Method and Privilege of CupsSensorsCollection

	NoAuth	Login	ConfigureManager	Configure Components	ConfigureUsers	ConfigureSelf
GET		V				

2.33.3 Properties

Refer to Supervyse OPF Redfish API User Guide.docx #Resource Collection Section.

2.33.3.1 Example

```
{
    "@odata.id": "/redfish/v1/CupsService/Sensors",
    "@odata.type": "#CupsSensors.Sensors",
    "Members": [],
    "Members@odata.count": 0,
    "Name": "CupsSensorsCollection"
}
```