PWM TIMER FOR WHITE LED PIN 10 > 861/ timer (UNUSED) N/U MOVE WHITE LES TO PIN 9 PWM CHANNEL (EX RGB DATA) PM 3 1RQ1 CONNECT RADIO INT TO PIN 2 INT & RADIO_ HUT (EX ADDR 0) PIN 4 CONNECT RAB-DATA TO - POWER Switch ZONE O PIN 5 - ZONE JUMPERS OR DIP SWITCH 20NE 1 - BARREL conn for Everying. PIN 6 PIN 17 MOTION A3 Sound PIN 160 A2

[LLUMINUS 1.5 ELEC. Cags









