

1. GPS Status (GPSInfo:fix=6,num_sat=10)

The fix=6 part means the drone has found its location with extreme accuracy. In drone technology, a "6" is the highest score possible for positioning. It means the drone knows exactly where it is down to a few centimeters.

The num_sat=10 part means the drone's GPS tracker is currently locked onto 10 different satellites in the sky. A drone needs to talk to at least 4 satellites just to fly safely, so having 10 means its connection is incredibly strong and stable

2. Battery Status (Battery:voltage=12.6,current=0.0,level=100)

The voltage=12.6 shows how much electrical power is inside the battery. A reading of 12.6 Volts tells us that this is a standard 3-cell drone battery that is completely full.

The current=0.0 measures how much electricity is being used right this second. It says 0.0 because the drone's spinning motors are still turned off (disarmed). Right now, the drone is just sitting still and using almost no power.

The level=100 is simply the battery life percentage. Just like on your smartphone, "100" means the battery is completely charged and ready for takeoff.

3. Last Heartbeat Status (Last Heartbeat: 0.976...)

A Heartbeat is a constant digital "pulse" or signal that the drone sends out every single second. It is the drone's way of saying, "I am turned on, running properly, and listening to your commands."

The number 0.976... tells us how many seconds have passed since your computer script last heard from the drone. Because this number is less than 1 second, it proves that your Python script and the drone simulator are talking to each other instantly without any lag or delays.

