HOME PLOTS APPS

Search (Ctrl+Shift+Space) Hariprasath

New Script | New Live Script | New | Open | Go to File | Find Files — FILE

Import Data | Save Workspace | Clean Data | New Variable | Open Variable | Clear Workspace — VARIABLE

Favorites | Clear Commands — CODE

Simulink — SIMULINK

Layout | Set Path | Add-Ons | Settings | Connections | Parallel — ENVIRONMENT

Help | Request Support | Feedback | Learn MATLAB — RESOURCES

Copilot Chat — COPILOT

/ › MATLAB Drive

Editor

adc exp 2.m × | untitled2.m × | untitled.m × | untitled3.m × | untitled4.m ×

MATLAB Drive\untitled4.m

```
% Calculation and Verification of Frequency Deviation
% and Modulation Index of FM Signal
clc;
clear;
close all;
%% Message Signal Parameters
Am = 2; % Message amplitude (V)
fm = 500; % Message frequency (Hz)
%% Carrier Signal Parameters
Ac = 1; % Carrier amplitude (V)
fc = 10000; % Carrier frequency (Hz)
%% FM Parameters
kf = 250; % Frequency sensitivity (Hz/V)
fs = 100000; % Sampling frequency (Hz)
T = 0.01; % Simulation duration (s)
%% Time Vector
t = 0:1/fs:T;
%% Message Signal
m = Am*cos(2*pi*fm*t);
%% Frequency Deviation

delta_f = kf*Am;
%% Modulation Index
beta = delta_f/fm;
%% FM Signal
fm_signal = Ac*cos(2*pi*fc*t + beta*sin(2*pi*fm*t));
%% Display Parameters
fprintf('Carrier Frequency (fc) = %.0f Hz\n',fc);
fprintf('Message Frequency (fm) = %.0f Hz\n',fm);
fprintf('Message Amplitude (Am) = %.0f V\n',Am);
fprintf('Frequency Sensitivity (kf) = %.0f Hz/V\n',kf);
fprintf('\nFrequency Deviation (Delta f) = %.2f Hz\n',delta_f);
fprintf('Modulation Index (Beta) = %.2f\n',beta);
%% Verification
beta_verify = delta_f/fm;
fprintf('Verified Modulation Index = %.2f\n',beta_verify);
%% Verification Check
tolerance = 1e-6;
if abs(beta - beta_verify) < tolerance
    fprintf('\nVerification Successful\n');
else
```

Apps

Figure 1 ×



