

Programming the Radioddity GS-10B Pro Radio

1. Push the V/M button to change to VFO Mode.
2. Set the Receive Frequency using the number keys.
3. Push the HOME button to enter the Menu System.
4. Using the RIGHT > button move to Menu 14 – R-CTCSS. Press the Home Button to select the menu item. Set the tone frequency, this will be listed with the repeater frequency you are setting.
5. Move to Menu 26 – Offset. Press the Home Button to select the menu item. This is normally 0.6000 this will configure the offset for the transmit frequency.
6. Before setting the memory location, go to Menu 11 – DELCH. Press the Home Button to select the menu item. Delete any preset in the memory you wish to use. I found my radio came with some presets. New memory channels to do over write.
7. Go to Menu 10 – MEMCH. Press the Home Button to select the menu item. Select the number that you wish to save the new repeater.
8. Push the V/M button to change to the memories.
9. With the new frequency selected. Push the Home Button and go to Menu 16 – Push the Home Button to select. Enter the Name using the number keys like we did with the first flip phones.
10. Exit the Menu system buy pushing the button far RIGHT <]. Select the new channel you just created and test your newly programmed repeater.