

MERCURY ALARM BEEP CODES

One-page reference for two specific operator-manual families



Start with the serial number. Mercury alarm patterns vary by model, year, and rigging. Use the table that matches the engine family, then confirm it in that motor's operator manual.

A. CLASSIC OPTIMAX TWO-STROKE

2006 OptiMax operator-manual family

FUNCTION	HORN	MEANING / RESPONSE
Start-up	One beep	Normal system test
Low oil reserve	4 beeps / 2 min	Refill engine reservoir and remote oil tank
Water in fuel	4 beeps / 2 min	Water at full level in filter chamber; follow manual removal procedure
Cooling problem	Continuous	Guardian active. Neutral, check telltale and intakes; stop if flow is absent or intermittent
Oil critically low	Continuous	Guardian limits power. Refill engine reservoir and remote tank
Oil-pump failure	Continuous	No lubricating oil is reaching engine. Stop
Overspeed	Continuous	System limits RPM. Check prop pitch, engine height, and trim
Sensor out of range	Continuous / intermittent	Guardian may limit power. Service required

B. OLDER 40/50/60 EFI FOURSTROKE

2006 EFI FourStroke operator-manual family

HORN	CONDITION	BEHAVIOUR / RESPONSE
One beep	Normal key-up test	No action if it does not recur
Six beeps	MAP, MAT, TPS, or ECM checksum	May continue running; service required
3 beeps / 4 min	Voltage, EST, injector, coolant sensor, or IAC	Hard start, rough run, or stall; service required
Intermittent	Fuel pump, relay, or ECM reference voltage	May not start or may stall under load
Continuous	Overheat	Guardian active. Stop and check intakes / cooling flow
Continuous	Low oil pressure	This family: power may be limited to 10%. Stop and check oil
Continuous	Voltage below 10 V or above 16 V	This family: power may be limited to 75%
Continuous	Coolant-sensor failure	This family: power may be limited to 50%
Continuous	Speed limiter	Cuts cylinders at 6,200 RPM; cuts all at 6,350 RPM

CONTINUOUS ALARM, LOST COOLING FLOW, OR MAJOR POWER REDUCTION

Reduce throttle and stop safely. Do not keep running to test whether the alarm clears.
Send the beep pattern, serial number, and display photo through [hbw.wiki/service](https://www.hbw.wiki/service).

OWNER NOTES FOR THE SERVICE REQUEST

Motor serial number

Exact beep pattern and interval

Display message / fault code