

STANDARD OPERATING PROCEDURE

Title: Rolling Mill Bearing Replacement

Document ID: SOP-RM-001

Purpose

To safely replace worn or damaged bearings in rolling mill equipment and restore equipment reliability.

Required Tools

- Bearing puller
- Torque wrench
- SKF bearing kit
- Dial indicator
- Safety lockout kit

Procedure

1. Stop rolling mill operation.
2. Perform Lockout/Tagout (LOTO).
3. Remove bearing housing cover.
4. Inspect shaft for wear and damage.
5. Remove damaged bearing using approved puller.
6. Clean shaft and housing surfaces.
7. Install replacement bearing.
8. Verify alignment using dial indicator.
9. Apply recommended lubrication.
10. Reassemble housing.
11. Conduct low-speed test run.
12. Verify vibration level below 3 mm/s.

Acceptance Criteria

- Bearing temperature below 80°C
- Vibration below 3 mm/s
- No abnormal noise

Common Failure Indicators

- Increased vibration
- High bearing temperature
- Metal particles in lubricant
- Abnormal operating noise