

Ultrasonic Sensor
(HC-SR04)



ESP32



IR Sensor Module



Connections:

Ultrasonic Sensor (HC-SR04) → ESP32

- VCC → 5V (VIN)
- TRIG → D5
- ECHO → D18
- GND → GND

IR Sensor Module → ESP32

- VCC → 5V (VIN)
- OUT → D19
- GND → GND