

5.4 Coolant Filter Replacement

The coolant filter must be inspected every 600 operating hours and replaced if discoloration or particulate buildup is visible. Use only the manufacturer-approved filter cartridge, part number CF-2201.

To replace the filter, first isolate the coolant loop at the shutoff valve, then remove the filter housing cap by turning it counter-clockwise. Discard the old cartridge and o-ring seal.

WARNING: Allow the coolant system to cool for at least 30 minutes before servicing. Residual pressure in the housing can eject the cap.