APPLICATION

XTS TRANSPORT LAYER

<<global>>
GVL_XTS

StationStart	ST_STATION_PARAMETER
Station	ARRAY [1..MAX_STATION] OF fb_Station
StationList	ARRAY [1..MAX_STATION] OF fb_Station_LinkedListCtrl
StationListItf	ARRAY [1..MAX_STATION] OF I_Station_LinkedList
StationCtrlItf	ARRAY [1..MAX_STATION] OF I_XtsTransport_Station
StationCtrl	ARRAY [1..MAX_STATION] OF ST_STATION_CTRL
StationState	ARRAY [1..MAX_STATION] OF ST_STATION_STATE
StationParameter	ARRAY [1..MAX_STATION] OF ST_STATION_PARAMETER
PositionOffset	ARRAY [1..MAX_STATION] OF T_NEST_OFFSET
XtsTransport	fb_TransportUnit
XtsTransportCtrl	ST_XTS_TRANSPORT_CTRL
XtsTransportState	ST_XTS_TRANSPORT_STATE
Xpu	fb_XpuCtrl
XpuCtrl	ST_XPU_CTRL
XpuState	ST_XPU_STATE
XpuInfo	ST_XPU_INFO
XpuModules	ARRAY [1..MAX_MODULE] OF Tc3_XTS_Utility.ST_InfoDataView
CaGroup	FB_CaGroup
CaGroupItf	I_XtsTransport_CaGroup
CaGroupRef	Tc3_McCoordinatedMotion.AXES_GROUP_REF
CaGroupInfo	ST_GROUP_INFO
Mover	ARRAY [1..MAX_MOVER] OF fb_MoverCtrl
MoverCtrl	ARRAY [1..MAX_MOVER] OF ST_MOVER_CTRL
MoverState	ARRAY [1..MAX_MOVER] OF ST_MOVER_STATE
MoverItf	ARRAY [1..MAX_MOVER] OF I_XtsTransport_Mover
LastPosition	ARRAY [1..MAX_MOVER] OF LREAL
LastGap	ARRAY [1..MAX_MOVER] OF LREAL
MoverInfo	ARRAY [1..MAX_MOVER] OF ST_MOVER_INFO
MoveData	ARRAY [1..MAX_MOVER] OF ST_MOVE_DATA
GearData	ARRAY [1..MAX_MOVER] OF ST_GEAR_DATA
AxisRefMover	ARRAY [1..MAX_MOVER] OF Tc2_MC2.AXIS_REF

<<global>>
XTS_Parameter

Version	STRING
MAX_MOVER	UINT
MAX_MODULE	UINT
MAX_PART	UINT
MAX_TRACK	UINT
MAX_GROUP	UINT
MAX_INFO_SERVER	UINT
MAX_INFO_STATION	UINT
MAX_INFO_STOP_POS	UINT
MAX_STATION	UINT
MAX_STATION_NEST	UINT
MAX_LIST_NODES	UINT
MAX_MASTER	UINT