

ENR 4

无线电导航设施/系统

RADIO NAVIGATION AIDS/SYSTEMS

ENR 4.1

无线电导航设施——航路

Radio navigation aids — en-route

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
阿克苏 Aksu VOR/DME	KQS	112.1 MHz CH 58X	H24	N41°15.7' E080°19.5'	1 188	
阿里 Ali VOR/DME	KUS	113.7 MHz CH 84X	H24	N31°58.9' E080°07.6'		
阿勒泰 Altay VOR/DME	TAI	114.3 MHz CH 90X	H24	N47°44.8' E088°05.0'	766	
庵东 Andong VOR/DME	AND	114.8 MHz CH 95X	H24	N30°15.4' E121°13.3'	32	
按树林 Anshulin VOR/DME	JHG	112.5 MHz CH 72X	H24	N22°03.1' E100°53.1'	1 233	For VOR/DME: R105 °R215 °clockwise U/S (except R109 °for SID/STAR、R156 °for initial approach procedure) .
柏鹤寺 Baihesi VOR/DME	BHS	117.9 MHz CH 126X	H24	N30°30.7' E104°12.0'		For VOR: Beyond 20NM on R219 °for STAR U/S; For DME: Beyond 24NM on R082 °for STAR U/S.
邦达 Bangda VOR/DME	DCH	113.3 MHz CH 80X	H24	N30°31.3' E097°08.5'	4 322	R005 °R100 °clockwise, R180 °R300 ° clockwise, beyond 22NM on R003 °, beyond 19NM on R097 °, beyond 20NM on R107 °, and beyond 8NM on R258 °U/S.
半塔集 Bantaji NDB	OF	340 kHz	H24	N32°40.4' E118°34.7'		

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
抱龙 Baolong NDB	WL	426 kHz	H24	N18°29.3' E109°24.2'		Range: 200NM; BRG052 °for initial approach procedure and STAR, within 5NM on BRG170 °for STAR and ENR, within 5NM on BRG206 °for STAR and HLDG, beyond 25NM on BRG206 °for ENR, within 3.5NM on BRG291 °for STAR U/S.
包头 Baotou VOR/DME	BAV	117.3 MHz CH 120X	H24	N40°33.4' E109°59.9'	1 019	
倍加皂 Beijiazao VOR/DME	BJZ	108.2 MHz CH 19X	H24	N40°03.3' E113°29.6'		
奔牛 Benniu NDB	ZJ	217 kHz	H24	N31°56.5' E119°42.6'		
博鳌 Boao VOR/DME	DBA	115.4 MHz CH 101X	H24	N19°09.7' E110°26.5'	33	For DME:beyond 30NM on R272 °U/S.
百色 Bose VOR/DME	BSE	115.9 MHz CH 106X	H24	N23°55.4' E106°36.1'	380	
蔡甸 Caidian VOR/DME	DCD	114.25 MHz CH 89Y	H24	N30°26.4' E114°09.5'	50	For VOR: BTN 16-17.7NM on R030 °U/S.
岑村 Cencun VOR/DME	CEN	114.6 MHz CH 93X	H24	N23°09.1' E113°25.0'	108	For VOR/DME: R130 °for HLDG and IAP, R135 °for missed approach U/S; For DME: BTN 23.5-25NM on R157 °for IAP U/S.
茶庵 Cha'an VOR/DME	HFC	111.8 MHz CH 55X	H24	N32°04.8' E116°46.1'	47	
昌北 Changbei VOR/DME	NCH	115.1 MHz CH 98X	H24	N28°53.1' E115°54.7'	43	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
常德 Changde NDB	CD	225 kHz	H24	N28°50.9' E111°37.3'		Beyond 12NM on BRG009 °for SID U/S.
昌都 Changdu NDB	RG	247 kHz	H24	N31°08.8' E097°10.6'		BTN 17-25NM on BRG 003 °;beyond 12NM on BRG 052 °;BTN 9-12NM on BRG 059 ° U/S.
长海 Changhai VOR/DME	CHI	116.8 MHz CH 115X	H24	N39°16.0' E122°37.0'	46	For VOR: BTN 29-31NM on R257 °for STAR U/S.
长生桥 Changshengqiao VOR/DME	SHC	111.0 MHz CH 47X	H24	N29°25.9' E106°43.7'	500	
长武 Changwu NDB	HO	375 kHz	H24	N35°12.6' E107°46.1'		Beyond 40NM on BRG 070 °U/S.
长治 Changzhi NDB	SQ	398 kHz	H24	N36°14.4' E113°07.0'		
朝阳 Chaoyang VOR/DME	CHG	114.5 MHz CH 92X	H24	N41°32.2' E120°26.0'	183	
茶山 Chashan VOR/DME	KGF	116.45 MHz CH 111Y	H24	N30°09.0' E114°45.7'	114	
车道峪 Chedaoyu NDB	CDY	292 kHz	H24	N40°34.7' E117°13.4'		U/S.
承德 Chengde VOR/DME	DHC	112.3 MHz CH 70X	H24	N41°07.7' E118°02.8'	687	
成都 Chengdu NDB	ZW	260 kHz	H24	N30°30.0' E103°54.5'		Beyond 30NM on BRG122 °; beyond 10NM on BRG260 °for SID, beyond 10NM on BRG269 °for STAR/SID U/S.

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
程海 Chenghai VOR/DME	CEH	113.4 MHz CH 81X	H24	N26°39.9' E100°43.2'	2 629	
赤峰 Chifeng VOR/DME	CHF	115.5 MHz CH 102X	H24	N42°11.4' E118°48.7'	748	
崇州 Chongzhou VOR/DME	CZH	114.5 MHz CH 92X	H24	N30°38.7' E103°41.2'		
从化 Conghua VOR/DME	CON	113.0 MHz CH 77X	H24	N23°35.3' E113°35.2'	77	For DME: Beyond 16NM on R011 °for HLDG, beyond 29NM on R320 °for STAR U/S.
大虎山 Dahushan VOR/DME	DHN	116.5 MHz CH 112X	H24	N41°38.7' E122°06.9'		
大理 Dali VOR/DME	DAL	112.6 MHz CH 73X	H24	N25°38.6' E100°19.4'	2 199	For VOR/DME: R064 °R107 °clockwise U/S; For DME: Beyond 22NM on R020 °for STAR/SID U/S.
大连 Dalian VOR/DME	DBL	115.4 MHz CH 101X	H24	N38°57.7' E121°34.2'	59	
丹东 Dandong VOR/DME	DDG	113.9 MHz CH 86X	H24	N40°15.4' E124°17.0'	98	For VOR/DME: R043 °R200 °clockwise (except within 6NM on R114 °for ENR, R192 °for SID, R194 °for STAR) U/S; For VOR: R012 °R023 °clockwise U/S; For DME: Beyond 14NM on R004 °for STAR/SID, R005 °R028 °clockwise, beyond 10NM on R188 °for IAP and missed approach, beyond 17NM on R210 °for initial approach procedure U/S.
党山 Dangshan VOR/DME	DSH	117.3 MHz CH 120X	H24	N30°08.9' E120°30.1'	38	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
当阳 Dangyang NDB	VL	261 kHz	H24	N30°45.1' E111°51.2'		
稻城 Daocheng VOR/DME	MYD	115.9 MHz CH 106X	H24	N29°21.4' E100°02.7'	4 428	
大榕江 Darongjiang NDB	VQ	398 kHz	H24	N25°33.7' E110°28.6'		
大托铺 Datuopu NDB	ZK	520 kHz	H24	N28°01.1' E112°57.8'		
大王庄 Dawangzhuang VOR/DME	VYK	112.7 MHz CH 74X	H24	N39°11.7' E116°34.3'		
磴口 Dengkou VOR/DME	DKO	113.5 MHz CH 82X	H24	N40°18.5' E106°57.8'	1 019	
德新 Dexin VOR/DME	CDX	116.35 MHz CH 110Y	H24	N31°15.0' E104°22.8'	540	R255 °R360 °clockwise U/S.
东定日 Dongdingri VOR/DME	DRD	117.1 MHz CH 118X	H24	N28°35.9' E086°54.9'	4 301	For VOR/DME: R141 °R220 °clockwise U/S; For VOR: beyond 20NM on R003 °for ENR, beyond 13NM on R003 °for STAR/SID, R310 °R016 (except R003) clockwise U/S; For DME: beyond 13NM on R003 °for ENR, beyond 9NM on R003 °for STAR/SID, R220 °R226 °clockwise, R307 °R036 (except R003) clockwise U/S.
东木栏头 Dongmulantu VOR/DME	MLT	112.7 MHz CH 74X	H24	N20°09.1' E110°40.4'	61	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
东山 Dongshan VOR/DME	DST	109.2 MHz CH 29X	H24	N27°45.0' E120°37.8'	39	For VOR: Beyond 22NM on R034 °for IAP U/S; For DME: Beyond 18NM on R034 °for IAP U/S.
东羊角 Dongyangjiao NDB	PU	296 kHz	H24	N41°30.4' E123°17.5'		
东营 Dongying VOR/DME	DYN	114.0 MHz CH 87X	H24	N37°31.7' E118°47.2'	14	
敦煌 Dunhuang VOR/DME	DNH	115.5 MHz CH 102X	H24	N40°09.8' E094°50.7'	1 123	
额济纳旗 Ejinaqi VOR/DME	JNQ	112.7 MHz CH 74X	H24	N41°59.4' E101°03.0'		
恩施 Enshi VOR/DME	ENH	114.7 MHz CH 94X	H24	N30°17.5' E109°36.1'	1 147	For VOR: BTN 10-12.2NM on R266 °for SID U/S.
二连浩特 Erenhot VOR/DME	LHT	112.5 MHz CH 72X	H24	N43°24.8' E112°07.6'	1 014	R255 °R025 °clockwise (except R283 °, R297 °, R314 °and R335 °) U/S.
二塘 Ertang NDB	QP	213 kHz	H24	N24°40.2' E110°46.6'		
阜康 Fukang VOR/DME	FKG	116.3 MHz CH 110X	H24	N44°10.4' E087°59.0'	551	For DME: Beyond 15NM on R224 °and beyond 33NM on R245 °U/S.
涪陵 Fuling VOR/DME	FLG	114.0 MHz CH 87X	H24	N29°42.0' E107°22.7'		For VOR: R360 °R010 °clockwise, R165 °R190 °clockwise, R210 °R225 °clockwise U/S; For DME: R165 °R240 °clockwise, beyond 17NM on R247 °for SID, beyond 24NM on R247 °for ENR U/S.

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
福清 Fuqing VOR/DME	FQG	117.4 MHz CH 121X	H24	N25°44.4' E119°23.1'		Beyond 24NM on R040 °and R041 °for IAP U/S.
扶绥 Fusui VOR/DME	FSL	112.05 MHz CH 57Y	H24	N22°26.1' E107°50.0'	270	
阜阳 Fuyang VOR/DME	FYG	112.9 MHz CH 76X	H24	N32°53.0' E115°44.0'	42	For VOR: Beyond 27NM on R316 °U/S.
扶余 Fuyu VOR/DME	FYU	113.7 MHz CH 84X	H24	N44°54.7' E124°48.2'		
富蕴 Fuyun VOR/DME	XFY	114.7 MHz CH 94X	H24	N46°47.7' E089°32.4'	938	
福州 Fuzhou VOR/DME	FOC	116.8 MHz CH 115X	H24	N25°54.8' E119°39.1'		R010 °R160 °clockwise (except R014 °, R030 °) U/S.
高栏 Gaolan NDB	UJ	204 kHz	H24	N21°55.2' E113°17.6'		
高密 Gaomi NDB	YO	443 kHz	H24	N36°26.3' E119°41.3'		
高要 Gaoyao VOR/DME	GYA	116.5 MHz CH 112X	H24	N23°04.2' E112°29.2'		For VOR/DME: Beyond 21NM on R093 °, beyond 23NM on R097 °, R320 °R358 ° clockwise U/S.
耿马 Gengma VOR/DME	GMA	114.7 MHz CH 94X	H24	N23°31.7' E099°24.5'		R150 °R340 °clockwise (except R184 °for STAR, R252 °for ENR, R317 °for HLDG) U/S.
广元 Guangyuan VOR/DME	GYN	115.1 MHz CH 98X	H24	N32°23.2' E105°41.4'	627	
观澜 Guanlan VOR/DME	GLN	112.0 MHz CH 57X	H24	N22°42.5' E114°02.0'		

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
贵阳 Guiyang VOR/DME	KWE	114.3 MHz CH 90X	H24	N26°31.4' E106°47.7'	1 178	
谷塘 Gutang NDB	W	388 kHz	H24	N28°13.1' E113°13.0'		Beyond 10NM on BRG049 °for STAR, beyond 8NM on BRG074 °for SID, within 10NM on BRG083 °for ENR, BRG091 °for SID U/S.
固原 Guyuan VOR/DME	GUY	112.6 MHz CH 73X	H24	N36°04.8' E106°12.9'	1 735	For DME:Beyond 31NM on R219 °for ENR U/S.
海拉尔 Hailar VOR/DME	HLD	115.1 MHz CH 98X	H24	N49°12.2' E119°49.3'	667	
海青 Haiqing NDB	IJ	394 kHz	H24	N47°52.1' E134°38.7'		BRG130 °BRG060 °clockwise, within 15NM on BRG 081 °U/S.
杭州 Hangzhou VOR/DME	HGH	113.0 MHz CH 77X	H24	N30°14.4' E120°27.7'	13	
哈尔滨 Harbin VOR/DME	HRB	112.5 MHz CH 72X	H24	N45°37.6' E126°15.6'	137	
荷芭湖 Hebaohu VOR/DME	DHB	114.45 MHz CH 91Y	H24	N30°41.9' E113°58.3'	100	
黑河 Heihe VOR/DME	HEK	114.0 MHz CH 87X	H24	N50°10.1' E127°18.6'	330	R330 °R190 °clockwise (except R029 °for STAR/SID/ENR, R189 °and R190 °for IAP, R165 °and R351 °for IAP, RWY35 DME for IAP) U/S.
河口 Hekou VOR/DME	HOK	116.0 MHz CH 107X	H24	N31°19.5' E114°25.8'		For DME:Beyond 62NM on R226 °for SID U/S.
合流水 Heliushui NDB	DS	250 kHz	H24	N30°12.0' E106°50.9'		

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
横沙 Hengsha VOR/DME	HSH	114.4 MHz CH 91X	H24	N31°22.1' E121°50.8'	24	
衡水 Hengshui NDB	HG	350 kHz	H24	N37°43.0' E115°42.3'		
河西 Hexi NDB	SB	319 kHz	H24	N27°44.4' E102°09.9'		BTN 5-18NM on BRG 051 °for SID, BTN 6-11NM, 17-19NM on BRG 132 °for SID, BTN 5-11NM, 19-22NM on BRG 245 °for SID, BTN 11-16NM on BRG 345 °for SID U/S.
呼和浩特 Hohhot VOR/DME	HET	116.9 MHz CH 116X	H24	N40°43.5' E111°54.0'	1 095	
和田 Hotan VOR/DME	HTN	113.1 MHz CH 78X	H24	N37°02.2' E079°52.1'	1 431	
淮安 Huaian VOR/DME	HUN	113.3 MHz CH 80X	H24	N33°46.4' E119°06.6'	18	
怀来 Huailai NDB	KM	360 kHz	H24	N40°23.3' E115°29.8'		U/S.
怀柔 Huairou VOR/DME	HUR	113.6 MHz CH 83X	H24	N40°19.8' E116°44.9'	62	
黄城 Huangcheng VOR/DME	HCH	116.1 MHz CH 108X	H24	N37°39.3' E120°32.7'	34	
黄陂 Huangpi VOR/DME	DHP	113.75 MHz CH 84Y	H24	N30°52.2' E114°28.2'	55	
黄平 Huangping VOR/DME	KHP	113.4 MHz CH 81X	H24	N26°58.4' E107°59.5'	943	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
黄山 Huangshan VOR/DME	TXN	116.1 MHz CH 108X	H24	N29°44.3' E118°15.2'	141	BTN 37-49.5NM on R011 °for STAR/SID U/S.
花垣 Huayuan VOR/DME	HUY	112.0 MHz CH 57X	H24	N28°34.8' E109°27.0'		R010 °R040 °clockwise, beyond 26NM on R194 °for ENR U/S.
湖光 Huguang NDB	LH	356 kHz	H24	N21°08.1' E110°20.0'		Beyond 30NM on BRG120 °for ENR, BTN 8-15NM, 26-32NM, beyond 36NM on BRG174 °for ENR, beyond 37NM on BRG175 °for SID, BTN 6-12NM, beyond 25NM on BRG187 °for STAR, BRG196 °BRG206 °clockwise, BTN 5-14NM on BRG228 °for SID U/S.
回龙 Huilong VOR/DME	HLC	115.95 MHz CH 106Y	H24	N30°18.1' E103°41.7'	567	
回龙山 Huilongshan VOR/DME	MOU	114.95 MHz CH 96Y	H24	N30°36.7' E114°59.3'	112	
佳木斯 Jiamusi VOR/DME	JMU	113.5 MHz CH 82X	H24	N46°50.5' E130°27.9'	91	
江北 Jiangbei VOR/DME	CKG	116.1 MHz CH 108X	H24	N29°44.8' E106°39.2'	418	
笕桥 Jianqiao NDB	CJ	324 kHz	H24	N30°18.3' E120°10.0'		
胶北 Jiaobei VOR/DME	JDW	116.85 MHz CH 115Y	H24	N36°19.8' E119°58.6'	49	
胶东 Jiaodong VOR/DME	JDG	114.45 MHz CH 91Y	H24	N36°22.7' E120°04.0'	13	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
嘉峪关 Jiayuguan VOR/DME	JSG	116.1 MHz CH 108X	H24	N39°50.7' E098°21.4'	1 557	
济南 Jinan VOR/DME	YQG	113.7 MHz CH 84X	H24	N36°50.0' E117°12.9'	31	
静宁 Jingning VOR/DME	JIG	113.7 MHz CH 84X	H24	N35°31.9' E105°43.4'		
景泰 Jingtai VOR/DME	JTA	114.9 MHz CH 96X	H24	N37°11.8' E104°04.8'		For VOR: Beyond 37NM on R307 °for ENR U/S; For DME: Beyond 28NM on R307 °for ENR U/S.
荆州 Jingzhou VOR/DME	DJZ	115.55 MHz CH 102Y	H24	N30°15.8' E112°26.9'	45	
晋江 Jinjiang VOR/DME	JNJ	117.0 MHz CH 117X	H24	N24°48.1' E118°35.8'	16	Beyond 15NM on R150 °R235 °clockwise U/S.
晋宁 Jinning VOR/DME	XSJ	108.2 MHz CH 19X	H24	N24°41.0' E102°48.0'	2 383	
金堂 Jintang VOR/DME	JTG	115.4 MHz CH 101X	H24	N30°52.3' E104°23.4'		For VOR: Beyond 24NM on R029 °for STAR, beyond 37NM on R068 °for SID, R170 °R205 °clockwise, beyond 20NM on R206 °for SID, R320 °R360 °clockwise U/S; For DME: Beyond 40NM on R068 °for SID, R170 °R205 °clockwise U/S.
金埡 Jinya VOR/DME	DJY	115.0 MHz CH 97X	H24	N31°02.7' E107°25.8'	428	
九亭 Jiuting VOR/DME	JTN	109.6 MHz CH 33X	H24	N31°07.4' E121°20.5'	28	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
九洲 Jiuzhou VOR/DME	ZAO	117.2 MHz CH 119X	H24	N22°14.7' E113°36.7'	47	
济源 Jiyuan NDB	GU	234 kHz	H24	N35°06.6' E112°31.8'		
开原 Kaiyuan VOR/DME	KYU	114.9 MHz CH 96X	H24	N42°37.9' E124°00.4'		
康定 Kangding VOR/DME	KDJ	112.4 MHz CH 71X	H24	N30°08.5' E101°43.9'	4 247	For VOR: R040 °R115 °clockwise (except within 15NM on R069 °for SID/ENR, within 8.5NM on R086 °for SID/ENR) U/S; For DME: R030 °R120 °clockwise (except within 10NM on R069 °for SID/ENR, within 8.5NM on R086 °for SID/ENR) U/S.
喀什 Kashi VOR/DME	KHG	115.7 MHz CH 104X	H24	N39°32.8' E076°01.4'	1 401	
寇岭 Kouling VOR/DME	KLX	110.6 MHz CH 43X	H24	N34°15.9' E109°14.9'	908	For VOR: Beyond 10NM on R100 °for SID U/S; For DME: Beyond 20NM on R339 °and R340 °for initial approach procedure U/S.
临沂 LINYI VOR/DME	LNK	112.8 MHz CH 75X	H24	N35°03.0' E118°24.8'	74	
来宾 Laibin VOR/DME	LBN	113.7 MHz CH 84X	H24	N23°45.8' E109°08.8'	126	
莱阳 Laiyang NDB	FD	298 kHz	H24	N36°55.8' E120°37.9'		
兰州 Lanzhou VOR/DME	DNC	114.0 MHz CH 87X	H24	N36°32.5' E103°37.1'	1 965	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
老粮仓 Laoliangcang NDB	GJ	245 kHz	H24	N28°05.0' E112°13.0'		
老粮仓 Laoliangcang VOR/DME	LLC	116.2 MHz CH 109X	H24	N28°04.1' E112°12.5'		For VOR: Beyond 65NM on R039 °; beyond 45NM on R092 °for STAR U/S; For DME: Beyond 42NM on R039 °; beyond 39NM on R083 °for STAR, beyond 35NM on R092 °for STAR, beyond 45NM on R186 °U/S.
拉萨 Lhasa VOR/DME	LXA	113.1 MHz CH 78X	H24	N29°17.8' E090°59.9'	3 571	For VOR:R175 °R185 °clockwise U/S; For DME:R168 °R220 °clockwise U/S.
凉城 Liangcheng NDB	SZ	282 kHz	H24	N40°31.1' E112°29.7'		BTN 4-6NM on BRG 312 °; BTN 4-6NM and 14-16NM on BRG 315 °; beyond 17NM on BRG 343 °U/S.
良乡 Liangxiang NDB	JR	475 kHz	H24	N39°43.2' E116°05.7'		
连江 Lianjiang VOR/DME	LJG	117.6 MHz CH 123X	H24	N26°13.2' E119°32.9'		For VOR/DME: R070 °150 °clockwise (except R107 °for IAP, R131 °for SID) U/S; For DME: beyond 35NM on R006 °for ENR, beyond 10NM on R131 °for SID U/S.
连胜围 Lianshengwei VOR/DME	ZUH	116.7 MHz CH 114X	H24	N22°13.3' E113°28.0'	68	For VOR/DME: R136 °156 °clockwise (except R147 °), beyond 16NM on R210 °for STAR/IAP U/S; For DME:beyond 15NM on R147 °for ENR,beyond 23NM on R227 °for IAP U/S.
连云港 Lianyungang VOR/DME	GFK	117.65 MHz CH 123Y	H24	N34°23.5' E119°09.9'	18	
荔波 Libo VOR/DME	GLB	112.8 MHz CH 75X	H24	N25°27.3' E107°57.8'	854	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
丽江 Lijiang VOR/DME	LJA	113.7 MHz CH 84X	H24	N26°46.4' E100°16.4'	2 438	For VOR/DME: Within 0.4NM on R015 °for IAP, R070 °R090 °clockwise, within 0.8NM on R195 °for IAP U/S; For VOR: Beyond 25NM enroute ALT 5100m on R053 °, beyond 22NM on R106 ° for STAR U/S; For DME: Beyond 17NM enroute ALT 5100m on R053 °, beyond 13NM on R106 ° for STAR, beyond 26NM enroute ALT 4800m on R179 °, R319 °R321 °clockwise U/S.
醴陵 Liling VOR/DME	LIG	112.4 MHz CH 71X	H24	N27°38.9' E113°31.0'	85	
临澧 Linli VOR/DME	LIN	117.5 MHz CH 122X	H24	N29°21.2' E111°38.9'	108	
柘社 Lishe NDB	BK	227 kHz	H24	N29°53.7' E121°20.0'		BRG113 °for initial approach procedure, BRG130 °for STAR/SID, BTN 11-15.5NM on BRG273 °for STAR/SID, BTN 2.5-3.5NM on BRG307 °for STAR, BTN 2.5-3.5NM on BRG308 °for SID, BTN 2-5NM on BRG323 °for SID U/S.
六盘水 Liupanshui VOR/DME	LPS	116.3 MHz CH 110X	H24	N26°38.6' E105°01.8'	2 101	
浏阳 Liuyang VOR/DME	LYH	113.55 MHz CH 82Y	H24	N28°23.6' E113°20.6'	215	
龙口 Longkou VOR/DME	LKO	115.8 MHz CH 105X	H24	N29°54.4' E113°41.5'		For VOR: R050 °R080 °clockwise U/S.
龙门 Longmen VOR/DME	LMN	116.3 MHz CH 110X	H24	N23°38.9' E114°19.6'	39	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
龙州 Longzhou VOR/DME	LON	112.2 MHz CH 59X	H24	N22°21.4' E106°52.1'		R130 °R030 °clockwise(except R226 °),beyond 4NM on R226 U/S.
隆子 Longzi VOR/DME	LZP	112.3 MHz CH 70X	H24	N28°25.8' E092°13.1'	4 046	For VOR/DME: R105 °R255 °clockwise U/S; For VOR: R340 °R050 °clockwise (except R359 °for STAR/SID), beyond 15NM on R359 °for STAR/SID U/S; For DME: R255 °R280 °clockwise (except R271 °for ENR, R275 °for HLDG), R325 °R065 °clockwise (except R359 °for STAR/SID, R064 °for ENR), beyond 10NM on R359 °for STAR/SID, beyond 22NM on R064 °for ENR U/S.
滦县 Luanxian VOR/DME	LUX	117.1 MHz CH 118X	H24	N39°44.5' E118°43.6'		For VOR:beyond 21NM on R273 °for SID,beyond 29NM on R275 °for SID U/S.
芦冲 Luchong NDB	SV	345 kHz	H24	N28°13.0' E113°20.9'		
禄口 Lukou VOR/DME	NJL	113.6 MHz CH 83X	H24	N31°45.3' E118°53.2'	24	R182 °R202 °clockwise, R300 °R320 °clockwise, R332 °R350 °clockwise (except on R349 °for ENR) U/S.
洛川 Luochuan VOR/DME	WJC	115.3 MHz CH 100X	H24	N35°46.7' E109°22.6'	1 117	
骆岗 Luogang VOR/DME	HFE	116.7 MHz CH 114X	H24	N31°46.5' E117°18.1'	89	For VOR: R314 °for IAP U/S.
洛阳 Luoyang VOR/DME	LYA	114.1 MHz CH 88X	H24	N34°44.5' E112°23.7'	268	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
泸西 Luxi VOR/DME	LXI	112.3 MHz CH 70X	H24	N24°32.5' E103°44.6'	1 753	For VOR/DME: BTN 70.2-83NM on R105 ° for HLDG U/S; For VOR: Beyond 38NM on R292 ° for SID U/S; For DME: Beyond 21NM on R292 ° for SID U/S.
马龙 Malong VOR/DME	DJT	114.6 MHz CH 93X	H24	N25°31.9' E103°36.3'	2 314	
芒市 Mangshi VOR/DME	LUM	114.1 MHz CH 88X	HO	N24°24.3' E098°32.4'	887	For VOR/DME: R090 °R260 °clockwise U/S (except R216 ° for HLDG); For VOR: Beyond 31NM on R086 ° for ENR U/S; For DME: Beyond 18NM on R086 ° for STAR/SID and beyond 27NM for ENR, beyond 28NM on R355 ° for ENR U/S.
满洲里 Manzhouli VOR/DME	MZL	113.1 MHz CH 78X	H24	N49°19.7' E117°38.7'		R320 °R100 °clockwise (except R007 °, R343 °) U/S.
玛旁雍 Mapangyong VOR/DME	OLP	113.4 MHz CH 81X	H24	N30°47.8' E081°23.7'	4 801	R090 °R208 °clockwise U/S.
绵阳 Mianyang VOR/DME	MYG	114.8 MHz CH 95X	H24	N31°26.0' E104°44.0'	538	
觅子 Mizi VOR/DME	MIZ	109.6 MHz CH 33X	H24	N34°49.2' E108°59.7'	631	
秣陵 Moling VOR/DME	MLJ	117.05 MHz CH 117Y	H24	N31°50.7' E118°51.3'	19	
牡丹江 Mudanjiang VOR/DME	MDJ	117.1 MHz CH 118X	H24	N44°30.9' E129°33.8'	278	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
那拉提 Nalati VOR/DME	NLT	115.5 MHz CH 102X	H24	N43°25.9' E083°22.7'	935	For VOR/DME: R135 °R205 °clockwise U/S; For DME: Beyond 27NM on R210 °for STAR/SID U/S.
南丰 Nanfeng NDB	NF	292 kHz	H24	N27°12.5' E116°33.5'		
南康 Nankang VOR/DME	BHY	117.1 MHz CH 118X	H24	N21°35.2' E109°25.9'	35	
南朗 Nanlang VOR/DME	NLG	117.7 MHz CH 124X	H24	N22°31.9' E113°33.7'	93	
南宁 Nanning VOR/DME	WUY	112.4 MHz CH 71X	H24	N22°35.1' E108°08.9'	142	
南泥湾 Nanniwan VOR/DME	NNW	114.75 MHz CH 94Y	H24	N36°25.2' E109°29.1'	1 314	For VOR: Within 0.2NM on R168 °; within 0.3NM on R348 °U/S. For DME: Within 0.1NM on R168 °; within 0.8NM on R348 °U/S.
南通 Nantong VOR/DME	NTG	115.6 MHz CH 103X	H24	N32°05.8' E120°58.7'	19	
南翔 Nanxiang NDB	PK	208 kHz	H24	N31°17.0' E121°19.8'		Beyond 4NM on BRG 002 °;beyond 7NM on BRG 243 °;BTN 7-12NM on BRG 264 °;BTN 14-19NM on BRG 292 °;beyond 3.5NM on BRG 350 °U/S.
南雄 Nanxiong VOR/DME	NNX	115.6 MHz CH 103X	H24	N25°05.7' E114°16.4'	39	
南浔 Nanxun VOR/DME	NXD	116.5 MHz CH 112X	H24	N30°53.8' E120°25.8'		
南阳 Nanyang NDB	ML	446 kHz	H24	N32°55.0' E112°33.0'		BRG180 °for STAR/SID U/S.

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
南盈滨岛 Nanyingbinda o VOR/DME	NYB	113.3 MHz CH 80X	H24	N20°00.9' E110°08.2'	27	
宁陕 Ningshan VOR/DME	NSH	116.3 MHz CH 110X	H24	N33°19.1' E108°18.7'		For VOR/DME: beyond 17NM on R029 °;beyond 8NM on R091 °, R140 °; beyond 18NM on R201 °; beyond 17NM on R204 °; beyond 25NM on R221 °; beyond 11NM on R262 °U/S; For VOR: R040 °R200 °clockwise,beyond 24NM on R071 °;R250 °R360 °clockwise (except R071 °,R091 °, R262 °) U/S; For DME: within 7NM and beyond 23NM on R015 °;within 7NM on R029 °; beyond 16NM on R071 °;BTN R250 °R210 °clockwise(except R015 °;R029 °;R071 °,R091 °,R201 °,R204 °;R209 °;R262 °) U/S.
牛岭 Niuling VOR/DME	JCS	116.6 MHz CH 113X	H24	N23°35.9' E116°24.7'	138	
鄂尔多斯 Ordos VOR/DME	HDS	116.1 MHz CH 108X	H24	N39°29.4' E109°51.7'	1 401	
盘龙 Panlong VOR/DME	XFA	110.8 MHz CH 45X	H24	N25°24.1' E102°56.0'	2 788	
蟠龙 Panlong VOR/DME	PLT	111.6 MHz CH 53X	H24	N25°48.5' E114°52.5'	163	
蓬莱 Penglai VOR/DME	YCS	116.4 MHz CH 111X	H24	N37°40.7' E121°00.0'	48	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
平洲 Pingzhou VOR/DME	POU	114.1 MHz CH 88X	H24	N23°01.3' E113°11.4'	27	For VOR/DME: Beyond 22NM on R009 ° for SID U/S; For VOR: Beyond 33NM on R339 °for SID U/S; For DME: Beyond 25NM on R339 °for SID U/S.
邳县 Pixian VOR/DME	DPX	112.4 MHz CH 71X	H24	N34°16.7' E117°59.9'		
泊头 Potou VOR/DME	BTO	115.9 MHz CH 106X	H24	N38°06.3' E116°34.6'		
浦东 Pudong VOR/DME	PUD	116.9 MHz CH 116X	H24	N31°10.3' E121°47.0'	15	
黔西 Qianxi VOR/DME	QNX	113.1 MHz CH 78X	H24	N27°02.5' E106°01.8'		
奇峰岭 Qifengling NDB	Y	417 kHz	H24	N25°10.3' E110°19.1'		
綦江 Qijiang VOR/DME	QJG	112.7 MHz CH 74X	H24	N29°03.1' E106°39.9'	426	For VOR:beyond 20NM on R011 °for STAR U/S; For DME:beyond 18NM on R011 °for STAR U/S.
青白口 Qingbaikou NDB	CD	422 kHz	H24	N40°00.8' E115°48.3'		Beyond 25NM on BRG 053 °;beyond 25NM on BRG 112 °;within 12NM on BRG 119 °;beyond 18NM on BRG 154 °;within 9NM and beyond 21NM on BRG 225 °;within 9NM on BRG 236 °;beyond 18NM on BRG 262 °U/S.
青岛 Qingdao VOR/DME	TAO	117.5 MHz CH 122X	H24	N36°17.3' E120°22.2'	18	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
庆阳 Qingyang VOR/DME	XFG	114.45 MHz CH 91Y	H24	N35°47.0' E107°37.3'	1 414	
齐齐哈尔 Qiqihar VOR/DME	NDG	112.9 MHz CH 76X	H24	N47°14.7' E123°55.2'		
奇台 Qitai VOR/DME	QTV	112.1 MHz CH 58X	H24	N43°59.3' E089°36.7'		
龟兹 Qiuci VOR/DME	XKC	114.1 MHz CH 88X	H24	N41°40.6' E082°50.6'	1 032	
日喀则 Rikaze VOR/DME	RKZ	113.5 MHz CH 82X	H24	N29°21.3' E089°16.3'	3 805	For VOR: R355 °R005 °clockwise U/S; For DME: R175 °R180 °; R350 °R010 ° clockwise U/S.
三江 Sanjiang VOR/DME	SJG	116.8 MHz CH 115X	H24	N25°46.6' E109°36.6'	342	
三峡 Sanxia VOR/DME	YIH	116.9 MHz CH 116X	H24	N30°32.1' E111°30.4'	186	
三亚 Sanya VOR/DME	SYX	112.5 MHz CH 72X	H24	N18°18.6' E109°10.4'	457	
三原 Sanyuan NDB	OD	202 kHz	H24	N34°35.9' E108°54.9'		Beyond 11NM on BRG108 °;beyond 12NM on BRG134 °;beyond 38NM on BRG200 °.
上马 Shangma VOR/DME	JDE	116.25 MHz CH 109Y	H24	N36°17.4' E120°15.2'	52	
上饶 Shangrao VOR/DME	SHR	114.0 MHz CH 87X	H24	N28°25.0' E117°58.2'		
商县 Shangxian NDB	RA	345 kHz	H24	N33°52.6' E109°55.8'		

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
商县 Shangxian VOR/DME	SHX	112.5 MHz CH 72X	H24	N33°52.6' E109°56.1'	756	For VOR/DME: beyond 19NM on R063 °U/S; For VOR: R300 °R070 °clockwise(except R063 °U/S; For DME: R320 °R060 °clockwise U/S.
山海关 Shanhaiguan NDB	LC	203 kHz	H24	N39°59.9' E119°47.1'		
汕头 Shantou VOR/DME	SWA	112.6 MHz CH 73X	H24	N23°26.4' E116°46.0'		
嵊州 Shengzhou VOR/DME	SHZ	113.4 MHz CH 81X	H24	N29°36.0' E120°49.0'		
沈阳 Shenyang VOR/DME	SEY	114.1 MHz CH 88X	H24	N41°38.5' E123°28.7'	59	
石各庄 Shigezhuang NDB	VM	280 kHz	H24	N39°17.8' E116°54.1'		U/S.
石龙 Shilong VOR/DME	SHL	115.7 MHz CH 104X		N23°05.5' E113°51.0'		U/S.
石湫 Shiqiu VOR/DME	SNQ	115.75 MHz CH 104Y	H24	N31°40.8' E118°58.1'	27	
狮泉河 Shiquanhe VOR/DME	SQH	114.5 MHz CH 92X	H24	N32°27.5' E080°03.6'		
双流 Shuangliu VOR/DME	CTU	115.7 MHz CH 104X	H24	N30°34.4' E103°56.6'	505	For DME: BTN 12-14NM on R290 °for ENR/SID U/S.
水泉 Shuiquan NDB	LS	445 kHz	H24	N45°27.0' E126°02.7'		

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
硕放 Shuofang VOR/DME	SUF	114.1 MHz CH 88X	H24	N31°29.9' E120°25.9'	11	
书院 Shuyuan VOR/DME	XSX	112.7 MHz CH 74X	H24	N30°55.9' E121°52.4'	27	
塔城 Tacheng VOR/DME	TCH	113.1 MHz CH 78X	H24	N46°39.5' E083°22.1'	619	R220 °R060 °clockwise(except on R277 °R283 °R297 °R299 °), beyond 11NM on R297 °U/S.
汤河口 Tanghekou NDB	YV	514 kHz	H24	N40°44.0' E116°38.0'		U/S.
桃花 Taohua VOR/DME	THA	114.7 MHz CH 94X	H24	N31°46.7' E117°07.4'	45	
陶家宫 Taojiagong VOR/DME	HAM	113.1 MHz CH 78X	H24	N42°50.6' E093°40.1'	843	For DME: Within 13NM on R290 °U/S.
天河 Tianhe VOR/DME	WHA	112.2 MHz CH 59X	H24	N30°46.9' E114°12.2'	43	
天河 Tianhe NDB	HG	254 kHz	H24	N30°55.5' E114°21.0'		Effective distance 25-150km BRG 360 °030 °clockwise U/S.
天津 Tianjin VOR/DME	TAJ	112.1 MHz CH 58X	H24	N39°06.6' E117°21.5'	11	
天门 Tianmen VOR/DME	WTM	108.8 MHz CH 25X	H24	N30°45.2' E113°08.5'	52	For VOR:BTN 36-44NM on R270 °U/S.
天山 Tianshan VOR/DME	XGD	112.05 MHz CH 57Y	H24	N30°41.5' E115°07.4'	178	
天镇 Tianzhen VOR/DME	TZH	115.6 MHz CH 103X	H24	N40°24.5' E114°03.1'		

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
通辽 Tongliao VOR/DME	TGO	116.3 MHz CH 110X	H24	N43°33.6' E122°11.8'	192	
桐庐 Tonglu VOR/DME	TOL	115.9 MHz CH 106X	H24	N29°45.8' E119°39.6'	54	For DME: R098 °R153 °beyond 32NM on R252 °R282 °R315 °and R328 °R338 °clockwise U/S.
铜仁 Tongren VOR/DME	TRN	115.2 MHz CH 99X	H24	N27°52.1' E109°17.6'	721	
土木尔台 Tumurtai VOR/DME	TMR	113.3 MHz CH 80X	H24	N41°50.6' E113°09.2'		
屯里 Tunli NDB	FZ	247 kHz	H24	N37°27.1' E121°10.7'		
乌鲁木齐 Urumqi VOR/DME	WUR	115.3 MHz CH 100X	H24	N43°54.8' E087°30.5'	664	
万昌 Wanchang VOR/DME	LJB	115.9 MHz CH 106X	H24	N43°46.4' E125°51.1'	199	
王滨沟 Wangbingou NDB	KY	365 kHz	H24	N41°42.3' E123°44.8'		
汪清 Wangqing VOR/DME	WQG	112.1 MHz CH 58X	H24	N43°17.6' E129°47.1'		For VOR/DME: R130 °R205 °clockwise U/S; For VOR: Beyond 20NM on R221 °for STAR/SID U/S; For DME: R035 °R068 °clockwise, beyond 16.3NM on R221 °for STAR/SID U/S.
潍坊 Weifang VOR/DME	WFG	116.6 MHz CH 113X	H24	N36°38.8' E119°07.2'	54	For DME:beyond 26NM on R349 °for ENR U/S.
威海 Weihai VOR/DME	WEH	115.8 MHz CH 105X	H24	N37°11.0' E122°13.6'	45	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
威宁 Weining NDB	HX	285 kHz	H24	N26°51.6' E104°16.9'		
尉氏 Weishi VOR/DME	DWS	117.4 MHz CH 121X	H24	N34°19.4' E114°04.7'	80	
魏县 Weixian VOR/DME	WXI	115.7 MHz CH 104X	H24	N36°21.8' E114°55.0'		
文昌 Wenchang VOR/DME	WCF	117.5 MHz CH 122X	H24	N19°51.1' E110°47.3'	49	
翁源 Wengyuan VOR/DME	WYN	113.9 MHz CH 86X	H24	N24°21.0' E114°06.7'	43	For DME: Beyond 33NM on R098 U/S.
闻堰 Wenyan NDB	WY	572 kHz	H24	N30°07.3' E120°12.1'		BTN 2-4NM on BRG066 °for STAR/SID, BTN 2-6NM on BRG157 °for STAR/SID, BRG224 °for SID, BRG237 °- BRG239 ° clockwise, BRG249 °for SID U/S.
温州 Wenzhou VOR/DME	WNZ	116.4 MHz CH 111X		N27°55.8' E120°51.8'	16	
吴川 Wuchuan VOR/DME	WUQ	116.25 MHz CH 109Y	H24	N21°29.3' E110°41.9'	41	
武当山 Wudangshan VOR/DME	DSY	115.15 MHz CH 98Y	H24	N32°34.3' E110°56.1'	364	R130 °R240 °clockwise (except R135 °and R150 °) U/S.
五凤溪 Wufengxi VOR/DME	WFX	117.1 MHz CH 118X	H24	N30°36.4' E104°29.5'		
无极 Wuji NDB	FL	272 kHz	H24	N38°14.9' E114°53.3'		

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
五粮液 Wuliangye VOR/DME	WLY	112.9 MHz CH 76X	H24	N28°51.0' E104°33.8'	400	For VOR: Within 0.3NM on R109 °U/S.
巫山 Wushan VOR/DME	SNF	112.15 MHz CH 58Y	H24	N31°04.5' E109°42.7'	1 779	
五通 Wutong NDB	PA	286 kHz		N25°24.3' E110°03.6'		U/S
无锡 Wuxi VOR/DME	VMB	113.9 MHz CH 86X	H24	N31°44.6' E120°11.5'	38	
吴忠 Wuzhong VOR/DME	DWZ	112.4 MHz CH 71X	H24	N37°55.3' E106°20.6'	1 103	
厦门 Xiamen VOR/DME	XMN	114.5 MHz CH 92X	H24	N24°32.6' E118°07.4'	23	R062 ° R222 ° clockwise U/S.
襄阳 Xiangyang NDB	NO	233 kHz	H24	N32°04.5' E112°16.6'		
小丹阳 Xiaodanyang VOR/DME	XDY	115.15 MHz CH 98Y	H24	N31°40.0' E118°43.0'	51	
西昌 Xichang VOR/DME	XIC	114.2 MHz CH 89X	H24	N28°00.2' E102°11.0'	1 566	For DME: R076 ° R110 ° clockwise U/S.
锡林浩特 Xilinhot VOR/DME	HOT	114.3 MHz CH 90X	H24	N43°54.9' E115°58.0'	1 021	
杏林 Xinglin VOR/DME	XLN	114.7 MHz CH 94X	H24	N24°33.9' E118°00.9'	46	R090 ° R185 ° clockwise, beyond 43NM on R359 ° for STAR/SID U/S.
行唐 Xingtang NDB	OC	235 kHz	H24	N38°27.3' E114°33.3'		

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
西宁 Xining VOR/DME	XNN	116.5 MHz CH 112X	H24	N36°31.6' E102°01.8'	2 196	For VOR: beyond 31-33NM on R070 °for ENR U/S; For DME: beyond 34NM on R070 °for ENR, beyond 18NM on R165 °for STAR/SID, beyond 36NM on R165 °for ENR, beyond 38NM on R334 °for ENR U/S.
新郑 Xinzheng VOR/DME	CGO	114.5 MHz CH 92X	H24	N34°31.1' E113°50.6'	158	
西山 Xishan VOR/DME	SGM	110.6 MHz CH 43X	H24	N25°04.9' E102°31.2'	2 312	
浠水 Xishui VOR/DME	XSH	115.4 MHz CH 101X	H24	N30°26.1' E115°16.0'		For VOR/DME: Beyond 19.8NM on R207 °for STAR U/S. For DME: Beyond 36NM on R127 °for STAR U/S.
薛家岛 Xuejiadao VOR/DME	XDX	110.4 MHz CH 41X	H24	N35°58.7' E120°17.4'	110	For VOR:BTN43-44NM enroute ALT 4200m on R164 °U/S.
叙永 Xuyong VOR/DME	XYO	116.7 MHz CH 114X	H24	N28°10.3' E105°25.2'		
徐州 Xuzhou VOR/DME	XUZ	114.3 MHz CH 90X	H24	N34°03.6' E117°33.0'	6	
雅布赖 Yabrai VOR/DME	YBL	115.7 MHz CH 104X	H24	N39°25.3' E102°46.5'		
盐城 Yancheng VOR/DME	YCH	115.3 MHz CH 100X	H24	N33°25.3' E120°12.3'	13	
扬州 Yangzhou VOR/DME	SJD	113.1 MHz CH 78X	H24	N32°32.7' E119°43.6'	13	

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
延吉 Yanji VOR/DME	YNJ	113.1 MHz CH 78X	H24	N42°53.0' E129°27.1'	210	R040 °R218 °clockwise(except the radial lines involved in flight procedures) U/S.
烟庄 Yanzhuang NDB	ZS	359 kHz	H24	N34°13.3' E108°51.2'		BRG 003 °for SID,within 6NM on BRG 030 °for STAR, within 5NM on BRG 072 °for SID, BRG 134 °for missed approach, beyond 5NM on BRG 140 °for STAR/SID , within 21NM on BRG 154 °for STAR/SID, BRG 180 °for STAR, BRG 230 °BRG270 ° clockwise, within 17NM on BRG 275 °for SID, BRG 294 °for HLDG, within 14NM and beyond 26NM on BRG 294 °for STAR and ENR, BRG 311 °for SID, within 20NM and beyond 38NM on BRG 311 °for ENR U/S.
姚集 Yaoji NDB	DO	266 kHz	H24	N34°04.5' E117°48.7'		
叶尔羌 Yarkant VOR/DME	DSC	112.5 MHz CH 72X	H24	N38°13.3' E077°04.3'	1 317	
银川 Yinchuan VOR/DME	YHD	112.0 MHz CH 57X	H24	N38°20.8' E106°24.6'	1 141	For VOR: BTN 24.5-29.5NM on R294 °for STAR/SID U/S; For DME: Beyond 38NM on R158 °for HLDG U/S.
英德 Yingde VOR/DME	YIN	113.5 MHz CH 82X	H24	N24°11.4' E113°24.9'	167	For VOR/DME: Beyond 30NM on R184 °for SID, beyond 30NM on R185 °for SID, beyond 31NM on R189 °for SID U/S; For DME: Beyond 26NM on R199 °for SID, beyond 39NM on R218 °for SID U/S.
伊宁 Yining VOR/DME	YNN	112.9 MHz CH 76X	H24	N43°57.4' E081°19.8'	681	
义乌 Yiwu VOR/DME	YEU	113.2 MHz CH 79X	H24	N29°19.9' E120°01.9'	87	For DME: beyond 20NM on R316 °U/S.

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
永福 Yongfu NDB	JW	281 kHz		N25°00.5' E110°01.0'		U/S
邕宁 Yongning VOR/DME	YNG	114.35 MHz CH 90Y	H24	N22°45.2' E108°30.9'	198	
源潭 Yuantan VOR/DME	TAN	112.5 MHz CH 72X	H24	N23°40.1' E113°14.5'	184	
玉都 Yudu VOR/DME	DJQ	114.7 MHz CH 94X	H24	N38°13.0' E085°26.6'	1 232	
榆林 Yulin VOR/DME	YLX	116.7 MHz CH 114X	H24	N38°22.9' E109°34.7'	1 195	
运城 Yuncheng VOR/DME	YCE	112.3 MHz CH 70X	H24	N35°06.8' E110°59.9'	405	
云和 Yunhe NDB	BZ	244 kHz	H24	N28°06.1' E119°33.7'		
咎岗镇 Zangangzhen NDB	JB	403 kHz	H24	N39°02.6' E116°11.9'		
泽当 Zedang NDB	DM	435 kHz	H24	N29°15.3' E091°45.9'		
张家界 Zhangjiajie VOR/DME	DYG	114.4 MHz CH 91X	H24	N29°05.6' E110°24.3'	246	Coverage for VOR: 200km. Coverage for DME: 350km. For VOR/DME: R120 °-R230 ° clockwise(except on R126 °) U/S; For VOR: Beyond 17NM on R126 °for STAR/SID U/S; For DME: Beyond 8NM on R126 °for STAR/SID U/S.

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
张家口 Zhangjiakou VOR/DME	HAR	113.9 MHz CH 86X	H24	N40°43.7' E114°57.8'	735	For DME: R004 °R027 °clockwise U/S.
张庄 Zhangzhuang NDB	AR	520 kHz	H24	N36°43.4' E116°55.0'		
昭通 Zhaotong VOR/DME	ZAT	115.5 MHz CH 102X	H24	N27°19.4' E103°45.3'		For VOR: Beyond 20NM on R077 °for STAR/SID U/S; For DME: Beyond 31NM on R027 °for ENR, R053 °R057 °clockwise, beyond 18NM on R077 °for STAR/SID, beyond 35NM on R077 °for ENR U/S.
正定 Zhengding VOR/DME	SJW	117.7 MHz CH 124X	H24	N38°16.8' E114°41.9'	68	
芷江 Zhijiang VOR/DME	ZHJ	117.8 MHz CH 125X	H24	N27°27.0' E109°42.5'	275	
中卫 Zhongwei VOR/DME	ZWX	117.5 MHz CH 122X	H24	N37°34.4' E105°07.5'	1 264	
中原 Zhongyuan VOR/DME	DZY	116.8 MHz CH 115X	H24	N34°43.6' E113°33.0'	196	
周口 Zhoukou VOR/DME	ZHO	115.5 MHz CH 102X	H24	N33°39.9' E114°39.3'	115	For DME: BTN 30-35NM on R341 °for SID U/S.
舟山 Zhoushan VOR/DME	HSN	112.3 MHz CH 70X	H24	N29°55.9' E122°21.8'	9	For DME: R098 °R106 °clockwise and R245 °R256 °clockwise U/S.

导航设施名称、类别 Name and Types of Aid	识别 ID	频率波道 Frequency Channel	工作时间 Hours of operation	坐标 Coordinates	DME 天线标高 ELEV of DME antenna(m)	备注 Remarks
祖庵 Zu'an VOR/DME	ZNX	110.8 MHz CH 45X	H24	N34°06.7' E108°30.2'	431	For VOR: Beyond 28NM on R157 °for ENR, R195-R210 °clockwise(except R195 ° and R209 °), beyond 24NM on R195 °; beyond 25NM on R209 °for ENR U/S. For DME: Beyond 47NM on R115 °for SID, R155-R220 °clockwise(except R157 °; R195 °and R209 °), beyond 22NM on R157 °; beyond 20NM on R195 °for SID, beyond 24NM on R209 °; beyond 55NM on R348 ° for STAR/SID U/S.