

PRESSURIZED Installation and Setup Instructions

Required Hardware

- PRESSURIZED arcade cabinet (plywood, self-contained unit)
- PRESSURIZED control deck (mounted inside cabinet lower section)
- Monitor / display (mounted inside cabinet upper section)
- MacBook or compatible computer running the Unity build
- Bluetooth speaker / boombox (for audio output, connected to Mac)
- Arduino Mega x2, Arduino Uno x1 (pre-installed in controller)
- USB cables: one per Arduino (3 total), routed from controller to laptop
- Power strip (for laptop, monitor, LED strips, and alarm light)
- LED strip power supply (pre-installed in controller)
- Alarm siren light (mounted on cabinet exterior, pre-wired)

Required Software

- Unity (version used during development) with the PRESSURIZED build installed
- Arduino IDE (for any debugging of serial communication. Not required for normal operation)
- The PRESSURIZED Unity build file (standalone executable)

Step-by-Step Launch

1. Position the arcade cabinet in the presentation space. Ensure adequate clearance for players on both sides.
2. Connect the power strip. Plug in the monitor, laptop, LED power supply, and alarm light.
3. Connect the USB cable from the controller Arduinos to the laptop. Verify all three are recognized by the operating system.
4. Power on the Bluetooth speaker and pair it to the laptop if not already paired.
5. Open the PRESSURIZED Unity build executable on the laptop.
6. Confirm the serial port connections are active in the Unity build (check the Command Manager script's serial port configuration if needed).
7. Verify LED backlighting activates on the controller. Verify the alarm light responds during gameplay.

8. Run a brief test play to confirm all inputs register correctly in-game.
9. Confirm the game audio is playing through the Bluetooth speaker at appropriate volume.
10. The game is ready for audience interaction. The start screen will display until a player initiates a session. Gameplay loops indefinitely.

Known Issues and Calibration Notes

- Arduino RAM is at capacity. Do not add additional processing logic to the Arduino scripts without first removing existing processes.
- Some input states may appear inverted on first boot if Arduino serial initializes before Unity opens. Restarting the Unity build resolves this.
- LED animations are driven by Unity via serial output. If LEDs are unresponsive, confirm the correct COM port is assigned to the Uno in the Unity build settings.
- Bluetooth speaker must be powered on before Unity build is launched for audio to route correctly.

Shutdown

1. Close the Unity build executable.
2. Disconnect USB cables from the laptop.
3. Power off the Bluetooth speaker.
4. Unplug the power strip.
5. The controller and cabinet can remain assembled for transport, or unscrewed into flat panels. Secure the control deck if relocating.