predetermined level

**Point of Delivery** means the physical connection point at which the water

leaves the Distribution System.

Premises means a tract or plot of land and includes the buildings

and any appurtenances on the land. Premises may contain more than one property or dwelling and more

than one Customer.

Pressure Relief Valve (PRV) means a pressure-activated valve which opens

automatically at a specified pressure to discharge fluid

**Responsible Person** means the person who assumes actual responsibility for

the installation or the ownership of the Water Fittings. (That person can be a contractor, a consultant or others as appointed or authorized by the owner to liaise with the Distribution Company to fulfil the requirements of the

water supply connection).

**Roof Tank** means a fixed container, cistern, or break tank located on

the roof of a building for the purpose of holding or storing water at atmospheric pressure and which does include a

Ground Storage Tank.

Servicing Valve means a valve for shutting off, for the purpose of

maintenance or service, the flow of water in a pipe

connected to a water fitting.

Stop Valve/Gate Valve means a valve, other than a Servicing Valve, used for

shutting off the flow of water in a pipe.

Tank Capacity in relation to a cistern or tank, the volume of storage,

excluding the unusable top level, measured up to the level of water that can be reached according to the inflow

control device setting.

**Terminal Fitting** means a water outlet device.

**Vent Pipe** means a pipe open to the atmosphere which exposes the

system to atmospheric pressure at its boundary.

Warning Device means a device that is installed in water storage tanks

(capacity >100,000 litres, or about 22,000 imperial

Guide to Water S	Supply Regulations 2017			
Author	Document	Version	Issue date	Approved by
KR/MSH	ER/P04/100	Issue 3	15 Dec. 2016	SSQ
		Page 7 of 8	6	